

Installing the IBM N series NFS Plug-in 1.0.20 for VMware VAAI



Installing the IBM N series NFS Plug-in 1.0.20 for VMware VAAI

Installing the IBM N series NFS Plug-in for VAAI (VMware vStorage APIs for Array Integration) involves enabling VMware vStorage for NFS on the IBM N series storage system, verifying that VAAI is enabled on the VMware host, downloading and installing the plug-in on the VMware ESXi host, and ensuring that the installation is successful.

Before you begin

- NFSv3 must be enabled on the storage system.
- VMware vSphere 5.0 or later must be available.

For more information about enabling NFS and using VMware vSphere, see the manuals listed in Step 10.

About this task

- If you are using the VMware ESXi CLI to install the plug-in, start with Step 1.
- If you are using Virtual Storage Console for VMware vSphere (VSC) to install the plug-in, start with Step 3.

VSC enables VMware vStorage for NFS on the storage controller and enables VAAI on the ESXi host, which are steps 1 through 2 of this procedure.

- Installing the NFS plug-in is a disruptive activity that requires rebooting the ESXi host before the installation is complete.

To ensure consistent access to the virtual machines residing on the ESXi host on which you are installing the NFS plug-in, you should consider virtual machine migrations, or install the NFS plug-in during planned maintenance windows.

IP address conventions used:

- IP addresses of the form 192.168.42.2xx refer to ESXi server VMkernel ports.
- IP addresses of the form 192.168.42.6x refer to 7-Mode systems.
- IP addresses of the form 192.168.42.8x refer to Storage Virtual Machines (SVMs, formerly known as Vservers) on systems running clustered Data ONTAP.

Procedure

1. Enable VMware vStorage for NFS by using one of the following methods:

If you use...	Then...
7-Mode CLI	Enable VMware vStorage for NFS on the storage system by using the following command: options nfs.vstorage.enable on

If you use...	Then...
7-Mode CLI for vFiler units	Enable VMware vStorage for NFS on the MultiStore vFiler unit hosting VMware NFS datastores by using the following command: vfiler run <i>vfiler_name</i> options nfs.vstorage.enable on

2. Verify that VAAI is enabled on each ESXi host. In VMware vSphere 5.0 and later, VAAI is enabled by default.

If you use...	Then...
VMware ESXi CLI	<ol style="list-style-type: none"> 1. Enter the following commands to verify that VAAI is enabled: esxcfg-advcfg -g /DataMover/ HardwareAcceleratedMove esxcfg-advcfg -g /DataMover/ HardwareAcceleratedInit If VAAI is enabled, these commands produce the following output: <pre style="border: 1px solid black; border-radius: 10px; padding: 5px;">~ # esxcfg-advcfg -g /DataMover/HardwareAcceleratedMove Value of HardwareAcceleratedMove is 1 ~ # esxcfg-advcfg -g /DataMover/HardwareAcceleratedInit Value of HardwareAcceleratedInit is 1</pre> 2. If VAAI is not enabled, enter the following commands to enable VAAI: esxcfg-advcfg -s 1 /DataMover/ HardwareAcceleratedInit esxcfg-advcfg -s 1 /DataMover/ HardwareAcceleratedMove These commands produce the following output: <pre style="border: 1px solid black; border-radius: 10px; padding: 5px;">~ # esxcfg-advcfg -s 1 /DataMover/HardwareAcceleratedInit Value of HardwareAcceleratedInit is 1 ~ # esxcfg-advcfg -s 1 /DataMover/HardwareAcceleratedMove Value of HardwareAcceleratedMove is 1</pre>
vSphere Client	<ol style="list-style-type: none"> 1. Using the vSphere client, log in to the vCenter server. 2. For each ESXi server, click the server name. 3. In the Software section of the Configuration tab, click Advanced Settings. 4. Select DataMover, and ensure that the DataMover.HardwareAcceleratedMove and DataMover.HardwareAcceleratedInit parameters are set to 1.

3. Download the IBM N series NFS Plug-in for VMware VAAI from the www.ibm.com/storage/support/nseries/.
4. Install the plug-in on the ESXi host by using one of the following three methods:

To...	Then...
<p>Install the offline bundle using the ESXi CLI</p>	<ol style="list-style-type: none"> Copy the offline bundle to the ESXi host, or to a common datastore accessible by all ESXi hosts. Enter the following command to list the contents of the offline bundle and verify the plug-in version: <pre>~ # esxcli software sources vib list -d file:///path_offline_bundle.zip</pre> <p>In the following output examples, the version and release date of the plug-in are for illustration purposes. The most recent version and release date of the plug-in might be different from what is shown. <i>path_offline_bundle</i> is the file name and full path of the offline bundle, and <i>plugin_name</i> is the name of the NFS plug-in.</p> <p>The following output is displayed when you enter this command:</p> <pre>~ # esxcli software sources vib list -d file:///IBMNasPlugin.v19.zip Name Version Vendor Rel Date Acceptance Level ----- IBM NasPlugin 1.0-019 IBM 2012-04-29 VMware Accepted</pre> Enter the following command to install the plug-in from the offline bundle: <pre>esxcli software vib install -n plugin_name -d file:///path_offline_bundle.zip</pre> <p>The following output is displayed when you enter this command:</p> <pre>~ # esxcli software vib install -n IBM NasPlugin -d file:///IBMNasPlugin.v19.zip Message: The update completed successfully, but the system needs to be rebooted for the changes to be effective. Reboot Required: true VIBs Installed: IBM_bootbank_IBM NasPlugin_1.0-019 VIBs Removed: VIBs Skipped: ~ #</pre>

To...	Then...
Use VSC to install the plug-in	<ol style="list-style-type: none"> 1. Extract the offline bundle in .zip format. 2. Copy the plug-in .vib file, IBMNasPlugin.vib, to the VSC installation directory. The path name is <i>VSC_installation_directory</i>\etc\vsc\web, where <i>VSC_installation_directory</i> is the directory where you installed VSC. The default directory path is C:\Program Files\IBM\Virtual Storage Console\. For example, if you are using the default installation directory, the path to the IBMNasPlugin.vib file is C:\Program Files\Virtual Storage Console\etc\vsc\web\IBMNasPlugin.vib. However, VSC lets you change that directory. 3. Check that the file name of the .vib file that you downloaded matches the predefined name that VSC uses, IBMNasPlugin.vib. If the file name does not match the predefined name, rename the .vib file. You do not need to restart the VSC client or the IBM vSphere Plug-in Framework (NVPF) service. 4. Go to the NFS Plug-in for VMware VAAI section of the Tools panel of Monitoring and Host Configuration, and click Install to Host. 5. In the pop-up box, specify the ESXi hosts on which you want to install the plug-in. 6. Click OK. Monitoring and Host Configuration automatically installs the plug-in on the hosts that you specified.

5. Reboot the ESXi host to complete the installation. However, the storage system does not need to be rebooted.
6. Verify that the plug-in was successfully installed on the host by entering the following command at the VMware ESXi command line:
~ # esxcli software vib list |more

The plug-in works automatically following the installation and reboot. The following output is displayed when you enter this command:

```

Name           Version  Vendor  Acceptance Level  Install Date
-----
IBMNASPlugin   1.0-019  IBM     VMwareAccepted    2012-04-29
~ # esxcli software vib get|more

IBM_bootbank_IBMNASPlugin_1.0-019
Name: IBMNASPlugin
Version: 1.0-019
Type: bootbank
Vendor: IBM
Acceptance Level: VMwareAccepted
Summary: NAS VAAI IBM Plugin
Description: IBM N series NAS VAAI Module for ESX Server
Release Date: 2012-04-29
Depends:
Conflicts:
Replaces:
Provides:
Maintenance Mode Required: False
Hardware Platforms Required:
Live Install Allowed: False
Live Remove Allowed: False
Overlay: False
Payloads: IBMNASPlugin
~ #

```

7. If you are using clustered Data ONTAP, either create or modify export policy rules for ESXi servers that use VAAI. Skip this step if you are using Data ONTAP operating in 7-Mode.

You can use export policies to restrict access to volumes to specific clients. NFSv4 is required in the export policy for VAAI copy offloading to work, so you might need to modify the export policy rules for datastore volumes on SVMs. If you are using protocols other than NFS on a datastore, verify that setting NFS in the export rule does not remove those other protocols.

If you use...	Then...
Clustered Data ONTAP CLI	<p>Enter the following command to set nfs as the access protocol for each export policy rule for ESXi servers that use VAAI:</p> <pre>vserver export-policy -rule modify -vserver vserver_name -policyname policy -ruleindex index -protocol nfs</pre> <p>In the following example:</p> <ul style="list-style-type: none"> • vs1 is the name of the SVM . • mypolicy is the name of the export policy. • 1 is the index number of the rule. • nfs includes the NFSv3 and NFSv4 protocols. <pre>cluster1::> vserver export-policy rule modify -vserver vs1 -policyname mypolicy -ruleindex 1 -protocol nfs</pre>

If you use...	Then...
OnCommand System Manager	<ol style="list-style-type: none"> 1. From the Home tab, double-click the appropriate cluster. 2. Expand the Storage Virtual Machines (SVMs) hierarchy in the left navigation pane. 3. In the navigation pane, select the Storage Virtual Machine (SVM) with VAAI-enabled datastores, and then click Policies > Export Policies. 4. In the Export Policies window, expand the export policy, and then select the rule index. The user interface does not specify that the datastore is VAAI enabled. 5. Click Modify Rule to display the Modify Export Rule dialog box. 6. Under Access Protocols, select NFS to enable all versions of NFS. 7. Click OK.

If you are starting with a new system, you need to create export policies and rules for the root volume and for each NFS datastore volume. For more information about creating export policy rules, see the *Clustered Data ONTAP File Access and Protocols Management Guide* and Technical Report 4068: VMware vSphere 5 on Clustered Data ONTAP 8.1.

Note: This technical report contains information about NetApp products that IBM licenses and in some cases customizes. Technical reports might contain information about models and features that are not supported by IBM.

8. If you are using Data ONTAP operating in 7-Mode, use the **exportfs** command for exporting volume paths. Skip this step if you are using clustered Data ONTAP.

For more information about the **exportfs** command, see the *Data ONTAP File Access and Protocols Management Guide for 7-Mode* or the man pages. When exporting the volume, you can specify a host by name or IP address, a subnet, or a netgroup. You need to specify IP address, subnet, or hosts for both the **rw** and **root** options. For example:

```
sys1> exportfs -p root=192.168.42.227 /vol/VAAI
```

You also can have a list separated by colons. For example:

```
sys1> exportfs -p root=192.168.42.227:192.168.42.228 /vol/VAAI
```

If you export the volume with the **actual** flag, the export path should have a single component for copy offload to work properly. For example:

```
sys1> exportfs -p actual=/vol/VAAI,root=192.168.42.227 /VAAI-ALIAS
```

Note: Copy offload does not work for multi-component export paths.

9. If you have not already done so, mount the NFS datastore on the ESXi host by performing the following steps:

- a. Enter the following command:

```
~ # esxcfg-nas -a mount_point_name -o 192.168.42.80 -s /volume_path
```

The following example shows the command to be run on clustered Data ONTAP for mounting the datastore and the resulting output:

```

~ # esxcfg-nas -a onc_src -o 192.168.42.80 -s /onc_src
Connecting to NAS volume: onc_src
/onc_src created and connected.

```

For 7-Mode systems, the /vol prefix precedes the NFS volume name. The following example shows the 7-Mode command for mounting the datastore and the resulting output:

```

~ # esxcfg-nas -a vms_7m -o 192.168.42.69 -s /vol/vms_7m
Connecting to NAS volume: /vol/vms_7m
/vol/vms_7m created and connected.

```

b. Enter the following command:

```
~ # esxcfg-nas -l
```

The following output is displayed:

```

VMS_vol103 is /VMS_vol103 from 192.168.42.81 mounted available
VMS_vol104 is VMS_vol104 from 192.168.42.82 mounted available
dbench1 is /dbench1 from 192.168.42.83 mounted available
dbench2 is /dbench2 from 192.168.42.84 mounted available
onc_src is /onc_src from 192.168.42.80 mounted available

```

Upon completion, the volume is mounted and available in the /vmfs/volumes directory.

10. Verify that the mounted datastore supports VAAI by using one of the following methods:

If you use...	Then...
ESXi CLI	Enter the following command: <pre>~ # vmkfstools -Ph /vmfs/volumes/onc_src/</pre> The following output is displayed: <pre> NFS-1.00 file system spanning 1 partitions. File system label (if any): onc_src Mode: public Capacity 760 MB, 36.0 MB available, file block size 4 KB UUID: fb9cccc8-320a99a6-0000-000000000000 Partitions spanned (on "notDCS"): nfs:onc_src NAS VAAI Supported: YES Is Native Snapshot Capable: YES ~ # </pre>
vSphere client	<ol style="list-style-type: none"> 1. Click ESXi Server > Configuration > Storage. 2. Look in the Hardware Acceleration column for an NFS datastore with VAAI enabled.

For more information about VMware vStorage over NFS, see the *Data ONTAP File Access and Protocols Management Guide for 7-Mode*. For details about configuring disks, aggregates, volumes, and space in the volumes, see the *Data ONTAP Storage Management Guide for 7-Mode*. For information about using VSC to provision NFS datastores and create clones of virtual machines in the VMware environment, see the *Virtual Storage Console for VMware vSphere Installation and Administration Guide*.

For more information about working with NFS datastores and performing cloning operations, see the VMware vSphere Storage guide and Technical Report 4068: VMware vSphere 5 on Clustered Data ONTAP 8.1.

Note: This technical report contains information about NetApp products that IBM licenses and in some cases customizes. Technical reports might contain information about models and features that are not supported by IBM.

11. If you are using Data ONTAP operating in 7-Mode, use the **sis on** command to enable the datastore volume for copy offloading and deduplication. Enabling SIS allows the copy offload operation to perform a fast and space-efficient copy. When you create a volume with VSC, by default it enables SIS on datastore volumes.

What to do next

Use the NFS plug-in space reservation and copy offload features to make routine tasks more efficient:

- Create virtual machines in the thick virtual machine disk (VMDK) format on traditional or FlexVol volumes and reserve space for the file at the time you create it.
- Clone existing virtual machines within or across IBM N series volumes. Datastores are volumes on the same 7-Mode system or vFiler unit.
- Perform cloning operations that finish faster than non-VAAI clone operations because they do not need to go through the ESXi host.

NA 210-06303_A0

© Copyright IBM Corporation 2013.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

SC27-4236-01

