

IBM Z and LinuxONE

Capacity on Demand User's Guide



Note:

Before you use this information and the product it supports, read the information in “Safety” on page vii, Appendix D, “Notices,” on page 119, and *IBM Systems Environmental Notices and User Guide*, Z125-5823.

This edition, SC28-7025-00, applies to IBM Z servers, beginning with the IBM z15, and IBM LinuxONE servers, beginning with the IBM LinuxONE III.

There might be a newer version of this document in a PDF file available on Resource Link. Go to <http://www.ibm.com/servers/resourcelink> and click Library on the navigation bar.

© **Copyright International Business Machines Corporation 2022.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Safety.....	vii
Safety notices.....	vii
World trade safety information.....	vii
Laser safety information.....	vii
Laser compliance.....	vii
About this publication.....	ix
Organization of this publication.....	ix
Related publications.....	x
Related HMC and SE console information.....	x
Who should read this publication.....	x
Accessibility.....	x
Accessibility features.....	x
Keyboard navigation.....	xi
Consult assistive technologies.....	xi
IBM and accessibility.....	xi
How to send your comments.....	xi
Chapter 1. Introduction.....	1
Capacity on Demand offerings.....	1
Permanent upgrades.....	1
Temporary upgrades.....	1
The process.....	2
Chapter 2. Planning.....	3
Permanent upgrades.....	3
Considerations for ordering and installing consecutive permanent LICCC upgrades.....	4
Considerations while temporary upgrades are active.....	5
Software considerations.....	10
Temporary upgrades.....	11
On/Off CoD.....	11
On/Off CoD test.....	14
Administrative On/Off CoD test.....	14
CBU.....	14
CPE.....	16
System Recovery Boost Upgrade.....	17
Subcapacity CP activation.....	17
Chapter 3. Enabling your machine to order upgrades.....	21
Capacity on Demand enablement feature codes.....	21
Agreements required for enablement.....	21
Existing agreements that carry forward to IBM Z and IBM LinuxONE.....	21
Agreements and supplements for IBM Z and IBM LinuxONE Capacity on Demand functions and features.....	22
How to enable your machine for On-Line CoD ordering.....	23
CIU machine profiles on Resource Link.....	24
Managing user access to machine profiles.....	26
Chapter 4. Ordering.....	29
Permanent upgrade considerations.....	29

Temporary upgrade considerations.....	31
On/Off CoD considerations.....	31
On/Off CoD test considerations.....	33
Administrative On/Off CoD test considerations.....	33
CBU considerations.....	33
CPE considerations.....	34
System Recovery Boost Upgrade considerations.....	35
How to order an upgrade record.....	35
Ordering a permanent upgrade.....	35
Ordering an On/Off CoD record.....	37
Ordering an On/Off CoD test record.....	39
Ordering an On/Off CoD record with prepaid upgrades.....	40
Ordering an On/Off CoD record with spending limits.....	44
Ordering an administrative On/Off CoD test record.....	48
Ordering a CBU record.....	49
Ordering a CPE record.....	51
Ordering a System Recovery Boost Upgrade record.....	53
How to order a replenishment record.....	54
How to cancel an upgrade record.....	57
Chapter 5. Retrieving and installing.....	59
Permanent upgrades.....	59
Temporary upgrades.....	63
Chapter 6. Activating temporary upgrade records.....	67
Activation rules.....	67
Methods of activation.....	67
Manually activating using the Support Element.....	67
Setting up scheduled operation to activate an upgrade record.....	74
Using SNMP and HMC Web Services APIs to activate an upgrade record.....	75
Using z/OS Capacity Provisioning.....	75
Chapter 7. Deactivating temporary capacity.....	77
Considerations before deactivating.....	77
How to deactivate.....	77
Chapter 8. Deleting temporary Capacity on Demand records.....	83
Chapter 9. Billing.....	87
Permanent upgrades.....	87
Temporary upgrades.....	87
Chapter 10. Monitoring.....	89
STSI instruction.....	89
SNMP APIs.....	89
History of activity on the system.....	89
Chapter 11. Discontinuing and removing Capacity on Demand features.....	93
Upgrading your machine.....	93
Selling your machine to another company.....	94
Returning your leased machine to IBM.....	94
IBM withdrawing the machine from marketing.....	94
Removing the Capacity on Demand features.....	94
Disabling a machine profile.....	95
Appendix A. Status and Messages	97

Order status definitions.....	97
Messages	98
Message format.....	98
Appendix B. Exporting your profile data.....	115
Appendix C. Understanding the content of the Installed Records page in the Temporary Upgrades window.....	117
Appendix D. Notices.....	119
Trademarks.....	119
Class A Notices.....	120
Index.....	125

Safety

Safety notices

Safety notices may be printed throughout this guide. **DANGER** notices warn you of conditions or procedures that can result in death or severe personal injury. **CAUTION** notices warn you of conditions or procedures that can cause personal injury that is neither lethal nor extremely hazardous. **Attention** notices warn you of conditions or procedures that can cause damage to machines, equipment, or programs.

World trade safety information

Several countries require the safety information contained in product publications to be presented in their translation. If this requirement applies to your country, a safety information booklet is included in the publications package shipped with the product. The booklet contains the translated safety information with references to the US English source. Before using a US English publication to install, operate, or service this product, you must first become familiar with the related safety information in the *Systems Safety Notices*, G229-9054. You should also refer to the booklet any time you do not clearly understand any safety information in the US English publications.

Laser safety information

All IBM Z® models can use I/O cards such as FICON®, Open Systems Adapter (OSA), RoCE Express, Integrated Coupling Adapter (ICA SR, ICA SR1.1), zHyperLink Express, or other I/O features which are fiber optic based and utilize lasers (short wavelength or long wavelength lasers).

Laser compliance

All lasers are certified in the US to conform to the requirements of DHHS 21 CFR Subchapter J for Class 1 or Class 1M laser products. Outside the US, they are certified to be in compliance with IEC 60825 as a Class 1 or Class 1M laser product. Consult the label on each part for laser certification numbers and approval information.

Laser Notice: U.S. FDA CDRH NOTICE if low power lasers are utilized, integrated, or offered with end product systems as applicable. Complies with 21 CFR 1040.10 and 1040.11 except for conformance with IEC 60825-1 Ed. 3., as described in Laser Notice No. 56, dated May 8, 2019.

CAUTION: Data processing environments can contain equipment transmitting on system links with laser modules that operate at greater than Class 1 power levels. For this reason, never look into the end of an optical fiber cable or open receptacle. (C027)

CAUTION: This product contains a Class 1M laser. Do not view directly with optical instruments. (C028)

About this publication

This publication provides information that can be used to enable, order, and activate upgrades through the family of flexible Capacity on Demand offerings for IBM Z, beginning with the IBM z15™, and IBM LinuxONE, beginning with the IBM LinuxONE III Capacity on Demand offerings include:

- Permanent Upgrade
- On/Off Capacity on Demand (On/Off CoD)
- Capacity Backup (CBU)
- Capacity for Planned Events (CPE)
- System Recovery Boost Upgrade

Specialty engine upgrades are among the upgrades supported by Capacity on Demand offerings. For IBM Z, specialty engines include:

- Integrated Coupling Facility (ICF)
- Integrated Facility for Linux® (IFL)
- z Integrated Information Processor (zIIP)
- System Assist Processor (SAP)

For LinuxONE, specialty engines include:

- Integrated Facility for Linux (IFL)
- System Assist Processor (SAP)

Note: Screen captures that appear in this publication may not be at the latest level. They are provided to represent the task for reference and navigation purposes only.

Organization of this publication

This document contains the following information:

- [Chapter 1, “Introduction,” on page 1](#) provides the information to help you select the solution that best fits the needs for your enterprise and information on managing system capacity.
- [Chapter 2, “Planning,” on page 3](#) provides information on what to consider when you are planning for temporary and permanent upgrades.
- [Chapter 3, “Enabling your machine to order upgrades,” on page 21](#) provides information on the agreements you need signed and the IDs you need to have in place before you order your temporary and permanent upgrades.
- [Chapter 4, “Ordering,” on page 29](#) provides information and steps describing how to order your temporary and permanent records using Resource Link®.
- [Chapter 5, “Retrieving and installing,” on page 59](#) provides information and steps describing how to retrieve and install your temporary and permanent records using the Support Element.
- [Chapter 6, “Activating temporary upgrade records,” on page 67](#) provides information and steps describing how to activate your temporary records using the Support Element.
- [Chapter 7, “Deactivating temporary capacity,” on page 77](#) provides information and steps describing how to deactivate processors or temporary model capacity using the Support Element.
- [Chapter 8, “Deleting temporary Capacity on Demand records,” on page 83](#) provides information on how to delete temporary records using the Support Element.
- [Chapter 9, “Billing,” on page 87](#) describes how you are charged based on the upgrade that you ordered.

- [Chapter 10, “Monitoring,” on page 89](#) provides information about the different functions available for you to use to monitor your Capacity on Demand activity.
- [Chapter 11, “Discontinuing and removing Capacity on Demand features,” on page 93](#) describes the steps you must complete if you need to discontinue the use of and remove one or more of the Capacity on Demand (CoD) features on a machine.
- [Appendix A, “Status and Messages,” on page 97](#) provides order status and product messages pertaining to problems you may be experiencing.
- [Appendix B, “Exporting your profile data,” on page 115](#) describes how to save your profile data.
- [Appendix C, “Understanding the content of the Installed Records page in the Temporary Upgrades window,” on page 117](#) describes the fields displayed on the **Installed Records** page in the **Temporary Upgrades** window.
- [Appendix D, “Notices,” on page 119](#) contains IBM trademarks and other special notices.

Related publications

Along with this publication, the following publications provide information about the functions and characteristics of the Capacity on Demand products and applications.

- *Processor Resource/System Manager (PR/SM) Planning Guide*, SB10-7178
- *SNMP Application Programming Interfaces*, SB10-7179
- *Hardware Management Console Web Services API*, SC27-2642

Related HMC and SE console information

Hardware Management Console (HMC) and Support Element (SE) information can be found on the console help system.

Who should read this publication

This document is intended for customers and enterprise decision makers to understand the On Demand concepts and process for implementing permanent and temporary upgrades using Capacity on Demand offerings. It can also be used by IBM® or Business Partner service representatives who install and maintain system capacity.

Accessibility

Accessible publications for this product are offered in EPUB format and can be downloaded from Resource Link at <http://www.ibm.com/servers/resourcelink>.

If you experience any difficulty with the accessibility of any IBM Z information, go to Resource Link at <http://www.ibm.com/servers/resourcelink> and click **Feedback** from the navigation bar on the left. In the **Comments** input area, state your question or comment, the publication title and number, choose **General comment** as the category and click **Submit**. You can also send an email to reslink@us.ibm.com providing the same information.

When you send information to IBM, you grant IBM a nonexclusive right to use or distribute the information in any way it believes appropriate without incurring any obligation to you.

Accessibility features

The following list includes the major accessibility features in IBM Z documentation, and on the Hardware Management Console and Support Element console:

- Keyboard-only operation
- Interfaces that are commonly used by screen readers
- Customizable display attributes such as color, contrast, and font size

- Communication of information independent of color
- Interfaces commonly used by screen magnifiers
- Interfaces that are free of flashing lights that could induce seizures due to photo-sensitivity.

Keyboard navigation

This product uses standard Microsoft Windows navigation keys.

Consult assistive technologies

Assistive technology products such as screen readers function with our publications, the Hardware Management Console, and the Support Element console. Consult the product information for the specific assistive technology product that is used to access the EPUB format publication or console.

IBM and accessibility

See <http://www.ibm.com/able> for more information about the commitment that IBM has to accessibility.

How to send your comments

Your feedback is important in helping to provide the most accurate and high-quality information. Send your comments by using Resource Link at <http://www.ibm.com/servers/resourcelink>. Click **Feedback** on the navigation bar on the left. You can also send an email to reslink@us.ibm.com. Be sure to include the name of the book, the form number of the book, the version of the book, if applicable, and the specific location of the text you are commenting on (for example, a page number, table number, or a heading).

Chapter 1. Introduction

Businesses must handle unpredictable market opportunities, customer needs, and external pressure without missing a beat or interrupting existing processes. This means your IT infrastructure must support changing business objectives. You should have access to the resources you need, when you need them.

This is the basic principle underlying the Capacity on Demand offerings for IBM Z and LinuxONE. The Capacity on Demand offerings allow you to get the resources you need, when you need them.

Capacity on Demand offerings

The Capacity on Demand offerings provide permanent and temporary upgrades by activating one or more LICCC records. These upgrades occur without disruption to the operation of the server.

Depending on the type of upgrade, you can order upgrades yourself using the Customer Initiated Upgrade (CIU) application on Resource Link or you can call your IBM sales representative to order the upgrades.

Permanent upgrades

You can order permanent upgrades using the CIU application on Resource Link or through your IBM sales representative to:

- Add model capacity
- Add specialty engines
- Add memory
- Activate unassigned model capacity or supported specialty engines
- Deactivate activated model capacity or supported specialty engines.

You can order permanent upgrades through your IBM Sales representative also to:

- Activate channels
- Activate cryptos
- Change specialty engines (recharacterization).

Temporary upgrades

Temporary upgrades are provided through the following offerings:

- **On/Off Capacity on Demand (On/Off CoD)** - This offering allows you to temporarily add model capacity or specialty engines due to seasonal activities, period-end requirements, peaks in workload, or application testing.
- **Capacity Backup (CBU)** - This offering allows you to replace model capacity or specialty engines to a backup server in the event of an unforeseen loss of server capacity because of an emergency.
- **Capacity for Planned Events (CPE)** - This offering, for IBM z15 servers, allows you to replace model capacity or specialty engines due to a relocation of workload during system migrations or a data center move.
- **System Recovery Boost Upgrade** - This offering for IBM Z servers allows you to make additional zIIPs temporarily available for a system recovery zIIP boost after planned or unplanned outages.
- **IBM Z Flexible Capacity for Cyber Resiliency** - This offering for IBM Z servers beginning with the IBM z16™ allows you to shift production capacity between participating IBM z16 servers at different sites.
- **Tailored Fit Pricing for IBM Z HW (TFP HW)** - A specialized pricing offering for On/Off CoD that supports charges based on the actual capacity usage rather than the capacity active.

You can order CBU, CPE, or System Recovery Boost Upgrade records, or related entitlements such as CBU tests, using the CIU application through Resource Link or calling your IBM sales representative.

You can order On/Off CoD records only by using the CIU application through Resource Link.

The process

Implementing the best Capacity on Demand solution to satisfy your requirements involves six steps:

1. Planning to determine your capacity needs
2. Enabling your machines to be ready for any upgrade
3. Ordering your upgrade records to have a solution readily available to use
4. Retrieving the required upgrade records
5. Installing the required upgrade records
6. Activating the specific upgrade processors.

[Chapter 2, “Planning,” on page 3](#) through [Chapter 6, “Activating temporary upgrade records,” on page 67](#) provide details on each of these steps.

In addition, [Chapter 7, “Deactivating temporary capacity,” on page 77](#) and [Chapter 8, “Deleting temporary Capacity on Demand records,” on page 83](#) provide information on deactivating capacity upgrades and deleting temporary records.

Note: This document will focus on using the CIU application through Resource Link to order permanent and temporary upgrades and the Support Element function through the HMC to retrieve, install, activate, and deactivate permanent and temporary upgrades.

Chapter 2. Planning

Before it is time for you to actually order and activate permanent upgrades or temporary upgrades, you should do some planning. This section describes why you would use each of the Capacity on Demand offerings, the general structure of each offering, and items you should consider before enabling each offering.

Permanent upgrades

Consider the following before implementing any permanent capacity and memory upgrades:

- Ensure that you enable your system well in advance of needing to place an order. (The enablement process is described in [Chapter 3, “Enabling your machine to order upgrades,”](#) on page 21.)
- Determine what configurations you might need based on workload projections. For permanent upgrades, workloads are usually long term and handle day to day productions.
- When ordering a permanent upgrade, you can order unassigned model capacity and supported specialty engines without changing the active configuration.
- You can order a permanent upgrade and have it ready for download when the need arises. A permanent upgrade record can be staged on the Support Element.

However, you cannot order another permanent upgrade until VPD is received that confirms the previous permanent upgrade is installed.

- Before installing consecutive permanent LICCC upgrades ordered from both the CIU application on Resource Link and your sales representative, carefully consider each upgrade's configuration and the effect they may have on each other upon installation. Refer to [“Considerations for ordering and installing consecutive permanent LICCC upgrades”](#) on page 4 for detailed information.
- Additional hardware cannot be installed using the CIU application through Resource Link, therefore, ensure that all additional capacity required is already installed.
- The sum of active and unassigned PUs is limited by the hardware or drawer capacity.
- The 2:1 zIIP to CP ratio for IBM Z processor configurations applies to permanent upgrade orders. The ratio may be a factor in limiting the number of zIIPs you can order.
- You can perform a permanent capacity upgrade when temporary records are activated on a server.

Refer to [“Considerations while temporary upgrades are active”](#) on page 5 for detailed information you need to consider before performing a permanent capacity upgrade while temporary upgrades are active.

- You can order permanent upgrades through your IBM Sales representative to change processor types. For example, you can convert an IFL to a zIIP or a zIIP to a CP. However, before you perform this conversion, look at your LPAR and processor pool definitions. If the engine being converted is the last engine of its type in the LPAR, you must configure the processor offline before applying the permanent upgrade.
- Additional logical processors can be concurrently configured online to logical partitions by the operating system when reserved processors are previously defined, resulting in image upgrades. The operating system must have the capability to concurrently configure more processors online.
- LinuxONE processing unit minimums and maximums apply to permanent upgrade orders and may be a factor in limiting the permanent upgrades you can order for a LinuxONE server:
 - A LinuxONE Emperor supports two model capacity configurations: 400 (no CPs) or 401 (one sub-capacity CP). Likewise, a LinuxONE Rockhopper supports two model capacity configurations: A00 (no CPs) or C01 (one sub-capacity CP). Active model capacity must always equal the purchased model capacity, so unassigning model capacity is not supported.
 - Unassigning IFLs is supported, but at least one IFL must be active.
 - ICF upgrades are not supported.

- zIIP upgrades are not supported.

Considerations for ordering and installing consecutive permanent LICCC upgrades

An upgrade that requires only reconfiguring a machine's Licensed Internal Code Configuration Control (LICCC) to define its new, upgraded hardware configuration is referred to as a **LICCC upgrade**. All temporary upgrades are LICCC upgrades and some types of permanent upgrades are LICCC upgrades. Permanent upgrades that add model capacity, specialty engines, or memory are LICCC upgrades. Permanent upgrades that deactivate or reactivate model capacity or specialty engines also are LICCC upgrades.

The installation of a permanent LICCC upgrade is considered complete only after IBM has received and processed the machine's updated Vital Product Data (VPD). After an upgrade is installed, the machine's updated VPD is automatically scheduled to be sent to IBM within 24 hours. Upon receiving the updated VPD, its processing includes making it available to the CIU application on Resource Link and to the ordering system used by sales representatives to ensure that subsequent orders for upgrades are based on the machine's newly upgraded hardware configuration.

You can order permanent LICCC upgrades using the CIU application on Resource Link, through your IBM or Business Partner sales representative, or from both if necessary. However, to install consecutive permanent LICCC upgrades ordered from both sources, you must install the upgrades in the same sequence you ordered them (if you install an upgrade out of sequence, it will invalidate prior upgrades you ordered earlier but did not install yet). You also need to carefully consider each upgrade's configuration and the effect they may have on each other upon installation.

For example, if two permanent LICCC upgrades are based on the same hardware configuration when ordered, installing either upgrade will, of course, change that hardware configuration. Now, the other upgrade may or may not be compatible with the machine's new hardware configuration. When you attempt to install the other upgrade, the installation may fail. Or if you were able to install the upgrade, it may negate or undo all or part of the previously installed upgrade. To reduce the possibility of these outcomes, consider the source of a machine's most recently installed permanent LICCC upgrade, either Resource Link or your sales representative, before installing a subsequent permanent LICCC upgrade ordered from the other source.

After the installation of permanent LICCC upgrades ordered from your sales representative:

- Cancel (or have your service representative cancel) the machine's staged permanent LICCC upgrade ordered from Resource Link, if any (a staged upgrade has been downloaded but not installed).
- Consider using (or having your service representative use) the **Transmit Vital Product Data** task on the machine's Support Element to send its updated VPD manually and immediately after installing the upgrades in order to expedite its receipt and processing by IBM.
- Upon receipt of the updated VPD, if the machine has a permanent LICCC upgrade that was ordered from Resource Link but has not been downloaded yet, the order will be canceled automatically.
- Wait until IBM has received and processed the machine's updated VPD before ordering a new permanent LICCC upgrade from Resource Link. If the CIU machine profile on Resource Link still shows the machine's prior hardware configuration, then IBM has not processed the machine's updated VPD yet. Otherwise, if the machine's newly upgraded hardware configuration is shown, then its updated VPD has been processed.

Secondly, and perhaps more importantly, after the installation of a permanent LICCC upgrade ordered from Resource Link:

- Make your service representative aware of the installation of the upgrade from Resource Link before having them install permanent LICCC upgrades ordered from your sales representative.
- Have the service representative check when the upgrades were ordered. If they were ordered before the installation of the upgrade ordered from Resource Link was completed, then they are based on the machine's prior hardware configuration rather than its new configuration. In this case, your sales

representative can advise you and your service representative whether the upgrades ordered from your sales representative must be canceled, can be adjusted, or can be installed as is.

Considerations while temporary upgrades are active

Capacity on Demand offerings support performing permanent upgrades while temporary upgrades are active. However, there are certain situations where it is necessary to deactivate or change the activation level of the temporary upgrades before activating the permanent upgrade to prevent any conflicts. Many of these situations apply only to systems that activate subcapacity CP engines. A precheck function is available on the Support Element to prevent a permanent upgrade if such conflicts exist. Refer to step “4” on page 61 for details.

On/Off CoD

With On/Off CoD upgrades, in most cases, there will not be problems because applying permanent upgrades will convert On/Off CoD engines of the same type to permanent engines.

For example, suppose you are running an IBM z16 at model capacity 735 with 4 temporary CP engines active. (See Figure 1 on page 5.) Then you apply a 2 CP permanent upgrade. The upgrade process will convert 2 of the temporary CP engines to permanent engines and leave 2 temporary CP engines active. (See Figure 2 on page 6.)

Note: In the tables that follow, each box represents a model capacity by its software model and approximate MSU value. The permanent model capacity is shown in bold text with a thick solid border. Temporary model capacity is shown with a thick dashed border. The permanent upgrade is represented by an arrow from original model capacity to the new model capacity. Invalid configuration changes are shown by an X.

<u>729</u> 5243	<u>730</u> 5396	<u>731</u> 5549	<u>732</u> 5702	<u>733</u> 5855	<u>734</u> 6008	735 6160	<u>736</u> 6313	<u>737</u> 6465	<u>738</u> 6617	<u>739</u> 6768
<u>629</u> 3553	<u>630</u> 3655	<u>631</u> 3760	<u>632</u> 3864	<u>633</u> 3968	<u>634</u> 4073	<u>635</u> 4177	<u>636</u> 4281	<u>637</u> 4385	<u>638</u> 4489	<u>639</u> 4593
<u>529</u> 2306	<u>530</u> 2374	<u>531</u> 2441	<u>532</u> 2507	<u>533</u> 2573	<u>534</u> 2638	<u>535</u> 2702	<u>536</u> 2765	<u>537</u> 2828	<u>538</u> 2890	<u>539</u> 2950
<u>429</u> 720	<u>430</u> 742	<u>431</u> 763	<u>432</u> 785	<u>433</u> 806	<u>434</u> 828	<u>435</u> 850	<u>436</u> 871	<u>437</u> 892	<u>438</u> 912	<u>439</u> 933

Figure 1. On/Off CoD configuration before permanent upgrade - successful upgrade

<u>729</u> 5243	<u>730</u> 5396	<u>731</u> 5549	<u>732</u> 5702	<u>733</u> 5855	<u>734</u> 6008	<u>735</u> 6160	<u>736</u> 6313	<u>737</u> 6465	<u>738</u> 6617	<u>739</u> 6768
<u>629</u> 3553	<u>630</u> 3655	<u>631</u> 3760	<u>632</u> 3864	<u>633</u> 3968	<u>634</u> 4073	<u>635</u> 4177	<u>636</u> 4281	<u>637</u> 4385	<u>638</u> 4489	<u>639</u> 4593
<u>529</u> 2306	<u>530</u> 2374	<u>531</u> 2441	<u>532</u> 2507	<u>533</u> 2573	<u>534</u> 2638	<u>535</u> 2702	<u>536</u> 2765	<u>537</u> 2828	<u>538</u> 2890	<u>539</u> 2950
<u>429</u> 720	<u>430</u> 742	<u>431</u> 763	<u>432</u> 785	<u>433</u> 806	<u>434</u> 828	<u>435</u> 850	<u>436</u> 871	<u>437</u> 892	<u>438</u> 912	<u>439</u> 933

Figure 2. On/Off CoD configuration after permanent upgrade - successful upgrade

Scenario 1: Are there sufficient number of engines on the system?

This scenario describes when there is an insufficient number of engines of the same type available on the system to apply a permanent upgrade with On/Off CoD active.

Suppose you are running an IBM z16 Max39 (ie. 39 available PUs) at model capacity 735 with 4 temporary CP engines active. (See Figure 1 on page 5.) Then you try to apply a 2 IFL upgrade. Because all engines on the system are active and the temporary engines are a different engine type, you will not be able to apply the upgrade without first deactivating 2 of the temporary CP engines.

Scenario 2: Will the permanent upgrade result in a higher subcapacity level than the On/Off CoD upgrade subcapacity level?

This scenario describes when On/Off CoD is active at a subcapacity level and you try to apply a permanent upgrade resulting in a higher subcapacity level. This scenario will not prevent you from completing your permanent upgrade, however, the resulting configuration may be different than expected.

On/Off CoD upgrades cannot activate capacity below the permanent subcapacity level. If the permanent capacity level is 6xx, then On/Off CoD upgrades can only be applied that add additional engines at the 6xx level, or that move to the 7xx level. On/Off CoD upgrades cannot change the subcapacity level to a 5xx or 4xx. When a permanent upgrade is applied when an On/Off CoD upgrade is active, if the subcapacity level of the permanent upgrade is greater than the capacity level of the current On/Off CoD upgrade, then the On/Off CoD upgrade's capacity level is increased to the permanent upgrade's subcapacity level.

Suppose you are running an IBM z16 at model capacity 631 with 4 temporary CP engines active. (See Figure 3 on page 7). Then you apply a permanent CP upgrade to a 732. Because the On/Off CoD record would now be at a lower capacity level than the permanent upgrade, the temporary subcapacity level is increased to a 735, a 47% increase in capacity, and 1 temporary CP engine is converted to a permanent engine. (See Figure 4 on page 7.)

If this increase in capacity and, therefore, the potential extra charges resulting from the higher capacity was not intended, you should either deactivate your On/Off CoD capacity or change to the desired subcapacity level before applying the permanent upgrade. In this instance, if the 732 level were still not enough capacity, then a change to the 733 level would be the next closest level.

<u>729</u> 5243	<u>730</u> 5396	<u>731</u> 5549	<u>732</u> 5702	<u>733</u> 5855	<u>734</u> 6008	<u>735</u> 6160	<u>736</u> 6313	<u>737</u> 6465	<u>738</u> 6617	<u>739</u> 6768
<u>629</u> 3553	<u>630</u> 3655	631 3760	632 3864	633 3968	634 4073	635 4177	636 4281	637 4385	638 4489	639 4593
<u>529</u> 2306	<u>530</u> 2374	<u>531</u> 2441	<u>532</u> 2507	<u>533</u> 2573	<u>534</u> 2638	<u>535</u> 2702	<u>536</u> 2765	<u>537</u> 2828	<u>538</u> 2890	<u>539</u> 2950
<u>429</u> 720	<u>430</u> 742	<u>431</u> 763	<u>432</u> 785	<u>433</u> 806	<u>434</u> 828	<u>435</u> 850	<u>436</u> 871	<u>437</u> 892	<u>438</u> 912	<u>439</u> 933

Figure 3. On/Off CoD configuration before permanent upgrade - subcapacity level

<u>729</u> 5243	<u>730</u> 5396	<u>731</u> 5549	732 5702	733 5855	734 6008	735 6160	736 6313	737 6465	738 6617	739 6768
<u>629</u> 3553	<u>630</u> 3655	631 3760	632 3864	633 3968	634 4073	635 4177	636 4281	637 4385	638 4489	639 4593
<u>529</u> 2306	<u>530</u> 2374	<u>531</u> 2441	<u>532</u> 2507	<u>533</u> 2573	<u>534</u> 2638	<u>535</u> 2702	<u>536</u> 2765	<u>537</u> 2828	<u>538</u> 2890	<u>539</u> 2950
<u>429</u> 720	<u>430</u> 742	<u>431</u> 763	<u>432</u> 785	<u>433</u> 806	<u>434</u> 828	<u>435</u> 850	<u>436</u> 871	<u>437</u> 892	<u>438</u> 912	<u>439</u> 933

Figure 4. On/Off CoD configuration after permanent upgrade - subcapacity level

Scenario 3: Are you trying to upgrade engines and downgrade engines when applying a permanent upgrade?

This scenario describes when On/Off CoD is active and the permanent record you try to apply is a mixture of upgrading engines and downgrading engines.

When a permanent upgrade increases the capacity level or number of engines of one type, and decreases the capacity level or number of engines of another type, On/Off CoD temporary engines are not converted from temporary to permanent. Instead the total number of temporary engines active will remain the same.

Suppose you are running at capacity level 708, (permanent capacity level of 705 plus 3 temporary CP engines) and 1 zIIP. Then you apply a permanent upgrade to add 3 CPs and 1 IFL, and remove 1 zIIP. The permanent upgrade results in running at capacity level 711 (permanent capacity level of 708 plus 3 temporary CP engines) and 1 IFL. The 3 temporary CP engines are not converted to permanent resources because the permanent upgrade contained a mixture of upgrading and downgrading resources.

Flexible Capacity

Considerations and scenarios for installing a permanent upgrade while a temporary Flexible Capacity upgrade is active are the same as On/Off CoD upgrades. The permanent upgrade converts temporary resources of the same type if possible.

Replacement capacity offerings

With replacement capacity offerings, such as CBU and CPE, you need to be cautious when you try to apply a permanent upgrade primarily because with these offerings, active temporary capacity is not replaced by permanent capacity. Replacement capacity offerings add engines and capacity levels to the permanent engine and capacity levels. Therefore, when a permanent upgrade changes the engine counts or capacity levels, there is a corresponding change in the active temporary records. Replacement capacity that was activated before a permanent upgrade will be active on top of the new permanent configuration.

There are four basic scenarios to consider when planning for a permanent upgrade with a replacement capacity offering active. These scenarios include:

- Are there sufficient PUs on the system to allow for the permanent upgrade?
- Will the resultant configuration (permanent plus any active temporary records) after applying the permanent upgrade be a valid configuration?
- If you are on a subcapacity system and have replacement capacity records active, will the permanent upgrade result in an engine configuration that goes into the second drawer on a multi-drawer system?
- Do you have sufficient CBU features to continue activation at the new processor level?

Scenario 1: Are there sufficient PUs available on the system?

Because replacement capacity engines are not converted into permanent engines when a permanent upgrade is applied, you must ensure that there are sufficient engines available to activate the permanent upgrade.

Suppose you are running an IBM z16 Max39 (ie. 39 available PUs) at model capacity 735 with CBU engines active to a 739 level. (See [Figure 5 on page 8.](#)) With this scenario, you cannot perform any permanent engine upgrades, regardless of engine type, until the appropriate number of CBU engines have been deactivated.

$\frac{729}{5243}$	$\frac{730}{5396}$	$\frac{731}{5549}$	$\frac{732}{5702}$	$\frac{733}{5855}$	$\frac{734}{6008}$	$\frac{735}{6160}$	$\frac{736}{6313}$	$\frac{737}{6465}$	$\frac{738}{6617}$	$\frac{739}{6768}$
$\frac{629}{3553}$	$\frac{630}{3655}$	$\frac{631}{3760}$	$\frac{632}{3864}$	$\frac{633}{3968}$	$\frac{634}{4073}$	$\frac{635}{4177}$	$\frac{636}{4281}$	$\frac{637}{4385}$	$\frac{638}{4489}$	$\frac{639}{4593}$
$\frac{529}{2306}$	$\frac{530}{2374}$	$\frac{531}{2441}$	$\frac{532}{2507}$	$\frac{533}{2573}$	$\frac{534}{2638}$	$\frac{535}{2702}$	$\frac{536}{2765}$	$\frac{537}{2828}$	$\frac{538}{2890}$	$\frac{539}{2950}$
$\frac{429}{720}$	$\frac{430}{742}$	$\frac{431}{763}$	$\frac{432}{785}$	$\frac{433}{806}$	$\frac{434}{828}$	$\frac{435}{850}$	$\frac{436}{871}$	$\frac{437}{892}$	$\frac{438}{912}$	$\frac{439}{933}$

Figure 5. CBU configuration before permanent upgrade

Scenario 2: Will the resultant configuration be a valid configuration?

A subcapacity system has four subcapacity levels. When you activate a temporary upgrade, you activate one or more additional engines and one or more additional capacity levels. If you then apply a permanent upgrade, the resulting configuration must allow for the same number of temporary capacity levels and engines level to be active.

Suppose you are running an IBM z16 at model capacity 635 with CBU engines active to a 739 level (adding one capacity level and four engines). You then try to apply a permanent upgrade to a 735. The system would then attempt to add four engines and go up one capacity level from the new permanent configuration. Because there are no capacity levels beyond 7xx, the upgrade would fail. (See [Figure 7 on page 9.](#))

In this case, for the upgrade to work, first lower the CBU activation to a 639, and then apply the upgrade.

$\frac{729}{5243}$	$\frac{730}{5396}$	$\frac{731}{5549}$	$\frac{732}{5702}$	$\frac{733}{5855}$	$\frac{734}{6008}$	$\frac{735}{6160}$	$\frac{736}{6313}$	$\frac{737}{6465}$	$\frac{738}{6617}$	$\frac{739}{6768}$	$\frac{740}{6919}$
$\frac{629}{3553}$	$\frac{630}{3655}$	$\frac{631}{3760}$	$\frac{632}{3864}$	$\frac{633}{3968}$	$\frac{634}{4073}$	$\frac{635}{4177}$	$\frac{636}{4281}$	$\frac{637}{4385}$	$\frac{638}{4489}$	$\frac{639}{4593}$	
$\frac{529}{2306}$	$\frac{530}{2374}$	$\frac{531}{2441}$	$\frac{532}{2507}$	$\frac{533}{2573}$	$\frac{534}{2638}$	$\frac{535}{2702}$	$\frac{536}{2765}$	$\frac{537}{2828}$	$\frac{538}{2890}$	$\frac{539}{2950}$	
$\frac{429}{720}$	$\frac{430}{742}$	$\frac{431}{763}$	$\frac{432}{785}$	$\frac{433}{806}$	$\frac{434}{828}$	$\frac{435}{850}$	$\frac{436}{871}$	$\frac{437}{892}$	$\frac{438}{912}$	$\frac{439}{933}$	

Figure 6. Configuration before permanent upgrade - subcapacity level is not valid

						X	X	X	X	X	
$\frac{729}{5243}$	$\frac{730}{5396}$	$\frac{731}{5549}$	$\frac{732}{5702}$	$\frac{733}{5855}$	$\frac{734}{6008}$	$\frac{735}{6160}$	$\frac{736}{6313}$	$\frac{737}{6465}$	$\frac{738}{6617}$	$\frac{739}{6768}$	$\frac{740}{6919}$
$\frac{629}{3553}$	$\frac{630}{3655}$	$\frac{631}{3760}$	$\frac{632}{3864}$	$\frac{633}{3968}$	$\frac{634}{4073}$	$\frac{635}{4177}$	$\frac{636}{4281}$	$\frac{637}{4385}$	$\frac{638}{4489}$	$\frac{639}{4593}$	
$\frac{529}{2306}$	$\frac{530}{2374}$	$\frac{531}{2441}$	$\frac{532}{2507}$	$\frac{533}{2573}$	$\frac{534}{2638}$	$\frac{535}{2702}$	$\frac{536}{2765}$	$\frac{537}{2828}$	$\frac{538}{2890}$	$\frac{539}{2950}$	
$\frac{429}{720}$	$\frac{430}{742}$	$\frac{431}{763}$	$\frac{432}{785}$	$\frac{433}{806}$	$\frac{434}{828}$	$\frac{435}{850}$	$\frac{436}{871}$	$\frac{437}{892}$	$\frac{438}{912}$	$\frac{439}{933}$	

Figure 7. Configuration after permanent upgrade - subcapacity level is not valid

Scenario 3: Will resultant configuration go into the second drawer?

If you are on a subcapacity system, with a temporary record active, any permanent upgrade that moves the CP capacity marker to the second drawer will fail. This failure will occur even if the resulting capacity appears to be valid.

Suppose you are running an IBM z16 at model capacity 635 with CBU engines active to a 738 level. (See Figure 8 on page 10.) Then, if you try to apply a permanent upgrade to a 637, your upgrade will fail because you are moving the capacity marker beyond the 739 level into the second drawer. (See Figure 9 on page 10.)

For this upgrade to work, first decrease the CBU activation to a 637, and then apply the permanent upgrade. You could then activate additional CBU processors if necessary.

<u>729</u> 5243	<u>730</u> 5396	<u>731</u> 5549	<u>732</u> 5702	<u>733</u> 5855	<u>734</u> 6008	<u>735</u> 6160	<u>736</u> 6313	<u>737</u> 6465	<u>738</u> 6617	<u>739</u> 6768	<u>740</u> 6919
<u>629</u> 3553	<u>630</u> 3655	<u>631</u> 3760	<u>632</u> 3864	<u>633</u> 3968	<u>634</u> 4073	<u>635</u> 4177	<u>636</u> 4281	<u>637</u> 4385	<u>638</u> 4489	<u>639</u> 4593	
<u>529</u> 2306	<u>530</u> 2374	<u>531</u> 2441	<u>532</u> 2507	<u>533</u> 2573	<u>534</u> 2638	<u>535</u> 2702	<u>536</u> 2765	<u>537</u> 2828	<u>538</u> 2890	<u>539</u> 2950	
<u>429</u> 720	<u>430</u> 742	<u>431</u> 763	<u>432</u> 785	<u>433</u> 806	<u>434</u> 828	<u>435</u> 850	<u>436</u> 871	<u>437</u> 892	<u>438</u> 912	<u>439</u> 933	

Figure 8. Configuration before permanent upgrade - upgrade moves to next drawer

<u>729</u> 5243	<u>730</u> 5396	<u>731</u> 5549	<u>732</u> 5702	<u>733</u> 5855	<u>734</u> 6008	<u>735</u> 6160	<u>736</u> 6313	<u>737</u> 6465	<u>738</u> 6617	<u>739</u> 6768	X
<u>629</u> 3553	<u>630</u> 3655	<u>631</u> 3760	<u>632</u> 3864	<u>633</u> 3968	<u>634</u> 4073	<u>635</u> 4177	<u>636</u> 4281	<u>637</u> 4385	<u>638</u> 4489	<u>639</u> 4593	
<u>529</u> 2306	<u>530</u> 2374	<u>531</u> 2441	<u>532</u> 2507	<u>533</u> 2573	<u>534</u> 2638	<u>535</u> 2702	<u>536</u> 2765	<u>537</u> 2828	<u>538</u> 2890	<u>539</u> 2950	
<u>429</u> 720	<u>430</u> 742	<u>431</u> 763	<u>432</u> 785	<u>433</u> 806	<u>434</u> 828	<u>435</u> 850	<u>436</u> 871	<u>437</u> 892	<u>438</u> 912	<u>439</u> 933	

Figure 9. Configuration after permanent upgrade - upgrade moves to next drawer

Scenario 4: Using CBU is there sufficient CP features codes for increasing engine speed?

With CBU, CP capacity is managed by features codes. You select feature codes to either add engines or increase the engine speed.

Suppose you are running at capacity level 611 with increase capacity to a 711 using CBU. This requires 11 CP feature codes. Then, while CBU is active, you attempt to activate a permanent upgrade that adds an additional processor to go to a 612. The upgrade will fail because 12 CBU CP feature codes are now required.

To prevent this failure, either deactivate CBU prior to installing the permanent upgrade, or replenish the CBU record to add an additional CBU CP feature code prior to installing the permanent upgrade.

System Recovery Boost

A temporary System Recovery Boost upgrade can remain active no more than six hours. Consider waiting until an active System Recovery Boost upgrade is deactivated before installing a permanent upgrade.

Software considerations

While capacity upgrades to the server itself are concurrent, your software may not be able to take advantage of the increased capacity without performing an Initial Program Load (IPL).

Software charges based on the total capacity of the server on which the software is installed are adjusted to the new capacity that is in place after the permanent upgrade.

Software products using Workload License Charge (WLC) may not be affected by the server upgrade, as their charges are based on partition utilization and not based on server total capacity.

Some third party software packages may require new license keys in order to take advantage of the additional capacity. Check with your software vendor for details.

See your IBM sales representative for further information.

Temporary upgrades

You can have eight temporary upgrade records (On/Off CoD, CBU, CPE, System Recovery Boost Upgrade) installed or active at any given time. However, you can only have one On/Off CoD record active at any given time.

On/Off CoD

Consider the following before implementing any temporary capacity upgrades using On/Off CoD:

- Plan in advance to determine what configurations you might need based on workload projections. This is important because, when properly planned, you only need to order one On/Off CoD record; and this record should be able to handle any possible configurations you want to activate.
- When you order an On/Off CoD record, you can prepay for the upgrade or post-pay for the upgrade.
 - When ordering a post-paid On/Off CoD record without spending limits, you select your upgrade configuration. There is no cost incurred when you order or install this type of record. You pay for what you activate during the activation time. You are charged on a 24-hour basis.
 - When ordering a prepaid On/Off CoD record, you can select one or more configurations and identify the duration of each configuration. Then Resource Link calculates the total number of tokens you will need. As resources are used, the tokens are decremented.
 - When ordering a post-paid On/Off CoD record with spending limits, you can select your upgrade configuration and identify your maximum spending limit. Then, Resource Link calculates the number of tokens that will not allow you to exceed that limit. As the resources are used, the tokens are decremented.

For CP engines, a token represents an amount of processing capacity resulting in one MSU of software cost for one day (an MSU day). For specialty engines, a token represents the activation of one engine of that type for one day (a processor day).

- Ensure that you enable your system well in advance of needing to place an order. (The enablement process is described in [Chapter 3, “Enabling your machine to order upgrades,”](#) on page 21.)
- You can order an On/Off CoD record, retrieve the record to the Support Element, and install the record all in advance, to have it ready for activation.
- An On/Off CoD upgrade cannot change the server model, as additional processor drawer installation is not supported. However, On/Off CoD may change the server model capacity identifier if additional CP capacity is requested.
- Any currently unused capacity may be used for On/Off CoD, limited by the amount of currently physically installed capacity. Processing capacity that would previously have been referred to as CPs is measured in CP capacity units, not in PUs.
- On/Off CoD allows you to temporarily turn on unowned PUs, unassigned CPs (or unassigned CP capacity), and unassigned IFLs available within the current model with the following limitations:
 - Temporary model capacity with CPs and capacity level equal to or greater than the active model capacity, up to 100% of the purchased capacity (active permanent capacity plus unassigned permanent capacity)
 - As many temporary IFLs up to the total of purchased IFLs (permanently active IFLs plus unassigned IFLs)
 - As many additional specialty engines of each type up to the total purchased specialty engines of each type.
- An On/Off CoD record is initially available for up to 180 days, starting on the date you place your order.

- If you have an On/Off CoD record active and decide that you need to increase capacity, add processors, or extend the time to use the existing temporary capacity beyond the 180 days, you do not need to deactivate your current record to apply the new configuration record, temporarily leaving you with reduced capacity. You can reuse the existing On/Off CoD record by ordering a replenishment record. When ordering a replenishment record, you cannot decrease any of the limits identified in the On/Off CoD record. They must stay the same or increase.
- An On/Off CoD record can be activated until midnight GMT on its expiration date. If the record is active when it expires, it will be deactivated automatically. You can extend the expiration date by ordering a replenishment record before or after the record expires. You can also enable the automatic renewal function to automatically extend the expiration date of installed records.
- LinuxONE processing unit minimums and maximums apply to On/Off CoD record orders and allow ordering records for activating IFL upgrades and SAP upgrades only.

Additional logical processors can be concurrently configured online to logical partitions by the operating system when reserved processors are previously defined, resulting in image upgrades. The operating system must have the capability to concurrently configure more processors online.

Note

On/Off CoD provides a "physical" concurrent upgrade, resulting in more enabled processors available to a server configuration. Thus, additional planning and tasks are required for nondisruptive "logical" upgrades.

Considerations for unassigned model capacity and unassigned specialty engines

Unassigned model capacity is the portion of a machine's purchased model capacity (if any) that is not active. A machine with unassigned model capacity typically is referred to as a downgraded machine because the active portion of its purchased model capacity is less than, or downgraded from, its total purchased model capacity (also referred to as the model capacity high water mark).

Supported On/Off CoD upgrades for a downgraded machine include unassigned model capacities (which may or may not include the purchased model capacity) that have equal or greater CPs and capacity level as the active model capacity. You can use any installed On/Off CoD record (excluding administrative On/Off CoD test records) to activate supported On/Off CoD upgrades that reactivate a downgraded machine's unassigned model capacity. So your planning for ordering and installing an On/Off CoD record typically requires deciding only how much more model capacity, above the purchased model capacity, you might want to activate with this On/Off CoD record.

Financial considerations may also apply to this decision. Currently there are no hardware charges for temporary reactivations of unassigned model capacity, but hardware charges for temporary activation of model capacity above your purchased model capacity are determined by your On/Off CoD upgrade pricing agreement with IBM or your Business Partner.

Begin by deciding whether you want the On/Off CoD record you order to support:

- Only reactivating unassigned model capacity, or
- Both reactivating unassigned model capacity and activating more model capacity (up to 100% more than your machine's purchased model capacity).

If you want an On/Off CoD record that supports only reactivating your machine's unassigned model capacity, then order a record that enables activating zero percent (0%) more model capacity.

When you order an On/Off CoD record, you will see that the 0% more model capacity option is paired with your machine's current purchased model capacity. This indicates the purchased model capacity is the **maximum** model capacity that can be activated with this On/Off CoD record if you choose 0% more model capacity. But it is important to understand that your selection is the **maximum** additional model capacity that can be activated with this On/Off CoD record; it is not necessarily the only model capacity that can be activated. If you choose 0% more model capacity, you will be able to use the record

to activate any model capacity from the machine's downgraded model capacity up to and including its purchased model capacity.

For example, if you have an active model capacity of 715 (15 CPs) and a purchased model capacity of 718 (18 CPs), and you decide to order an On/Off CoD record that enables activating 0% more model capacity, then you can use the record to activate temporary upgrades from 715 (15 CPs) to 716 (16 CPs), 717 (17 CPs), or 718 (18 CPs). The record supports reactivating part or all of the machine's unassigned model capacity.

Otherwise, if you want to order an On/Off CoD record that supports both reactivating your machine's unassigned model capacity and activating more model capacity, you will need to select the maximum additional model capacity you might want to activate with this On/Off CoD record.

Your options for selecting a maximum model capacity are shown as percent increases, from 0% to 100%, of your machine's current purchased model capacity. Some options show a percent increase paired with a specific model capacity to give you a reference for choosing a percent increase great enough to enable activating particular model capacities.

Regardless of the percent increase you choose, it is important to understand that your selection is the **maximum** additional model capacity that can be activated with this On/Off CoD record. The record you order can be used to activate any model capacity from the machine's downgraded model capacity up to the model capacity at or nearest to the percent increase you choose.

For example, if you have an active model capacity of 715 (15 CPs) and a purchased model capacity of 718 (18 CPs), and you decide to order an On/Off CoD record that enables activating 15% more model capacity, then you can use the record to activate temporary upgrades from 715 (15 CPs) to:

- 716 (16 CPs), 717 (17 CPs), or 718 (18 CPs) for reactivation of part or all of the unassigned model capacity, and
- 719 (19 CPs), 720 (20 CPs), or 721 (21 CPs) for reactivation of all unassigned model capacity plus activation of additional model capacity.

Your considerations and options for using On/Off CoD records for temporary reactivation of unassigned specialty engines are similar. Unassigned IFLs, for example, are the subset of a machine's purchased IFLs that are not active. You can use any installed On/Off CoD record to reactivate a machine's unassigned IFLs (excluding administrative On/Off CoD test records). When planning for ordering and installing an On/Off CoD record, you must decide whether you want the record to support only reactivating the unassigned IFLs or support both reactivating the unassigned IFLs and activating more IFLs (up to two times more than your machine's purchased IFLs).

If you want an On/Off CoD record that supports only reactivating your machine's unassigned IFLs, then order a record that enables activating zero (0) more IFLs. Otherwise, if you want to order an On/Off CoD record that supports both reactivating your machine's unassigned IFLs and activating more IFLs, you will need to select the **maximum** number of additional IFLs you might want to activate with this On/Off CoD record. In either case, it is important to understand that your selection is the **maximum** additional IFLs that can be activated with this On/Off CoD record. The record you order can be used to reactivate any number of unassigned IFLs and to activate additional IFLs up to the number you choose.

Software considerations

Software Parallel Sysplex® License Charge (PSLC) customers are billed at the million service unit (MSU) level represented by the combined permanent and temporary capacity. All PSLC products are billed at the peak MSUs enabled during the month, regardless of usage.

Customers with Workload License Charge (WLC) licenses are billed by product, at the highest four-hour rolling average for the month. In this instance, temporary capacity does not necessarily increase your software billing until that capacity is allocated to logical partitions and actually consumed.

For customers with IPLA, there is a daily charge for additional capacity above the current capacity purchased.

There may be additional fees for non-IBM software. In addition, some non-IBM software packages may require new license keys in order to take advantage of the additional capacity. Check with your software vendor for details.

See your IBM sales representative for further information.

On/Off CoD test

Consider the following before implementing any On/Off CoD test records:

- An On/Off CoD test record allows you to:
 - Validate that the retrieve, install, activate, and deactivate On/Off CoD capacity upgrade process performs nondisruptively
 - Train your authorized users to activate an On/Off CoD record
 - Test an LPAR configuration
 - Verify you can change between CP activation levels.
- An On/Off CoD test record cannot be active at the same time as an On/Off CoD record
- An On/Off CoD test record deactivates at the end of the test period (24 hours).

Administrative On/Off CoD test

Consider the following before implementing any administrative On/Off CoD test records:

- An administrative On/Off CoD test record allows you to test the Capacity on Demand process for training and API testing without incurring hardware or software charges.
- No capacity is activated with this test record.
- An administrative On/Off CoD test record cannot be active at the same time as another On/Off CoD record. You must deactivate the administrative On/Off CoD test record prior to activating any other On/Off CoD records.

CBU

Consider the following before implementing any temporary capacity upgrades using CBU:

- Existing CBU entitlement considerations:
 - Note:** These tasks must be done by an IBM or Business Partner sales representative.
 - Any CBU contract in place can be carried forward.
 - CBU entitlements can be carried forward as a single record or split into multiple records.
 - Splitting of records can only affect resources, not the term limit.
 - Each record created by this action includes test activations.
 - Any resources added to the carried forward entitlements will be priced accordingly.
 - CBU engine type conversions will be allowed during the upgrade.
- During the manufacturing process, up to four ordered CPE and CBU records will be installed rather than staged. If more than four records are ordered, the records are staged on the Support Element and you can manually select which records to install.
- A CBU agreement must be in place before the feature code for this offering can be enabled on your server. Enabling the CBU feature code is nondisruptive. (The enablement process is described in [Chapter 3, “Enabling your machine to order upgrades,” on page 21.](#))
- CBU upgrades activate PUs through LICCC only. The hardware required for a CBU upgrade must already be installed. A CBU upgrade changes the model capacity identifier but cannot change the model.
- A CBU test upgrades the machine for the sole purpose of checking your system's ability to adequately perform in the event of an emergency. Each CBU record provides a specific number of free, 10-day

test activations. The number of free test activations equates to the number of years that are purchased with the CBU record. (For example, a three year CBU record has three tests activations, a one year CBU record has one test activation.) Additional test activations beyond the free tests may be purchased in single increments up to a maximum of 15 CBU tests per record. This maximum of 15 tests per record cannot be exceeded and includes any free activations plus additional paid test activations.

- If CBU was not included in the order with your new machine, contact your sales representative to place an order for CBU.
- You can extend the expiration date of an existing non-expired CBU record up to a maximum of five years by ordering a replenishment record. The five years includes your current remaining years of the CBU record (rounded up) plus any newly purchased years. One test activation is provided for each additional year added to the CBU record. A CBU record cannot be activated after the expiration date has passed. If the record is active it will be automatically deactivated at midnight GMT two days after the expiration date and the CBU record will remain on the system.
- A CBU system typically operates with a "base" PU configuration having a preconfigured number of additional spare PUs reserved for activation, in case of an emergency, as CBU model capacity or specialty engines.
- The base CBU server configuration must have sufficient memory and channels to accommodate the potential needs of the largest CBU target configuration. When capacity is needed in an emergency, you can activate the emergency CBU configuration with the reserved spare PUs. It is very important to ensure that all required functions are available on the "backup" servers, including CFLEVELs for Coupling Facility partitions, as well as cryptographic and connectivity capabilities.
- You can run production workload on a CBU upgrade during a CBU test provided that at least an equivalent amount of production capacity is shut down for the duration of the CBU test. If you already have existing CBU contracts, you will also need to sign an Amendment (US form #Z125-8145) with IBM.
- You can order a CBU record that contains more PUs than they have available on your system. Then when you activate the CBU record, you would select the combination of PU types you want to activate.
- The 2:1 zIIP to CP ratio for IBM Z processor configurations applies to CBU record orders. The ratio may be a factor in limiting the number of zIIPs you can order.
- This upgraded configuration is activated temporarily and provides additional PUs above and beyond the server's original, permanent configuration. The number of additional PUs is limited by the configuration of the CBU record.
- When the emergency is over or the CBU test is complete, the server must be taken back to its original, permanent configuration. The CBU records can be deactivated at any time before the end of real or test activation. If it is not manually deactivated, it will be automatically deactivated and the CBU record will remain on the system.
- A real activation is available up to 90 days starting on the date you activate the CBU record. When a CBU real activation has been exhausted, the CBU record is automatically deactivated. Once the real activation has been consumed, the CBU record cannot be activated again, even if test activations are remaining on the record. However, you can order a replenishment record to restore the real activation for continued use of this CBU record. You may order and install this replenishment while the CBU real activation is still active to prevent a gap in your disaster recovery coverage.
- Once a CBU record enters the 2-day grace period, the only customer option is to deactivate all resources from this record. You cannot change the activation level by increasing or decreasing partial resources. If you attempt to partially increase or decrease resources, you will receive an error indicating the CBU record has expired.
- LinuxONE processing unit minimums and maximums apply to CBU record orders and allow ordering records for activating IFL upgrades and SAP upgrades only.

Note: CBU for processors provides a "physical" concurrent upgrade, resulting in more enabled processors available to a server configuration. Thus, additional planning and tasks are required for nondisruptive "logical" upgrades.

Software considerations

IBM software charges during a disaster or a test are not affected by CBU. Software charges for the designated CBU machine are based on its permanent configuration; software charges for any machine whose workload is transferred to the CBU machine during an emergency are based on that machine's permanent configuration. Please note that CBU does not add any IBM program authorizations beyond those that you have acquired.

There may be additional fees for non-IBM software. In addition, some non-IBM software packages may require new license keys in order to take advantage of the additional capacity. Check with your software vendor for details.

See your IBM sales representative for further information.

CPE

Consider the following before implementing any temporary capacity upgrades using CPE:

- During the manufacturing process, up to four ordered CPE and CBU records will be installed rather than staged. If more than four records are ordered, the records are staged on the Support Element and you can manually select which records to install.
- A CPE agreement must be in place before the special code that enables the offering can be loaded on your server. CPE features can be added nondisruptively to an existing IBM Z server. (The enablement process is described in Chapter 3, “Enabling your machine to order upgrades,” on page 21.)
- CPE can activate any PUs through LICCC only. For IBM Z servers, the correct hardware must be installed to allow the required upgrade by LICCC. CPE changes the model capacity identifier, but cannot change the IBM Z model.
- A CPE system typically operates with a "base" PU configuration having a preconfigured number of additional spare PUs reserved for activation. A single CPE record may be used to activate any of these spare PUs as any additional model capacity or specialty engines.
- The 2:1 zIIP to CP ratio for IBM Z processor configurations applies to CPE record orders. The ratio may be a factor in limiting the number of zIIPs you can order.
- It is very important to ensure that all required functions are available on the "backup" server, including CFLEVELs for Coupling Facility partitions, as well as channel, cryptographic capacities, and that sufficient memory on the system is available.
- When the event is over, the server must be taken back to its original, permanent configuration. The CPE record can be deactivated at any time before the expiration date. If it is not manually deactivated, it will be automatically deactivated. Used CPE records are not automatically removed. They will remain on the system after deactivation.
- Fixed prepaid price.
- LinuxONE processing unit minimums and maximums apply to CPE record orders and allow ordering records for activating IFL upgrades and SAP upgrades only.

Software considerations

There are no additional IBM software charges for capacity activated using CPE. Software charges for the designated CPE machine are based on its permanent configuration; software charges for any machine whose workload is transferred to the CPE machine during the event are based on that machine's permanent configuration. Please note that CPE does not add any IBM program authorizations beyond those that you have acquired.

There may be additional fees for non-IBM software. In addition, some non-IBM software packages may require new license keys in order to take advantage of the additional capacity. Check with your software vendor for details.

See your IBM sales representative for further information.

System Recovery Boost Upgrade

Consider ordering and installing a System Recovery Boost Upgrade record as a lower cost alternative to other CoD records for making additional zIIPs available for a system recovery zIIP boost.

System Recovery Boost is a control program function that makes additional processing capacity temporarily available to logical partitions for expediting system recovery processes such as system shutdown, system IPL, and middleware/workload restart and recovery.

A zIIP boost is a System Recovery Boost option whereby a logical partition can dispatch CP workloads to its active zIIPs during system recovery. Active zIIPs can include both permanent zIIPs and temporary zIIPs.

A System Recovery Boost Upgrade record is a CoD record specifically designed to make temporary zIIPs available for a zIIP boost. A standard record is configured accordingly to support activating an ample number of additional zIIPs but for a short period of time: up to 20 additional zIIPs, for up to six hours, for each activation. It is priced as a prepaid record, billable upon download, with no subsequent software charges or maintenance charges for the additional zIIPs activated by the record.

A standard record is configured with 30 activation tokens. Each activation consumes one token, regardless of the number of additional zIIPs activated. But the number of activations is effectively unlimited. There is no charge for ordering and installing replenishment records to restore an installed record's activation tokens.

The record subscription length (ie. how long you can use the record) is configurable. You can set the record subscription for up to five years, in one year increments, when ordering the record. The subscription begins on the record order date.

The record expires when its subscription ends. But you can order and install a replenishment record anytime on or before the record expiration date to extend its subscription, in one year increments, up to the five year maximum. The replenishment record is priced as a prepaid record and billable upon download.

A free 90 day trial is available for supported machines that have not previously had a System Recovery Boost Upgrade record installed. The trial provides a standard record with full capabilities and a 90 day subscription. If you decide you want to continue using the record after the 90 day trial ends, you can order and install a replenishment record on or before the record expiration date to extend its subscription up to five years. Otherwise, if you decide to let the trial record expire, you can simply order a new record whenever you decide you need it.

Subcapacity CP activation

The restrictions described in this section apply only to IBM Z models that support CPs in multiple drawers. These restrictions do not apply to IBM Z models with CPs in a single drawer. Furthermore:

- These restrictions apply only to systems using subcapacity CPs (4xx, 5xx, or 6xx capacity levels); they do not apply to systems using full capacity CPs (7xx capacity levels).
- These restrictions apply only to temporary model capacity upgrades; they do not apply to specialty engine upgrades.
- These restrictions apply only when you use multiple temporary records at the same time. A typical scenario for using multiple temporary records at the same time is activating a CBU record while an On/Off CoD record is active.

Multi-drawer systems using subcapacity CPs allow using multiple temporary records at the same time, but some restrictions apply to the range of model capacity upgrades you can activate. The restrictions prevent activating and deactivating model capacity upgrades in combinations that would result in invalid configurations in the second drawer or beyond, where subcapacity CPs are not supported.

Figure 10 on page 18 shows an example of how unrestricted activation and deactivation of multiple records could lead to an invalid configuration in the second drawer of an IBM z16. The IBM z16 in this example is using subcapacity CPs (its permanent model capacity is 633) and it has two temporary records

installed: an On/Off CoD record and a CBU record. Consider the result of using its temporary records as follows:

- The On/Off CoD record is used to activate a model capacity upgrade from 633 to 735.
- The CBU record is used to activate an additional 12 CPs, upgrading the model capacity from 735 to 747. The combined capacity level of the two upgrades is now in the second drawer.
- If the On/Off CoD record is deactivated while the CBU record remains active, it would result in a capacity setting of 645, which is not a valid configuration because subcapacity CPs are not supported beyond the first drawer.

729 5243	730 5396	731 5549	732 5702	733 5855	734 6008	735 6160	736 6313	737 6465	738 6617	739 6768	740 6919	741 7069	742 7218	743 7366	744 7513	745 7659	746 7804	747 7949
629 3553	630 3655	631 3760	632 3864	633 3968	634 4073	635 4177	636 4281	637 4385	638 4489	639 4593	X	X	X	X	X	X	X	X
529 2306	530 2374	531 2441	532 2507	533 2573	534 2638	535 2702	536 2765	537 2828	538 2890	539 2950	X	X	X	X	X	X	X	X
429 720	430 742	431 763	432 785	433 806	434 828	435 850	436 871	437 892	438 912	439 933	X	X	X	X	X	X	X	X

Figure 10. Example of invalid IBM z16 capacity setting from activation and deactivation of multiple records

Rules for subcapacity CP activations

To prevent invalid configurations when multiple records are active, three rules are enforced for activation of subcapacity CPs:

- When one record increases the capacity level, it is the only record allowed to subsequently activate capacity beyond the first drawer.
- When more than one record increases the capacity level, none of the records are allowed to activate capacity beyond the first drawer.
- When one record increases the capacity level and activates capacity beyond the first drawer, it is the only record allowed to subsequently activate additional CPs.

These rules, plus limits included in the temporary capacity records, guarantee the server returns to a valid configuration when any active record is deactivated.

Examples of the rules

The rules are illustrated in the following four examples.

Example one:

When a record activates an upgrade that increases the CP capacity level but does not enter the second drawer, another record can subsequently activate upgrades only within the first drawer.

For example, in Figure 11 on page 19, the first activated record changes the capacity setting of an IBM z16 from 633 to 735. The machine allows activation of additional CPs from any subsequent temporary record up to 739, the maximum capacity setting within the first drawer of an IBM z16, as shown.

$\frac{729}{5243}$	$\frac{730}{5396}$	$\frac{731}{5549}$	$\frac{732}{5702}$	$\frac{733}{5855}$	$\frac{734}{6008}$	$\frac{735}{6160}$	$\frac{736}{6313}$	$\frac{737}{6465}$	$\frac{738}{6617}$	$\frac{739}{6768}$	X
$\frac{629}{3553}$	$\frac{630}{3655}$	$\frac{631}{3760}$	$\frac{632}{3864}$	$\frac{633}{3968}$	$\frac{634}{4073}$	$\frac{635}{4177}$	$\frac{636}{4281}$	$\frac{637}{4385}$	$\frac{638}{4489}$	$\frac{639}{4593}$	X
$\frac{529}{2306}$	$\frac{530}{2374}$	$\frac{531}{2441}$	$\frac{532}{2507}$	$\frac{533}{2573}$	$\frac{534}{2638}$	$\frac{535}{2702}$	$\frac{536}{2765}$	$\frac{537}{2828}$	$\frac{538}{2890}$	$\frac{539}{2950}$	X
$\frac{429}{720}$	$\frac{430}{742}$	$\frac{431}{763}$	$\frac{432}{785}$	$\frac{433}{806}$	$\frac{434}{828}$	$\frac{435}{850}$	$\frac{436}{871}$	$\frac{437}{892}$	$\frac{438}{912}$	$\frac{439}{933}$	X

Figure 11. Example of IBM z16 upgrades allowed for other records after first record changes capacity level within the first drawer

Example two:

When multiple records activate upgrades that increase the capacity level but do not enter the second drawer, the machine does not allow any record to enter the second drawer.

For example, Figure 12 on page 19 shows two records that change the CP capacity level of an IBM z16. Entering the second drawer is not allowed. Only upgrades to capacity settings in the first drawer are allowed under the second rule.

$\frac{729}{5243}$	$\frac{730}{5396}$	$\frac{731}{5549}$	$\frac{732}{5702}$	$\frac{733}{5855}$	$\frac{734}{6008}$	$\frac{735}{6160}$	$\frac{736}{6313}$	$\frac{737}{6465}$	$\frac{738}{6617}$	$\frac{739}{6768}$	X
$\frac{629}{3553}$	$\frac{630}{3655}$	$\frac{631}{3760}$	$\frac{632}{3864}$	$\frac{633}{3968}$	$\frac{634}{4073}$	$\frac{635}{4177}$	$\frac{636}{4281}$	$\frac{637}{4385}$	$\frac{638}{4489}$	$\frac{639}{4593}$	X
$\frac{529}{2306}$	$\frac{530}{2374}$	$\frac{531}{2441}$	$\frac{532}{2507}$	$\frac{533}{2573}$	$\frac{534}{2638}$	$\frac{535}{2702}$	$\frac{536}{2765}$	$\frac{537}{2828}$	$\frac{538}{2890}$	$\frac{539}{2950}$	X
$\frac{429}{720}$	$\frac{430}{742}$	$\frac{431}{763}$	$\frac{432}{785}$	$\frac{433}{806}$	$\frac{434}{828}$	$\frac{435}{850}$	$\frac{436}{871}$	$\frac{437}{892}$	$\frac{438}{912}$	$\frac{439}{933}$	X

Figure 12. Example of IBM z16 upgrades allowed after two records change capacity levels

Example three:

When a record increases the CP capacity level and enters the second drawer, only this record can activate additional CPs. You can use other records only to add specialty engines.

For example, in Figure 13 on page 20, the first record activated an upgrade that changed the capacity setting of an IBM z16 from 533 to 743. While this record remains active, it is the only record allowed to add CPs (up to the limits defined by the capacity record) under the third rule. Other temporary records can be used only to add specialty engines.

<u>729</u> 5243	<u>730</u> 5396	<u>731</u> 5549	<u>732</u> 5702	<u>733</u> 5855	<u>734</u> 6008	<u>735</u> 6160	<u>736</u> 6313	<u>737</u> 6465	<u>738</u> 6617	<u>739</u> 6768	<u>740</u> 6919	<u>741</u> 7069	<u>742</u> 7218	<u>743</u> 7366	<u>744</u> 7513	<u>745</u> 7659	<u>746</u> 7804	<u>747</u> 7949
<u>629</u> 3553	<u>630</u> 3655	<u>631</u> 3760	<u>632</u> 3864	<u>633</u> 3968	<u>634</u> 4073	<u>635</u> 4177	<u>636</u> 4281	<u>637</u> 4385	<u>638</u> 4489	<u>639</u> 4593	X	X	X	X	X	X	X	X
<u>529</u> 2306	<u>530</u> 2374	<u>531</u> 2441	<u>532</u> 2507	<u>533</u> 2573	<u>534</u> 2638	<u>535</u> 2702	<u>536</u> 2765	<u>537</u> 2828	<u>538</u> 2890	<u>539</u> 2950	X	X	X	X	X	X	X	X
<u>429</u> 720	<u>430</u> 742	<u>431</u> 763	<u>432</u> 785	<u>433</u> 806	<u>434</u> 828	<u>435</u> 850	<u>436</u> 871	<u>437</u> 892	<u>438</u> 912	<u>439</u> 933	X	X	X	X	X	X	X	X

Figure 13. Example of first record changing capacity level and entering the second drawer of an IBM z16

Example four:

When the first record does not increase the CP capacity level, the second record is allowed to increase the CP capacity level and to enter the second drawer.

Figure 14 on page 20 illustrates this example for an IBM z16:

- The first record upgrades the model capacity from 533 to 537, and another record upgrades it from 537 to 743. This is a valid configuration, because either record can be deactivated entirely without resulting in an invalid configuration.
- Adding more CPs with the first record is not possible because, under the third rule, only the record that activates capacity beyond the first drawer can add more CPs. So only the second record can add CPs (up to the limits defined by the capacity record).
- Both records can still deactivate CPs. That is, even the first record can decrease the number of activated CPs.

<u>729</u> 5243	<u>730</u> 5396	<u>731</u> 5549	<u>732</u> 5702	<u>733</u> 5855	<u>734</u> 6008	<u>735</u> 6160	<u>736</u> 6313	<u>737</u> 6465	<u>738</u> 6617	<u>739</u> 6768	<u>740</u> 6919	<u>741</u> 7069	<u>742</u> 7218	<u>743</u> 7366	<u>744</u> 7513	<u>745</u> 7659	<u>746</u> 7804	<u>747</u> 7949
<u>629</u> 3553	<u>630</u> 3655	<u>631</u> 3760	<u>632</u> 3864	<u>633</u> 3968	<u>634</u> 4073	<u>635</u> 4177	<u>636</u> 4281	<u>637</u> 4385	<u>638</u> 4489	<u>639</u> 4593	X	X	X	X	X	X	X	X
<u>529</u> 2306	<u>530</u> 2374	<u>531</u> 2441	<u>532</u> 2507	<u>533</u> 2573	<u>534</u> 2638	<u>535</u> 2702	<u>536</u> 2765	<u>537</u> 2828	<u>538</u> 2890	<u>539</u> 2950	X	X	X	X	X	X	X	X
<u>429</u> 720	<u>430</u> 742	<u>431</u> 763	<u>432</u> 785	<u>433</u> 806	<u>434</u> 828	<u>435</u> 850	<u>436</u> 871	<u>437</u> 892	<u>438</u> 912	<u>439</u> 933	X	X	X	X	X	X	X	X

Figure 14. Example of second record changing capacity level and entering the second drawer of an IBM z16

Chapter 3. Enabling your machine to order upgrades

The enablement process for each Capacity on Demand offering begins when you order the associated enablement feature code and sign the associated IBM contract document(s), and for online buying capability, completes when you receive an email from Resource Link notifying you that your machine is enabled for ordering upgrade records.

This chapter lists the Capacity on Demand enablement features and their feature codes, lists the agreements that must be signed for the enablement process to begin, and guides you through the instructions you must follow to enable your machine to order upgrades.

Capacity on Demand enablement feature codes

The Capacity on Demand enablement features are:

- On-Line Capacity on Demand (CoD) Buying (FC 9900)
- Permanent Upgrade Authorization (FC 9898)
- On/Off CoD Authorization (FC 9896)
- CBU Authorization (FC 9910)
- CPE Authorization (FC 9912)
- SRB Upgrade Authorization (FC 9930)

You can order CoD enablement features through your sales representative when ordering a supported server or at any time afterward.

Agreements required for enablement

Most existing agreements for Customer Initiated Upgrade-On/Off Capacity on Demand (CIU-On/Off CoD) and Capacity Back Up (CBU) will carry forward to IBM Z and LinuxONE for those offerings. Refer to [“Existing agreements that carry forward to IBM Z and IBM LinuxONE”](#) on page 21 for a list of these agreements.

Capacity on Demand capabilities and features introduced for IBM Z and LinuxONE are supported by a new set of agreements. Refer to [“Agreements and supplements for IBM Z and IBM LinuxONE Capacity on Demand functions and features”](#) on page 22 for a list of these agreements.

Existing agreements that carry forward to IBM Z and IBM LinuxONE

CIU-On/Off CoD

If you have any of the following CIU-On/Off CoD agreements already existing, you can carry those forward for only the features associated with the previously signed agreements.

- *IBM Customer Agreement, Attachment for Customer Initiated Upgrade and IBM eServer™ On/Off Capacity on Demand* (US form #Z125-6611)
- *IBM Customer Agreement, Supplement for Customer Initiated Upgrade and IBM eServer On/Off Capacity on Demand II* (US form #Z125-6688)
- *IBM Customer Agreement, Supplement for Customer Initiated Upgrade and IBM eServer On/Off Capacity on Demand* (US form #Z125-6612)
- *IBM Customer Agreement, Addendum to Customer Initiated Upgrade and IBM eServer On/Off Capacity on Demand Tests* (US form #Z125-7139).

CBU

If you have any of the following CBU agreements already existing, you can carry those forward for only the offerings associated with the previously signed agreements.

- *IBM Customer Agreement, Attachment for Capacity Backup Upgrade* (US form #Z125-5598 Version -03, -04, or -05 (only))
- *IBM Customer Agreement, Supplement for Capacity Backup Upgrade* (US form #Z125-6857)
- *IBM Customer Agreement, Supplement for Capacity Backup Upgrade II* (US form #Z125-7137).

Agreements and supplements for IBM Z and IBM LinuxONE Capacity on Demand functions and features

In addition to the customer agreements for each specific Capacity on Demand feature, there are additional customer agreements and supplements that must be signed before you can enable some of the features. These additional customer agreements are: the base Capacity on Demand agreement, the replacement capacity offering agreement, and the On-Line CoD Buying agreement.

Base Capacity on Demand agreement:

Contains the base terms for all IBM Z and LinuxONE Capacity on Demand features:

- *IBM Customer Agreement Attachment for IBM System z® Capacity on Demand Offerings* (US form #Z125-7879).

Replacement capacity offering agreement:

Contains the common terms common for each replacement capacity offering.

- *IBM Customer Agreement Attachment for IBM System z Replacement Capacity Offerings* (US form #Z125-7880).

On-Line CoD Buying agreement and supplement

Contains the supporting terms for the On-Line CoD Buying of Permanent Upgrades and On/Off CoD features and the optional On-Line CoD buying capability for the CBU and CPE features:

- *IBM Customer Agreement Attachment for IBM System z On-Line CoD Buying* (US form #Z125-7884)
- *Supplement for On-Line Ordering* (US form #Z125-7885) or *Supplement for On-Line Ordering II* (US form #Z125-7908).

The On-Line Ordering attachment requires a supplement through which the customer's Resource Link IDs are specified as being valid for placing online orders for a given machine. The supplement must be prepared and signed with each transaction that includes an On-Line CoD Buying feature (FC 9900).

Note: The On-Line CoD Buying feature (FC 9900) is a prerequisite when ordering Permanent Upgrade Enablement (FC 9898) or On/Off CoD Enablement (FC 9896) for the first time. Without the On-Line CoD Buying feature, you cannot use Resource Link to acquire upgrades and other entitlements.

The On-Line CoD Buying feature (FC 9900) is optional for the CBU and CPE offerings because the CBU and CPE records can also be ordered or replenished through your sales representative. However, if the On-Line Buying feature (FC 9900) is subsequently ordered, you can use Resource Link to order CBU or CPE records and entitlement replenishment.

Agreements required for Capacity Back Up (CBU)

You are required to sign the following agreements one time within a given country before IBM will accept an order for your first instance of the enablement feature code for CBU Enablement (feature #9910):

- *IBM Customer Agreement Attachment for IBM System z Capacity on Demand Offerings* (US form #Z125-7879)
- *IBM Customer Agreement Attachment for IBM System z Replacement Capacity Offerings* (US form #Z125-7880)

- *IBM Customer Agreement Attachment for IBM System z Capacity Back Up* (US form #Z126-9408).

Note: These agreements may also be signed if a CBU contract expires and you want to renew it.

If you have CBU attachments already in place and you want to execute production workload on the capacity of the CBU upgrade during a CBU test, you must sign the following contract:

- *IBM Customer Agreement Amendment for Capacity Backup Upgrade Tests* (US form #Z125-8145)

Agreements required for Capacity for Planned Events (CPE)

You are required to sign the following agreements one time within a given country before IBM will accept an order for your first instance of the CPE Enablement feature code (feature #9912) :

- *IBM Customer Agreement Attachment for IBM System z Capacity on Demand Offerings* (US form #Z125-7879)
- *IBM Customer Agreement Attachment for IBM System z Replacement Capacity Offerings* (US form #Z125-7880)
- *IBM Customer Agreement Attachment for IBM System z Capacity for Planned Events* (US form #Z125-7882).

Agreements required for On/Off Capacity on Demand

You are required to sign the following agreements one time within a given country before IBM will accept an order for your first instance of the On/Off CoD Enablement feature (feature #9896):

- *IBM Customer Agreement Attachment for IBM System z Capacity on Demand Offerings* (US form #Z125-7879)
- *IBM Customer Agreement Attachment for IBM System z On-Line CoD Buying* (US form #Z125-7884), including either the *Supplement for On-Line Order* (US form #Z125-7885) or *Supplement for On-Line Ordering II* (US form #Z125-7908)
- *IBM Customer Agreement Attachment for IBM System z On/Off Capacity on Demand* (US form #Z125-7883).

Agreements required for On-Line CoD Buying of Permanent Upgrades

You are required to sign the following agreements one time within a given country before IBM will accept an order for your first instance of the Permanent Upgrade Enablement feature (feature #9898):

- *IBM Customer Agreement Attachment for IBM System z Capacity on Demand Offerings* (US form #Z125-7879)
- *IBM Customer Agreement Attachment for IBM System z On-Line CoD Buying* (US form #Z125-7884), including either the *Supplement for On-Line Ordering* (US form #Z125-7885) or *Supplement for On-Line Ordering II* (US form #Z125-7908).

Agreements required for System Recovery Boost Upgrade

You are required to sign the following agreements one time within a given country before IBM will accept an order for your first instance of the SRB Upgrade Authorization feature code (feature #9930):

- *IBM Customer Agreement Attachment for IBM System z Capacity on Demand Offerings* (US form #Z125-7879)
- *IBM Client Relationship Agreement Attachment for IBM Z System Recovery Boost Upgrade* (US form #Z126-8599).

How to enable your machine for On-Line CoD ordering

To enable your machine for ordering CoD records:

1. Obtain an IBMid by creating an IBM account at <http://www.ibm.com/account/profile>.

2. Log onto Resource Link to register your IBMid.
3. Contact your IBM or Business Partner sales representative to order your Capacity on Demand offerings. After your sales representative submits your enablement order, they contact CSO/BPSO to generate the appropriate agreement(s) and supplement(s) that you must sign. These agreements explain the terms and conditions for your Capacity on Demand offerings. The supplement requires your registered IBMid, customer number, machine type and serial number.
4. The sales representative sends the signed supplement to the IBM Access Administrator who creates the machine profile based on the information you provide in the supplement.
5. Resource Link enables the IBM Service Support System to download the feature codes to the machine the next time the machine performs a Transmit Service Availability Data (TSAD) transmission. (This occurs during the next scheduled availability call home.)
Note: You will want to verify that your machine is set for a schedule operation to transmit the machine TSAD. This is set up on the Support Element.
6. Once the above steps are completed, Resource Link sends an email to notify you that the machine is enabled for On-Line CoD ordering.

CIU machine profiles on Resource Link

A Customer Initiated Upgrade (CIU) machine profile is the IBM Resource Link web page that supports ordering Capacity on Demand (CoD) records online for a CoD-enabled machine. IBM creates a machine profile during the machine enablement process and notifies its authorized users by email when the machine profile is created and online ordering is enabled.

Opening machine profiles

Authorized users can open CIU machine profiles on Resource Link. To open a machine profile:

1. Click the **Customer Initiated Upgrade** left navigation link on any Resource Link web page to open the **Active machine profiles** page.
2. Locate the machine in the list on the **Active machine profiles** page. Look for its identifiers in the **Type-serial-customer#** column (machine type, serial number, customer number) or its name in the **System name** column.
3. Click the machine's link in the **Type-serial-customer#** column to open its machine profile.

The machine profile page title identifies the machine by machine type, serial number, and customer number. The page content provides further details of its configuration and identification, along with links for enabled CoD ordering options, and for updating the machine profile.

An upgrade matrix is also available. The matrix displays the potential upgrade capacities for the hardware model. To view this information, click **Display upgrade matrix** located on the right navigation pane.

Machine profile

3931 - 0092D - 5555556

Current configuration		Machine summary	Ordering options
Model Capacity:	730 (30 CPs)	Type, model, serial: 3931 - A01 - 0092D	→ Order permanent upgrade
ICF:	2	System name: SYSA	→ Order On/Off CoD record
zIIP:	5	Model capacity downgraded from: 731 (31 CPs)	→ Order On/Off CoD test record
IFL:	3		→ Order On/Off CoD record with prepaid upgrades
SAP:	10		→ Order administrative On/Off CoD test record
Memory:	768		→ Order Capacity Backup (CBU) record
Unassigned ICF:	1	Customer summary	→ Order System Recovery Boost Upgrade record
Unassigned zIIP:	3	Company name: IBM	📄 Display upgrade matrix
Unassigned IFL:	2	Customer number: 5555556	To update profile
Current configuration as of 12 Jun 2022 22:53:37		GEO, country: Americas - US	📄 Upload VPD
			📄 Upload upgrade billing XML data
			→ Disable machine profile...

The machine profile **About ordering** section includes the user ID of the person authorized to order CoD records, the user ID of a secondary approver (if needed), what offerings and settings are enabled, and notes about the current contract for the server and any possible restrictions.

About ordering	Ordering options	For more information
Authorization to create orders User ID: orderer@biz.com	CIU permanent: Enabled	→ On/Off CoD billing history
Authorization to approve orders User ID: approver@biz.com	On/Off CoD: Enabled	↓ Download upgrade history CSV (868 bytes)
Notes:	Auto renewal: Enabled	→ Manage users
<ul style="list-style-type: none">• A pre-negotiated price agreement exists for this machine.• On/Off CoD maintenance prices are set for this machine.• On/Off CoD Test: 0 staged out of 1 remaining	CBU: Enabled	📄 Order status definitions
	Boost: Enabled	→ Customer Initiated Upgrade information


The machine profile **Capacity on Demand records** section provides a summary of all the temporary upgrade records that have been ordered for the server.

Capacity on Demand records

Open orders		All orders
Record number · type · install state		
Order number	Order status	Order description
<u>CRCBHRDP</u> · On/Off CoD · Installed		
<u>CXC BHRDP</u>	· Order approved 10 Feb 2022 · Installed	+100% model capacity, +3 ICF, +8 zIIP, +5 IFL, +8 SAP

The machine profile **Permanent upgrades** section provides a summary of all the permanent upgrade records that have been ordered for the server.

Permanent upgrades

Open orders		Complete orders	All orders	
Order number	Order summary	Date ordered	Order status	Status history
<u>CXDSLFR5</u>	Permanent upgrade 729 (29 CPs) to 730 (30 CPs) active	12 Jun 2022 15:19:14 GMT	Complete	 Open

Managing user access to machine profiles

IBM enables initial access to a machine profile upon creating it during the machine enablement process. Initial access includes at least one orderer, and may include additional orderers, order approvers, and viewers.

Users authorized to create orders:

Users with this role are allowed to order the various Capacity on Demand records. Generally these users have knowledge about the type of records that are required and the desired activation configurations.

Users authorized to approve orders:

Users with this role must approve record orders before they are staged on the support system and made ready for download. Generally these users have the financial authority within a company to purchase upgrades. Depending on your company's policy, you may or may not have an order approver. Companies that use a purchase order to control their purchases with IBM, must have an order approver in order to stage records.

Users authorized to view orders:

Generally this role is assigned to members of the operations team who are not authorized to create or approve orders but may need to view orders.

Only authorized users can order upgrade records, view orders, or approve orders. The lists of authorized users can be managed by the users defined in the **About ordering** section. Click the **Manage users** link located on the right navigation pane to view or update the list of users authorized in each role.

Manage users

Orderers	Approvers	Viewers
----------	-----------	---------

Active machines (3) All machines (12)

Use this form to add order creators, remove order creators or replace the managing order creator (shown in bold).

Update type:* Add user Remove user Replace managing user

User IDs:*

<input type="checkbox"/>	▲ Type	↕ Serial	↕ Active	↕ Orderers	
<input type="checkbox"/>		3931	0092D	Yes	orderer@biz.com
<input type="checkbox"/>		8561	FF321	Yes	orderer@biz.com , altorderer@biz.com
<input type="checkbox"/>		8561	FF322	Yes	orderer@biz.com , altorderer@biz.com

Figure 15. Manage users panel

Chapter 4. Ordering

This chapter explains what you should consider before ordering an upgrade and provides steps you need to follow when ordering an upgrade.

To order permanent upgrades, CBU records, and CPE records, you can use the CIU application through Resource Link or you can call your IBM or Business Partner sales representative. To order On/Off CoD records, you can only use the CIU application through Resource Link.

This chapter provides information about ordering an upgrade record using the CIU application through Resource Link.

Permanent upgrade considerations

Before you order a permanent upgrade using the CIU application through Resource Link, consider the following:

- You can only order one permanent upgrade record at a time. However, a single record can have multiple items (any number of engines of any type and memory) as long as they are within the limits of the machine. With this record, you can also order "unassigned" model capacity and IFLs.

If a permanent upgrade is currently being processed, you cannot order another permanent upgrade until VPD is received that confirms the previous permanent upgrade is installed.

- When placing your order, consider how many engines will be left on your machine and how this will impact your enhanced drawer availability.
- Capacity limits or specialty engine limits. (See Table 1 on page 29, Table 2 on page 29, Table 3 on page 30, Table 4 on page 30, and Table 5 on page 30.)

Table 1. IBM z16 Model A01 - Capacity limits and specialty engine limits for permanent upgrades

Model	Available PUs	Active PUs			zIIPs/ uzIIPs	Base SAPs	Opt SAPs	Spare PUs
		CPs	ICFs / uICFs	IFLs / uIFLs				
A01	39	0 - 39	0 - 39/38	0 - 39/38	0 - 25/24	5	0 - 8	2
A01	82	0 - 82	0 - 82/81	0 - 82/81	0 - 54/53	10	0 - 8	2
A01	125	0 - 125	0 - 125/124	0 - 125/124	0 - 82/81	15	0 - 8	2
A01	168	0 - 168	0 - 168/167	0 - 168/167	0 - 110/109	20	0 - 8	2
A01	200	0 - 200	0 - 200/199	0 - 200/199	0 - 132/131	24	0 - 8	2

Table 2. z15 Model T02 - Capacity limits and specialty engine limits for permanent upgrades

Model	Available PUs	Active PUs			zIIP	Base SAPs	Opt SAPs	Spare PUs
		CPs	ICF	IFLs / uIFLs				
T02	4	0 - 4	0 - 4	0 - 4/3	0 - 2	2	0 - 2	1
T02	13	0 - 6	0 - 13	0 - 13/12	0 - 7	2	0 - 2	1

Table 2. z15 Model T02 - Capacity limits and specialty engine limits for permanent upgrades (continued)

Model	Available PUs	Active PUs			zIIP	Base SAPs	Opt SAPs	Spare PUs
		CPs	ICF	IFLs / uIFLs				
T02	21	0 - 6	0 - 21	0 - 21/20	0 - 12	3	0 - 2	2
T02	31	0 - 6	0 - 31	0 - 31/30	0 - 12	4	0 - 8	2
T02	65	0 - 6	0 - 65	0 - 65/64	0 - 12	8	0 - 8	2

Table 3. LinuxONE III Model LT2- Capacity limits and specialty engine limits for permanent upgrades

Model	Available PUs	Active PUs			zIIP	Base SAPs	Opt SAPs	Spare PUs
		CPs	ICF	IFLs / uIFLs				
LT2	4	0 - 4	0 - 4	1 - 4 / 0 - 3	0 - 2	2	0 - 2	1
LT2	13	0 - 6	0 - 13	1 - 13 / 0 - 12	0 - 7	2	0 - 2	1
LT2	21	0 - 6	0 - 21	1 - 21 / 0 - 20	0 - 12	3	0 - 2	2
LT2	31	0 - 6	0 - 31	1 - 31 / 0 - 30	0 - 12	4	0 - 8	2
LT2	65	0 - 6	0 - 65	1 - 65 / 0 - 64	0 - 12	8	0 - 8	2

Table 4. z15 Model T01 - Capacity limits and specialty engine limits for permanent upgrades

Model	Available PUs	Active PUs			zIIP	Base SAPs	Opt SAPs	Spare PUs
		CPs	ICF	IFLs / uIFLs				
T01	34	0 - 34	0 - 34	0 - 34/33	0 - 22	4	0 - 8	2
T01	71	0 - 71	0 - 71	0 - 71/70	0 - 46	8	0 - 8	2
T01	108	0 - 108	0 - 108	0 - 108/107	0 - 70	12	0 - 8	2
T01	145	0 - 145	0 - 145	0 - 145/144	0 - 107	16	0 - 8	2
T01	190	0 - 190	0 - 190	0 - 190/189	0 - 126	22	0 - 8	2

Table 5. LinuxONE III Model LT1- Capacity limits and specialty engine limits for permanent upgrades

Model	Available PUs	Active PUs			zIIP	Base SAPs	Opt SAPs	Spare PUs
		CPs	ICF	IFLs / uIFLs				
LT1	34	0 - 34	0 - 34	1 - 34 / 0 - 33	0 - 22	4	0 - 8	2
LT1	71	0 - 71	0 - 71	1 - 71 / 0 - 70	0 - 46	8	0 - 8	2
LT1	108	0 - 108	0 - 108	1 - 108 / 0 - 107	0 - 70	12	0 - 8	2
LT1	145	0 - 145	0 - 145	1 - 145 / 0 - 144	0 - 107	16	0 - 8	2
LT1	190	0 - 190	0 - 190	1 - 190 / 0 - 189	0 - 126	22	0 - 8	2

- The 2:1 zIIP to CP ratio for IBM Z processor configurations applies to permanent upgrade orders. The ratio may be a factor in limiting the number of zIIPs you can order.
- If you increase permanent capacity, you may be taking away from the additional capacity available for CBU.
- If you increase permanent capacity while On/Off CoD resources are active, any active On/Off resources of the same type are used to satisfy the permanent upgrade.

- If you have a leased machine, determine whether you are going to lease the upgrade or purchase the upgrade.
- If your business process requires you to have a purchase order before placing an order, make sure you have the purchase order number ready before placing your order.
- CIU Express is the default method for ordering permanent upgrades. It allows you to place permanent upgrade orders for your machine and have the orders ready for download in a significantly shorter time frame - approximately three hours. The order will be staged until you download or cancel the upgrade record.

When ordering a permanent upgrade, you may optionally choose not to follow the CIU Express method. If you do not use CIU Express, the processing of your order will take significantly longer. In addition, you will only have up to 30 days to download your permanent upgrade record. Notification is sent seven days before the expiration. It is highly recommended that you use the default CIU Express method of processing your upgrade order.

Continue to “How to order an upgrade record” on page 35 for instructions on how to order a permanent upgrade using the CIU application through Resource Link.

Temporary upgrade considerations

This section provides information you should consider before ordering temporary upgrade records.

On/Off CoD considerations

Before you order an On/Off CoD record, consider the following:

- For a single On/Off CoD record,
 - The maximum upgrade for CP capacity is 100% of the **current purchased capacity**. Current purchased capacity (also referred to as the "high water mark" or HWM) includes owned and active permanent capacity and owned and unassigned permanent capacity. (See [Figure 16 on page 32.](#)) Capacity is computed based on processing capacity gained by adding the engines. It is based off the published LSPR values for the configuration.




Figure 16. Maximum CP capacity

- The maximum upgrade allowed for specialty engines is doubling the number of engines.

For example, for an increase in model capacity, if you have a 711, you can activate up to a 727. If you have a 711 with 2 unassigned engines (713 purchased), you would be able to activate up to a 731. For an increase in specialty engines, if you have 6 ICFs, you can add up to 6 more ICFs.

It is recommended that when you order a post-paid On/Off CoD record, you order the maximum capacity and maximum number of specialty engines.

Note: Resource Link will not allow you to order beyond the maximum.

Although it is recommended that you order the maximum capacity and number of specialty engines when you order a On/Off CoD record, there may be reasons when you do not want to maximize. For example, you may:

- Not want all engines available for use.
- Want to prevent certain types of upgrades.
- Want to reactivate just the unassigned capacity (order 0%).

Note: Even though Resource Link displays the high water mark model when you specify 0% when ordering, a 0% On/Off CoD record on a downgraded machine allows you to activate any supported On/Off CoD upgrades to unassigned model capacities between the active permanent configuration and your high water mark.

- By default, an On/Off CoD record is initially available up to 180 days, starting on the date you place your order. After the 180 days, the record will expire unless you "replenish" the record. Replenish allows you to use an existing configuration to either increase your capacity, add specialty engines, or extend the expiration date rather than ordering a new On/Off CoD record.

You can order a replenishment record to manually extend the expiration date or you can enable the automatic renewal function to automatically extend the expiration date of installed records. With the automatic renewal function, a replenishment record is automatically generated 90 days before the record expires. The expiration date on the newly generated replenishment record is set to 180 days

from the date the record was automatically generated, which extends the expiration date 90 days from the previous expiration date.

The automatic renewal function is available on post-paid On/Off CoD records. Automatic renewal requires a Remote Support Facility (RSF) connection.

Refer to [“How to order a replenishment record”](#) on page 54 for instructions describing how to order a replenishment record.

- If you apply a permanent upgrade, by default, any active On/Off CoD resources of the same type are converted to permanent upgrades. If all On/Off CoD resources are consumed by the permanent upgrade, the On/Off CoD record remains active with zero resources allocated. Therefore, after the permanent upgrade is complete, you should deactivate (or Undo) the On/Off CoD record.
- If your business process requires you to have a purchase order before placing an order, make sure you have the purchase order number ready before placing your order.

Continue to [“How to order an upgrade record”](#) on page 35 for instructions how to order an On/Off CoD record using the CIU application through Resource Link.

On/Off CoD test considerations

Before you order an On/Off CoD test record, consider the following:

- There is one free On/Off CoD test allowed for each machine that is registered for On/Off CoD.
- An On/Off CoD test record has a maximum duration of 24 hours. It is automatically deactivated after 24 hours.
- An On/Off CoD test record is deactivated if the number of CPs and the number of specialty engines are set to zero.
- You can order any configuration within the limits of a normal On/Off CoD record.
- You can change activation levels with a On/Off CoD test record.

Administrative On/Off CoD test considerations

Before you order an administrative On/Off CoD test record, consider the following:

- The capacity level is fixed at 0%.
- You can order an administrative On/Off CoD test record that never expires, has an expiration date but is automatically renewed, or needs to be manually replenished within 180 days.

CBU considerations

Before you order a CBU record, consider the following:

- Determine what engines you need to backup.
- Determine whether you need to backup one machine at a time or multiple machines.
- Determine whether you need to backup multiple machines simultaneously.
- When ordering a CBU record, the specialty engines are ordered by quantity and the CP capacity is managed by feature codes.

For CP capacity, you select feature codes to either add engines or increase the engine speed. (See [Figure 17](#) on page 34.)

7xx																	
6xx																	
5xx																	
4xx																	
n-way	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	...

Figure 17. CBU CP feature codes

- A single real activation is available up to 90 consecutive days, starting on the date you activate the CBU record.
- If your business process requires you to have a purchase order before placing an order, make sure you have the purchase order number ready before placing your order.
- When ordering a CBU record, you must specify the length of the contract. The length of the contract can be 1-5 years.
- Each CBU record provides a specific number of free, 10-day test activations. The number of free test activations equates to the number of years that are purchased with the CBU record. (For example, a three year CBU record has three tests activations, a one year CBU record has one test activation.) Additional test activations beyond the free tests may be purchased in single increments up to a maximum of 15 CBU tests per record. This maximum of 15 tests per record cannot be exceeded and includes any free activations plus additional paid test activations.

These test activations are only available for use if the real activation is available. Once the real activation has been used, **all** activations are disabled until the real activation is restored.

- If you want to order more tests or extend the expiration date to an existing record, you can "replenish" the order. Replenishment allows you to use an existing configuration rather than ordering a new CBU record. Refer to ["How to order a replenishment record"](#) on page 54 for detailed instructions.
- The 2:1 zIIP to CP ratio for IBM Z processor configurations applies to CBU record orders. The ratio may be a factor in limiting the number of zIIPs you can order.
- You cannot decrease the capacity level.
- You cannot remove permanent engines from the configuration.

Continue to ["How to order an upgrade record"](#) on page 35 for instructions how to order a CBU record using the CIU application through Resource Link.

CPE considerations

Before you order a CPE record, consider the following:

- This is only one real activation per record.
- There are no test activations.
- A single activation is available for 72 consecutive hours (3 days), starting on the date you activate the CPE record.
- The CIU application allows you to select a model capacity and a number of specialty engines that might exceed the server's available engines. However, when it is time to activate this capacity, you can only activate capacity up the machine's available engines.
- If your business process requires you to have a purchase order before placing an order, make sure you have the purchase order number ready before placing your order.
- The 2:1 zIIP to CP ratio for IBM Z processor configurations applies to CPE record orders. The ratio may be a factor in limiting the number of zIIPs you can order.
- You cannot decrease the capacity level.
- You cannot remove permanent engines from the configuration.

Continue to “[How to order an upgrade record](#)” on page 35 for instructions how to order a CPE record using the CIU application through Resource Link.

System Recovery Boost Upgrade considerations

Before you order a System Recovery Boost Upgrade record, consider the following:

- The machine configuration must include at least one permanent zIIP.
- You can order and install one record per enabled machine.
- You can use the additional zIIPs activated by the record only for a system recovery zIIP boost.
- A logical partition's control program must support the System Recovery Boost function to be able to use additional zIIPs activated by the record.
- The number of available engines in your machine configuration may limit the number of additional zIIPs you can activate with the record.
- The 2:1 zIIP to CP ratio for IBM Z processor configuration is not applicable; the ratio does not limit the additional zIIPs you can activate with the record.

How to order an upgrade record

To order an upgrade record using the CIU application through Resource Link, follow these steps:

1. Sign onto Resource Link.
2. Click **Customer Initiated Upgrade** from the left navigation bar on the main Resource Link page. The **Active machine profiles** page opens. It lists all machines on which you are authorized to create or replenish orders, or on which you are listed as the order approver or viewer.
3. The first column displays the machine type, serial number, and customer number of each machine as a link. Click the link for the desired machine. The **Machine profile** page opens.
4. Depending on the type of upgrade, select from one of the following procedures and follow the steps describing how to order the record:
 - [“Ordering a permanent upgrade” on page 35](#)
 - [“Ordering an On/Off CoD record” on page 37](#)
 - [“Ordering an On/Off CoD test record” on page 39](#)
 - [“Ordering an On/Off CoD record with prepaid upgrades” on page 40](#)
 - [“Ordering an On/Off CoD record with spending limits” on page 44](#)
 - [“Ordering an administrative On/Off CoD test record” on page 48](#)
 - [“Ordering a CBU record” on page 49](#)
 - [“Ordering a CPE record” on page 51](#)

Ordering a permanent upgrade

An authorized orderer can order a permanent upgrade record for a machine from its CIU machine profile page. The order forms are presented as two or three steps, depending on the machine type and profile settings:

1. On the **Machine profile** page, click **Order permanent upgrade**. The **Order permanent upgrade - Step (1 of 2 | 1 of 3): Configure the record** page displays the current configuration and upgrade configuration information.

If the permanent upgrade ordering option is grayed out, the reason will be listed under the Notes in the machine profile **About ordering** section.

Order permanent upgrade

Step 1 of 2: Configure the record

Use this form to order a permanent upgrade. Select the upgrade configuration you want to order then click Continue.

First select the total upgrade configuration you want to order. Then, optionally, select the model capacity and specialty engines you want in the active configuration. Model capacity and specialty engines in the total configuration but not in the active configuration will be unassigned upon installing the upgrade.

	Upgrade configuration			
	Current configuration	Total configuration	Active configuration	Upgrade price
Model Capacity:	730 (30 CPs)	731 (31 CPs)▼	730 (30 CPs)▼	0.00
ICF:	2	3▼	2▼	0.00
zIIP:	5	8▼	5▼	0.00
IFL:	3	5▼	3▼	0.00
SAP:	10	10▼	10	0.00
Memory:	768 GB	768▼		0.00
Total purchase price:				0.00

Continue

2. Two selection columns display upgrade configuration options..

- The **Total configuration** selection list represents the amount of capacity you have purchased on the system. This is sometimes referred to as the "high water mark."
- The **Active configuration** selection list represents the amount of capacity you want active on the system. These selections allow you to unassign model capacity or supported specialty engines by setting the active configuration lower than the total configuration.

The capacity listed in the **Total configuration** field will always be greater than or equal to the capacity listed in the **Active configuration** field.

- a. Select the total upgrade configuration you want to order. For each entry, click the arrow to display the available upgrade values, and select your values.

Note: Only the available upgrade values will display. For example, if you increase the number of CPs in your model capacity value, the number of specialty engines available for you to select will decrease.

- b. Select the model capacity and specialty engines you want in the *active* configuration. Remember, you do not have to specify all your total model capacity or total specialty engines in the active configuration. By setting the active configuration lower than the total configuration, model capacity and specialty engines not in the active configuration will be unassigned when you install the upgrade.
- c. If a price agreement was not negotiated for this machine, the **Total purchase price** displays the value **Not Negotiated**. While you can submit the order without a price, it will not be staged until a price is set. Contact your IBM sales representative to negotiate the price agreement. Once the price is set, you will be notified to return to Resource Link to accept the price.

Click Continue after selecting the upgrade configuration.

3. The **Order permanent upgrade - Step 2 of 3: Select order options** page opens if the machine supports or requires setting options for CIU Express leasing or a purchase order.

Set the options applicable to your order:

- a. Select the order method (CIU Express: Yes or No). By default, CIU Express is enabled (Yes) for a machine, unless indicated otherwise in the contract, to enable retrieving a permanent upgrade record order from the support system within approximately three hours after it is ordered.
- b. If the machine is a leased machine, enter the lease information
- c. If your company requires a purchase order and requires approval for the order, you can enter the purchase order number and amount on this page or after the order is submitted, or the approver can enter the purchase order number and amount. You or the approver can optionally attach a copy of the purchase order.

If your company requires a purchase order and does not requires approval for the order, you must enter the purchase order number and amount on this page. You can optionally attach a copy of the purchase order.

- d. Click **Continue** after setting the order options.
4. On the **Order permanent upgrade - Step (2 of 2 | 3 of 3) : Review and submit your order** page, verify the information is correct and read the terms of the order. If you accept the terms, click **I accept the Terms and Conditions of this order** and click **Submit** to order the record.
5. The order is created. If subsequent order processing actions are necessary, such as setting the order price or approving the order, Resource Link sets the order status accordingly and notifies the responsible party by email. The record will be staged on the support system for download after all subsequent order processing actions are completed by the responsible parties.

Ordering an On/Off CoD record

An authorized orderer can order an On/Off CoD record for a machine from its CIU machine profile page:

1. Click **Order On/Off CoD record**. The **Order On/Off CoD record Step 1 of 2: Configure the record** page opens.

Order On/Off CoD record

Step 1 of 2: Configure the record

The On/Off CoD upgrade options on this order form are initialized to the maximum selections for upgrades that have prices set for this machine. Maximizing selections creates an On/Off CoD record that supports the widest possible range of On/Off CoD upgrades for the current machine configuration. Adjust the selections only if you want to change the type or range of On/Off CoD upgrades that can be activated with this record.

(*) indicates setting an expiration date is required to continue. Its initial setting is the maximum date allowed.

Expiration date:*

11/01/2022

Renew automatically

Date format: mm/dd/yyyy

Enable upgrades for up to:

Model capacity:

100% ▾

more model capacity

ICF:

3 ▾

more ICF engines

zIIP:

8 ▾

more zIIP engines

IFL:

5 ▾

more IFL engines

SAP:

8 ▾

more SAP engines

Continue

- For upgrades that have prices set for this machine, the maximum selections are automatically initialized and displayed. Maximizing the selections creates an On/Off CoD capacity record that supports the widest possible range of On/Off CoD upgrades for the current machine configuration.

If the prices are not negotiated yet, the upgrade value for the model capacity displays 0% and the upgrade value of each specialty engines displays 0. You can still select a value, however, before the order can be approved the price must be negotiated.

Note: For model capacity, 100% means when you will be doubling your existing capacity (not doubling the number of engines).

To view the supported upgrades, click **Show upgrades**. If prices have been set for this machine, you can view the supported upgrades and their prices by clicking **Show upgrade prices**. These tables list the supported model capacities and their relative capacity as a percentage of the current capacity.

The expiration date and automatic renewal option also display. (The automatic renewal option only displays on this initial **Order On/Off CoD record** page. It does not display when you order a replenishment record.) By default, an On/Off CoD record is initially available up to 180 days, starting

on the date you place your order. After the 180 days, the record will expire unless you replenish (renew) the record. You can automatically renew an installed record by enabling the automatic renewal function. (This is the default setting.) If you do not want the automatic renewal function enabled, deselect the **Renew automatically** checkbox. Then you must manually order replenishment records to extend the expiration date.

3. For each entry, click the arrow to select your upgrade values. Then click **Continue**. The **Order On/Off CoD record (Step 2 of 2)** page displays the values you entered along with the upgrade daily prices (if the prices were negotiated). The order description field will help identify this order in the staged orders listed on the Support Element. (You can change the description.)
4. On the **Order On/Off CoD record (Step 2 of 2)** page, read the terms and conditions.
5. If you are ready to accept, check **I accept the Terms and Conditions of this order** and click **Submit**.
6. The **On/Off CoD record order** page opens. Your record is now ordered and this page displays all the information about the record. This information includes the status of the order, the description, the expiration date, and the capacity upgrades you selected.

If the order price is not negotiated, the status is **Needs price agreement**. This means an order was created without a prenegotiated agreement in place. Contact your sales representative to negotiate a price agreement. Once the price is set, you will be notified to return to Resource Link to accept the price.

The order cannot be approved until the price has been negotiated and accepted.

7. When the order has been approved and is ready to be retrieved, the order status is **Download ready**. (You will also receive an email informing you that your upgrade record is "Download ready.")
8. Now your order can now be retrieved, installed, and activated through the Support Element.

As the order is retrieved, installed, and activated, the status will be reflected on the **Machine profile** page. For a list of possible status definitions, click **Order status definitions** located on the right navigation pane.

Ordering an On/Off CoD test record

Complete the steps under [“How to order an upgrade record”](#) on page 35 before you perform the following steps.

1. On the **Machine profile** page, check the Notes section to make sure a test record is available to order.
2. Click **Order On/Off CoD test record**. The **Order On/Off CoD test record (Step 1 of 2)** page opens.
3. For upgrades that have prices set for this machine, the maximum selections are automatically initialized and displayed. Maximizing the selections creates an On/Off CoD capacity test record that supports the widest possible range of On/Off CoD upgrades for the current machine configuration.

If the prices are not negotiated yet, the upgrade value for the model capacity displays 0% and the upgrade value of each specialty engines displays 0. You can still select a value, however, before the order can be approved the price must be negotiated.

Note: For model capacity, 100% means when you will be doubling your existing capacity (not doubling the number of engines).

To view the supported upgrades, click **Show upgrades**. If prices have been set for this machine, you can view the supported upgrades and their prices by clicking **Show upgrade prices**. These tables lists the supported model capacities and their relative capacity as a percentage of the current capacity.

For a test record, you have a maximum duration of 24 hours.

4. For each entry, click the arrow to select your upgrade values. Then click **Continue**. The **Order On/Off CoD test record (Step 2 of 2)** page displays the values you entered along with the upgrade daily prices (if the prices were negotiated). The order description field will help identify this order in the staged orders listed on the Support Element. (You can change the description.)
5. On the **Order On/Off CoD test record (Step 2 of 2)** page, read the terms and conditions.
6. If you are ready to accept, check **I accept the Terms and Conditions of this order** and click **Submit**.

7. The **On/Off CoD test order** page opens. Your record is now ordered and this page displays all the information about the record . This information includes the status of the order, the description, and the capacity upgrades you selected.

Note: A test record is activated for a 24 hour period. It is deactivated automatically. Although you may see prices listed, you will incur no hardware or software costs during this 24 hours period. The main reason for ordering a test record is to validate that the complete order, retrieve, install, activate, and deactivate On/Off CoD capacity upgrade process performs nondisruptively. This includes viewing the prices.

If the order price is not negotiated, the status is **Needs price agreement**. This means an order was created without a prenegotiated agreement in place. Contact your sales representative to negotiate a price agreement. Once the price is set, you will be notified to return to Resource Link to accept the price.

The order cannot be approved until the price has been negotiated and accepted.

8. When the order has been approved and is ready to be retrieved, the order status is **Download ready**. (You will also receive an email informing you that your upgrade record is "Download ready.")
9. Now your order can now be retrieved, installed, and activated through the Support Element.

As the order is retrieved, installed, and activated, the status will be reflected on the **Machine profile** page. For a list of possible status definitions, click **Order status definitions** located on the right navigation pane.

Ordering an On/Off CoD record with prepaid upgrades

An authorized orderer can order an On/Off CoD record with prepaid upgrades for a machine from its CIU machine profile page:

1. Click **Order On/Off CoD record with prepaid upgrades**. The **Order On/Off CoD record - Step 1 of 3: Configure the record** page opens.

Order On/Off CoD record

Step 1 of 3: Configure the record

The On/Off CoD upgrade options on this order form are initialized to the maximum selections for upgrades that have prices set for this machine. Maximizing selections creates an On/Off CoD record that supports the widest possible range of On/Off CoD upgrades for the current machine configuration. Adjust the selections only if you want to change the type or range of On/Off CoD upgrades that can be activated with this record.

Expiration date:* Renew automatically
Date format: mm/dd/yyyy

Enable upgrades for up to:

Model capacity:	<input type="text" value="100%"/>	more model capacity
ICF:	<input type="text" value="3"/>	more ICF engines
zIIP:	<input type="text" value="8"/>	more zIIP engines
IFL:	<input type="text" value="5"/>	more IFL engines
SAP:	<input type="text" value="8"/>	more SAP engines

- For upgrades that have prices set for this machine, the maximum selections are automatically initialized and displayed. Maximizing the selections creates an On/Off CoD capacity record that supports the widest possible range of On/Off CoD upgrades for the current machine configuration. It is recommended to keep the maximum values on this page. Then you will have a wider selection of prepaid upgrades to add to your order. The values you choose on this page determines the values displayed in the pulldown menus on the next page.

If the prices are not negotiated yet, the upgrade value for the model capacity displays 0% and the upgrade value of each specialty engines displays 0. You can still select a value, however, before the order can be approved the price must be negotiated.

Note: For model capacity, 100% means when you will be doubling your existing capacity (not doubling the number of engines).

To view the supported upgrades, click **Show upgrades**. If prices have been set for this machine, you can view the supported upgrades and their prices by clicking **Show upgrade prices**. These tables lists the supported model capacities and their relative capacity as a percentage of the current capacity.

For each entry, select your upgrade values. Click **Continue**. The **Order On/Off CoD record - Step 2 of 3: Add prepaid upgrades** page opens.

Order On/Off CoD record

Step 2 of 3: Add prepaid upgrades

Use this form to add prepaid upgrades to your On/Off CoD record order. You can order up to 50 prepaid upgrades per record. Repeat these steps for each prepaid upgrade you want to order:

1. Select an upgrade.
2. Enter the number of days you want to use the selected upgrade.
3. Click the "Add to order" link for the selected upgrade.

	Upgrade configuration	Price per day	Days of use	
Model capacity:	<input type="text" value="730 (30 CPs)"/>	-	<input type="text"/>	→ Add to order
ICF:	<input type="text" value="3"/>	-	<input type="text"/>	→ Add to order
zIIP:	<input type="text" value="8"/>	-	<input type="text"/>	→ Add to order
IFL:	<input type="text" value="5"/>	-	<input type="text"/>	→ Add to order
SAP:	<input type="text" value="10"/>	-	<input type="text"/>	→ Add to order

The selected prepaid upgrade has been removed from this order.

Prepaid upgrades

Upgrade configuration	Days of use	Tokens	Price
-	-	-	0.00
Total price			0.00

3. For each entry (model capacity or engine type), following these steps:

Note: You must add one upgrade at a time to your order.

- a. Click the arrow to display the pulldown menu, and select your upgrade value. The price (if negotiated) automatically displays in the **Price per day** field. If the price is not negotiated, you can still select a value; however, before the order can be approved, the price must be negotiated.

Note: Remember, the values listed in the pulldown menus on this page are based on the values you selected on the previous page.

- b. Select the number of days you want to use this upgrade.
- c. Click **Add to order**. The information displays in the **Prepaid upgrades** table. This table displays information about each upgrade you selected. This information includes: the upgrade configuration you selected, the number of days for each upgrade, the number of tokens for each upgrade, and the price of each upgrade. It also displays the total price of all the upgrades you selected for this order.

Note: You are not limited to activating the exact upgrades you order. You can order what you estimate you will use, but you can activate whatever you need within the limits of the tokens.

For example, if you first select 732 (32 CPs) from the Model capacity pulldown menu for three days use, and then select 8 from the IFL pulldown menu for two days of use, a **Prepaid upgrades** table similar to the following displays:

Prepaid upgrades

Upgrade configuration	Days of use	Tokens	Price	
732 (32 CPs)	3	459	48,291.48	[Remove]
8 IFLs	2	6	3,666.66	[Remove]
Total price			51,958.14	

[Continue](#)

- d. If you want to remove any upgrade before continuing, next to the appropriate upgrade configuration in the **Prepaid upgrades** table, select **Remove**. The total price is automatically adjusted.
 - e. Once you are finished adding the prepaid upgrades to your order, click **Continue**. The **Order On/Off CoD record - Step 3 of 3: Review and submit your order** page opens.
4. Review the upgrades you selected. You can display the data in the Prepaid upgrade table two ways: by upgrade configuration (shown in the previous step) or by upgrade type (shown as follows).

Prepaid upgrades

[By configuration](#) | [By type](#)

Upgrade type	Price	New tokens	Total tokens
Model capacity	48,291.48	<u>459</u>	<u>459</u>
ICF	0.00	0	0
zIIP	0.00	0	0
IFL	3,666.66	6	6
SAP	0.00	0	0
Total price	51,958.14		

Note: Prepaid upgrades are represented on On/Off CoD records by tokens. Upon installing this order, the record will have the total tokens shown above.

Click on the number of tokens listed for Model capacity (in our example, 459), to display a table that lists the various configurations you can activate with the number of tokens available.

If you need to make any changes or remove any upgrades, go back to the **Step 2 of 3: Add prepaid upgrades** page and make any corrections.

The **Description** field will help identify this order in the staged orders listed on the Support Element. You can change the description.

5. On the **Order On/Off CoD record (Step 3 of 3)** page, read the terms and conditions.
6. If you are ready to accept, check **I accept the Terms and Conditions of this order** and click **Submit**.
7. The **On/Off CoD record order** page opens. Your record is now ordered and this page displays all the information about the record. This information includes the status of the order, the description, and the capacity upgrades you selected.

If the order price is not negotiated, the status is **Needs price agreement**. This means an order was created without a prenegotiated agreement in place. Contact your sales representative to negotiate a price agreement. Once the price is set, you will be notified to return to Resource Link to accept the price.

The order cannot be approved until the price has been negotiated and accepted.

8. When the order has been approved and is ready to be retrieved, the order status is **Download ready**. (You will also receive an email informing you that your upgrade record is "Download ready.")
9. Now your order can now be retrieved, installed, and activated through the Support Element.

As the order is retrieved, installed, and activated, the status will be reflected on the **Machine profile** page. For a list of possible status definitions, click **Order status definitions** located on the right navigation pane.

Ordering an On/Off CoD record with spending limits

An authorized orderer can order an On/Off CoD record with spending limits for a machine from its CIU machine profile page:

1. Click **Order On/Off CoD record with spending limits**. The **Order On/Off CoD record - Step 1 of 3: Configure the record** page opens.

Order On/Off CoD record

Step 1 of 3: Configure the record

The On/Off CoD upgrade options on this order form are initialized to the maximum selections for upgrades that have prices set for this machine. Maximizing selections creates an On/Off CoD record that supports the widest possible range of On/Off CoD upgrades for the current machine configuration. Adjust the selections only if you want to change the type or range of On/Off CoD upgrades that can be activated with this record.

(*) indicates setting an expiration date is required to continue. Its initial setting is the maximum date allowed.

Expiration date:*

11/05/2022

Renew automatically

Date format: mm/dd/yyyy

Enable upgrades for up to:

Model capacity:

100%▼

more model capacity

ICF:

2▼

more ICF engines

zIIP:

10▼

more zIIP engines

IFL:

20▼

more IFL engines

SAP:

8▼

more SAP engines

Continue

2. For upgrades that have prices set for this machine, the maximum selections are automatically initialized and displayed. Maximizing the selections creates an On/Off CoD capacity record that supports the widest possible range of On/Off CoD upgrades for the current machine configuration. It is recommended to keep the maximum values on this page. Then on the next page, you will have a wider selection of upgrades to add to your order.

If the prices are not negotiated yet, the upgrade value for the model capacity displays 0% and the upgrade value of each specialty engines displays 0. You can still select a value, however, before the order can be approved the price must be negotiated.

Note: For model capacity, 100% means when you will be doubling your existing capacity (not doubling the number of engines).

To view the supported upgrades, click **Show upgrades**. If prices have been set for this machine, you can view the supported upgrades and their prices by clicking **Show upgrade prices**. These

tables lists the supported model capacities and their relative capacity as a percentage of the current capacity.

The expiration date and automatic renewal option also display. (The automatic renewal option only displays on this initial **Order On/Off CoD record** page. It does not display when you order a replenishment record.) By default, an On/Off CoD record is initially available up to 180 days, starting on the date you place your order. After the 180 days, the record will expire unless you replenish (renew) the record. You can automatically renew an installed record by enabling the automatic renewal function. (This is the default setting.) If you do not want the automatic renewal function enabled, deselect the **Renew automatically** checkbox. Then you must manually order replenishment records to extend the expiration date.

3. For each entry, select your upgrade values. Click **Continue**. The **Order On/Off CoD record - Step 2 of 3: Set spending limits** page opens.

Order On/Off CoD record

Step 2 of 3: Set spending limits

Use this form to set spending limits on this record. You can set a spending limit on each type of upgrade this record can be used to activate. Setting a spending limit on an upgrade will configure this record to support activating upgrade configurations with daily prices within the spending limit. Then:

- Each activation of an upgrade spends a portion of its spending limit.
- How much is spent depends on the size of the upgrade and how long it is activated.
- You can continue using the record to activate upgrades as long as the daily price of at least one upgrade configuration is within the unspent portion of its spending limit.

Set spending limits in whole numbers only (for example: 500000).

	Upgrades enabled up to:	Spending limit:
Model capacity:	100% more model capacity	<input type="text" value="0"/>
ICF:	2 more ICF engines	<input type="text" value="0"/>
zIIP:	10 more zIIP engines	<input type="text" value="0"/>
IFL:	20 more IFL engines	<input type="text" value="0"/>
SAP:	8 more SAP engines	<input type="text" value="0"/>

Continue

4. In the **Limit spending to:** field, identify the maximum amount you want to spend for the model capacity upgrade and each engine upgrade.

The spending limit must be entered in whole numbers. For example, suppose you want to set a spending limit of \$50,000.00 for model capacity upgrades and \$6000.00 for SAP engines. In the **Limit spending to:** field, enter 50000 and 6000, respectively.

Once you are finished entering and reviewing the data, click **Continue**. The **Order On/Off CoD record Step 3 of 3: Review and submit your order** page opens.

- After you select your upgrade values and your spending limit for each upgrade, Resource link calculates the maximum number of tokens so the cost of any upgrades that consume all these tokens will not exceed the spending limit. This information is displayed in the **Spending limits by upgrade type** table.

Spending limits by upgrade type

Upgrade type	Spending limit	New tokens	Total tokens
Model capacity	50,000.00	<u>357</u>	<u>357</u>
ICF	0.00	0	0
zIIP	0.00	0	0
IFL	0.00	0	0
SAP	6,000.00	3	3
Total spending limit	56,000.00		

Note: Spending limits are represented on On/Off CoD records by tokens. Upon installing this order, the record will have the total tokens shown above.

For model capacity upgrades, if you click on the number of tokens identified in the **New tokens** or **Total tokens** column, the **On/Off CoD tokens** page opens. Based on the monetary amount identified on the **Order On/Off CoD record (Step 2 of 3)** page, the information in this page identifies the number of tokens needed per day and the corresponding maximum number of days allowed for each available model capacity level. The available model capacity levels listed is determined by the model capacity percentage you identified on the **Order On/Off CoD record (Page 1 of 3)** page.

For specialty engines, the table displays the number of available tokens based on the number of engines identified on the **Order On/Off CoD record (Page 1 of 3)** page and the monetary amount identified on the **Order On/Off CoD record (Page 2 of 3)** page.

Review the upgrades and spending limits you selected. If you need to make any changes or remove any upgrades, go back to the previous pages and make any corrections.

The **Description** field will help identify this order in the staged orders listed on the Support Element. You can change the description.

- On the **Order On/Off CoD record (Step 3 of 3)** page, read the terms and conditions.
- If you are ready to accept, check **I accept the Terms and Conditions of this order** and click **Submit**.
- The **On/Off CoD record order** page opens. Your record is now ordered and this page displays all the information about the record. This information includes the status of the order, the description, the expiration date, and the tokens for the spending limit.

If the order price is not negotiated, the status is **Needs price agreement**. This means an order was created without a prenegotiated agreement in place. Contact your sales representative to negotiate a price agreement. Once the price is set, you will be notified to return to Resource Link to accept the price.

The order cannot be approved until the price has been negotiated and accepted.

- When the order has been approved and is ready to be retrieved, the order status is **Download ready**. (You will also receive an email informing you that your upgrade record is "Download ready.")
- Now your order can now be retrieved, installed, and activated through the Support Element.

As the order is retrieved, installed, and activated, the status will be reflected on the **Machine profile** page. For a list of possible status definitions, click **Order status definitions** located on the right navigation pane.

Ordering an administrative On/Off CoD test record

Complete the steps under “How to order an upgrade record” on page 35 before you perform the following steps.

- On the **Machine profile** page, click **Order administrative On/Off CoD test record**. The **Order administrative On/Off CoD test record (Step 1 or 2)** page opens.

Order administrative On/Off CoD test record

Step 1 of 2: Configure the record

The On/Off CoD upgrade options for this administrative test are fixed at 0.

(*) indicates setting an expiration date is required to continue. Its initial setting is the maximum date allowed.

Expiration date:*

11/05/2022

Record does not expire

Date format: mm/dd/yyyy

Renew automatically

Enable upgrades for up to:

Model capacity:	0% more model capacity
ICF:	0 more ICF engines
zIIP:	0 more zIIP engines
IFL:	0 more IFL engines
SAP:	0 more SAP engines

Continue

- Replenishment information also displays. This includes the expiration date field, the option to enable automatic renewal for the record, and the option to set no expiration date for the record.

By default, the test record is initially available up to 180 days, starting on the date you place your order. After the 180 days, the record will expire unless you replenish (renew) the record or set no expiration date. You can automatically renew an installed record by enabling the automatic renewal function. (This is the default setting.) If you do not want the automatic renewal function enabled, deselect the **Renew automatically** checkbox. Then you must manually order replenishment records to extend the expiration date.

The options to enable automatic renewal or to set no expiration date only display on this initial **Order administrative On/Off CoD test record** page. They do not display when you order a replenishment record. Also, if you select **Record does not expire**, you will not be able to order a replenishment record because there is nothing to replenish.

3. Click **Continue**. The **Order administrative On/Off CoD test record (Step 2 of 2)** page displays. The order description field will help identify this order in the staged orders listed on the Support Element. (You can change the description.)
4. Read the terms and conditions.
5. If you are ready to accept, check **I accept the Terms and Conditions of this order** and click **Submit**.
6. The **On/Off CoD admin test record order** page opens. Your record is now ordered and this page displays all the information about the record. This information includes the status of the order, the description, the expiration date, and the replenishment automatic renewal status.
7. When the order has been approved and is ready to be retrieved, the order status is **Download ready**. (You will also receive an email informing you that your upgrade record is "Download ready.")
8. Now your order can now be retrieved, installed, and activated through the Support Element.

As the order is retrieved, installed, and activated, the status will be reflected on the **Machine profile** page. For a list of possible status definitions, click **Order status definitions** located on the right navigation pane.

Ordering a CBU record

An authorized orderer can order a Capacity Backup (CBU) record for a machine from its CIU machine profile page:

1. Click **Order Capacity Backup (CBU) record**. The **Order Capacity Backup record - Step 1 of 2: Configure the record** page opens.

Order Capacity Backup record

Step 1 of 2: Configure the record

Use this form to order a Capacity Backup (CBU) record and contract:

1. Select the maximum additional model capacity and specialty engines that can be activated with this record.
2. Select the contract length (how long you want to use the record).
3. Your order includes one (1) CBU test for each year of the CBU contract. Optionally, select whether you want to purchase additional tests, up to a total of 15 tests for the record.
4. Your order includes one (1) real activation (ie. activation of backup capacity for up to 90 days).

		Enable backup capacity for up to:	Price per year
Model capacity:		730 (30 CPs) <input type="text"/> : 0 feature codes	0.00
ICF:		0 <input type="text"/> more ICF engines	0.00
zIIP:		0 <input type="text"/> more zIIP engines	0.00
IFL:		0 <input type="text"/> more IFL engines	0.00
SAP:		0 <input type="text"/> more SAP engines	0.00
Subtotal price per year:			0.00
CBU contract	Length:	5 <input type="text"/> years	x 5
Subtotal price:			0.00
	Tests included with contract:	+ 5	0.00
CBU tests	Additional tests:	+ 0 <input type="text"/>	0.00
	Total tests:	5	
New CBU record price (includes 1 real activation) :			25,000.00
Total price:			25,000.00

[Continue](#)

2. Select the model capacity and the number of specialty engines you need. Based on the model capacity you selected, the number of feature codes to be ordered will display in the entry field.

Select the contract length - 1 to 5 years. Each CBU record provides one free, 10-day test for every year purchased with the CBU record.

Optionally, select the number of additional test activations (for a fee). A maximum of 15 tests per record cannot be exceeded. This includes any free test activations plus additional paid test activations.

3. Click **Continue**. The **Order Capacity Backup record (Step 2 of 2)** page displays the values you entered along with the price per year (if the prices were negotiated). The order description field will help identify this order in the staged orders listed on the Support Element. (You can change the description.)
4. Read the terms and conditions.
5. If you are ready to accept, check **I accept the Terms and Conditions of this order** and click **Submit**.
6. The **Capacity Backup record order** page opens. Your record is now ordered and this page displays all the information about the record . This information includes the status of the order, the description, and the capacity upgrades you selected.

If the order price is not negotiated, the status is **Needs price agreement**. This means an order was created without a prenegotiated agreement in place. Contact your sales representative to negotiate a price agreement. Once the price is set, you will be notified to return to Resource Link to accept the price.

The order cannot be approved until the price has been negotiated and accepted.

7. When the order has been approved and is ready to be retrieved, the order status is **Download ready**. (You will also receive an email informing you that your upgrade record is "Download ready.")
8. Now your order can now be retrieved, installed, and activated through the Support Element.

As the order is retrieved, installed, and activated, the status will be reflected on the **Machine profile** page. For a list of possible status definitions, click **Order status definitions** located on the right navigation pane.

Ordering a CPE record

An authorized orderer can order a Capacity for Planned Events (CPE) record for a machine from its CIU machine profile page:

1. Click **Order Capacity for Planned Events (CPE) record**. The **Order Capacity for Planned Events record - Step 1 of 2: Configure the record** page opens.

Order Capacity for Planned Events record

Step 1 of 2: Configure the record

Use this form to order a Capacity for Planned Events (CPE) record.

Select the maximum additional model capacity and specialty engines that can be activated with this record for up to 3 days.

	Enable capacity for up to:	Price
Model capacity:	<input type="text" value="730 (30 CPs)"/> : 0 CP 0 CLI	0.00
ICF:	<input type="text" value="0"/> more ICF engines	0.00
zIIP:	<input type="text" value="0"/> more zIIP engines	0.00
IFL:	<input type="text" value="0"/> more IFL engines	0.00
SAP:	<input type="text" value="0"/> more SAP engines	0.00
Total price:		0.00

Continue

2. Select the model capacity and the number of specialty engines you need. The CIU application allows you to select a model capacity and number of specialty engines that might exceed the server's available engines. However, you will only be able to activate capacity up to the server's available engines. It can be activated for up to 72 hours (3 days).
3. Click **Continue**. The **Order Capacity for Planned Events record - Step 2 of 2: Review and submit your order** page opens.
4. Read the terms and conditions.
5. If you are ready to accept, check **I accept the Terms and Conditions of this order** and click **Submit**.
6. The **Capacity for Planned Events record order** page opens. Your record is now ordered and this page displays all the information about the record. This information includes the status of the order, the description, and the total price (or not negotiated).

If the order price is not negotiated, the status is **Needs price agreement** and the total price is **Not negotiated**. Contact your sales representative to negotiate a price agreement. Once the price is set, you will be notified to return to Resource Link to accept the price.

The order cannot be approved until the price has been negotiated and accepted.

7. When the order has been approved and is ready to be retrieved, the order status is **Download ready**. (You will also receive an email informing you that your upgrade record is "Download ready.")
8. Now your order can now be retrieved, installed, and activated through the Support Element.

As the order is retrieved, installed, and activated, the status will be reflected on the **Machine profile** page. For a list of possible status definitions, click **Order status definitions** located on the right navigation pane.

Ordering a System Recovery Boost Upgrade record

To order a System Recovery Boost Upgrade record, open the machine profile page on Resource Link (see "How to order an upgrade record" on page 35), go to the **Ordering options** link list, and click **Order System Recovery Boost Upgrade record**. Then follow the instructions on the subsequent order forms to:

1. Configure the record
2. Review and submit the order.


There is an additional step if your enterprise requires a Purchase Order (PO) for the record order. After you configure the record (step 1), an additional order form is displayed for you to provide the PO information.

Configure the record

Configuring the record is the first step in ordering a new System Recovery Boost Upgrade record. This step's order form displays the record configuration you can order for your machine. A standard record is configured with:

- 30 activations, of up to 20 additional zIIPs, for up to six hours per activation
- Automatic activation token replenishment enabled.

The record subscription length (ie. how long you can use the record) is configurable, and is a factor in computing the record price. Select the subscription length you want for your record, in one year increments, from one to five years. If your machine is eligible for a free 90 day trial record, select zero (0) years to order the trial record:



The screenshot shows a form element for selecting the subscription length. It consists of a rectangular box with a light gray background. On the left side, the text "Record subscription" is displayed in a bold, dark font. To the right of this text, the word "Length:" is centered. Further to the right, there is a dropdown menu showing the number "1" with a downward-pointing chevron symbol. To the right of the dropdown menu, the word "years" is displayed. A hand cursor icon is positioned over the dropdown menu, indicating it is interactive.

Figure 18. System Recovery Boost Upgrade record order form subscription length selection

Automatic activation token replenishment is a service that automatically orders, downloads, and installs replenishment records to restore an installed record's activation tokens. The service is enabled by default to better maintain an ongoing supply of tokens for the record.

Optionally, consider disabling automatic activation token replenishment only if you prefer to order replenishment records manually to restore activation tokens. To disable automatic activation token replenishment for a new record order, unmark its checkbox on the order form:



The screenshot shows a form element for configuring automatic activation token replenishment. It consists of a rectangular box with a light gray background. On the left side, the text "Activations:" is displayed in a bold, dark font, followed by the number "30". To the right of this text, there is a checkbox that is currently unchecked. To the right of the checkbox, the text "Replenish activations automatically" is displayed in a dark font. A hand cursor icon is positioned over the checkbox, indicating it is interactive.

Figure 19. System Recovery Boost Upgrade record order form with automatic activation token replenishment disabled

Review and submit the order

Reviewing and submitting the order is the last step in ordering a new System Recovery Boost Upgrade record. Use this step's order form to:

- Review the record configuration and total price
- Edit the record description (optional)
- Accept the Terms and Conditions of the order (required)
- Submit the order.

If System Recovery Boost Upgrade record pricing has been set up in advance for your machine, the order's total price is set accordingly. Otherwise, if pricing is not available, the total price is not set and is displayed instead as "not negotiated". But you can still submit your order. An IBM pricing team will be notified about setting its price.

The order's default record description summarizes the record configuration. Optionally you can edit it if you prefer to describe the record differently. Record details shown on Resource Link pages and support element Perform Model Conversion windows (after the record is installed) typically include the record description.

Accepting the Terms and Conditions of the order is required to submit it. Mark the I accept checkbox then click Submit to submit the order.

There is no charge for ordering a System Recovery Boost Upgrade record. You are billed for the record upon downloading it.

Order processing and status

After you submit a record order, subsequent order processing makes the record ready to download. But it may require you or others to take action to support and continue order processing. Resource Link notifies you and others to take action via email. Use the record order page on the Resource Link to take any required action and to monitor the order status:

- **Needs price agreement** indicates the order price is not set and an IBM pricing team was notified to set the order price.
- **Needs customer approval** indicates an IBM pricing team set the order price, your machine's authorized orderers were notified, and any one orderer must approve the order price.
- **Needs secondary approval** indicates your machine's authorized order approvers were notified and any one order approver must approve the order.
- **Needs BP admin approval** indicates you will be billed for the order by an IBM Business Partner, and the Business Partner was notified to approve the order.

Resource Link likewise notifies you via email when order processing has completed and your record is ready to download. The record order page on the Resource Link displays the order status:

- **Staging order** indicates IBM's automated process for making the record ready to download is in progress. This process typically is completed within an hour. No action is required by you or others.
- **Download ready** indicates order processing has completed and the record is ready for you to download.

How to order a replenishment record

You can modify (replenish) On/Off CoD records for upgrades without spending limits, On/Off CoD records for prepaid upgrades, On/Off CoD records for upgrades with spending limits, administrative On/Off CoD test record, and CBU records. Ordering a replenishment record allows you to use an existing On/Off CoD or CBU record to increase the limits for currently active orders without having to replace the record.

When ordering an On/Off CoD replenishment record (other than an administrative On/Off CoD test replenishment record), you can add processing resources and extend expiration date.

When ordering an administrative On/Off CoD test replenishment record, you can only modify the replenishment expiration date. When initially ordering an administrative On/Off CoD test record, if you selected the **Record does not expire** option, you will not have the ability to replenish the record because the record will not expire.

When ordering a CBU replenishment record, you can add processing resources, extend expiration date, restore real activation and order more tests. If you add processing resources or extend the expiration date to an active CBU, these changes are made immediately available without having to deactivate and reactivate an active CBU. However, to extend a real activation, you need to deactivate the CBU real activation you are using, and then activate the CBU real again. This is also true for test CBU activations; you cannot extend a test with another test, you must deactivate in between.

For On/Off CoD records, in addition to manually ordering a replenishment record to extend the expiration date, you can also automatically renew an installed record by enabling the automatic renewal function. (This is the default setting.) You can enable or disable the automatic renewal function for an On/Off CoD record at any time from the **On/Off CoD record** page. Manually ordering a replenishment record will block the generation of automatic renewal records until the manually generated record has been cancelled or applied.

There are eight slots available for installed or active upgrade records. When you order a replenishment record, you are using the same slot for the order you are replenishing. If you ordered a completely new record, you would have to wait for an open slot if all were taken.

You can only increase a machines model capacity or processors when ordering a replenishment record. You cannot decrease the entitlement level for an existing offering.

An authorized orderer can order replenishment records from a machine's Capacity on Demand record pages.

To replenish an On/Off CoD record, follow these steps:

1. In the **Capacity on Demand records** section on the **Machine profile** page, click the record number you want to replenish. The **On/Off CoD record** page opens.

Capacity on Demand records

Open orders		All orders	
Record number · type · install state			
Order number	Order status	Order description	
<u>CBBY9JJM</u> · CBU · Installed			
<u>CXBY9RNW</u>	· Ordered 15 Feb 2021 · Installed	+2 FCs model capacity, +0 ICF, +0 zIIP, +0 IFL, +0 SAP	
<u>CRBYHRSW</u> · On/Off CoD · Installed			
<u>CXBYHRSW</u>	· Ordered 23 Feb 2021 · Installed	+100% model capacity, +2 ICF, +10 zIIP, +20 IFL, +8 SAP	

The **On/Off CoD record** page opens.

2. Click **Order a replenishment record**. The **Order On/Off CoD record (Step 1 of 3)** page opens.

3. For the remaining steps, continue to one of the following:
 - For On/Off CoD record upgrade without spending limits, go to [“2” on page 38](#)
 - For On/Off CoD record with prepaid upgrade, go to [“2” on page 41](#)
 - For On/Off CoD record upgrade with spending limits, go to [“2” on page 45](#)
 - For administrative On/Off CoD test record, go to [“2” on page 48](#).

To replenish a CBU record, follow these steps:

1. In the **Capacity on Demand records** section on the **Machine profile** page, click the CBU record number you want to replenish.

Capacity on Demand records

Open orders		All orders	
Record number · type · install state			
Order number	Order status	Order description	
CBBY9JJM · CBU · Installed			
CXBY9RNW	· Ordered 15 Feb 2021 · Installed	+2 FCs model capacity, +0 ICF, +0 zIIP, +0 IFL, +0 SAP	
CRBYHRSW · On/Off CoD · Installed			
CXBYHRSW	· Ordered 23 Feb 2021 · Installed	+100% model capacity, +2 ICF, +10 zIIP, +20 IFL, +8 SAP	

The **Capacity Backup record** page opens.

2. There are two types of CBU replenishment records from which you can choose:

- **Order more backup capacity or more CBU tests**

This choice allows you to select the maximum additional model capacity and specialty engines that can be activated with this record. In addition, you can select whether you want to purchase additional CBU test activations, up to a total of 15 test activations.

- **Order a contract extension or more CBU tests**

This choice allows you to select the number of years you want to extend the CBU contract. The order will include one CBU test activation for each year you extend the CBU contract, up to a total of 15 test activations. In addition, you can select whether you want to order additional test activations.

Click the type of replenishment record you want to order. The **Order Capacity Backup record (Step 1 of 2)** page opens.

3. Fill in the appropriate information, then continue to step [“3” on page 51](#).

How to cancel an upgrade record

You can cancel your CIU, On/Off CoD (post-paid without spending limits), On/Off CoD (prepaid), On/Off CoD (post-paid with spending limits), On/Off CoD test, administrative On/Off CoD test, CBU, or CPE record any time before you retrieve it using the Support Element. To cancel your order, following these steps:

1. In the **Capacity on Demand record** or **Permanent upgrades** section on the **Machine profile** page, click the order number you want to cancel. The order page opens.
2. Click **Cancel order**. The cancel order page displays asking you to confirm the cancellation.
3. Click **Cancel order**. The order page displays again. The status information at the top of the page shows that the order is canceled.

Chapter 5. Retrieving and installing

After ordering a permanent or temporary record, Resource Link notifies you by email when the upgrade is ready to download, and the status on the **Machine profile** page in Resource Link will be **Download ready**. You are now ready to retrieve and install the upgrade record.

The retrieve and install functions are performed on the Support Element using system programmer mode. To manage a staged, installed, activated/deactivated record, the system must be in IML complete state.

If you are retrieving an upgrade record from the support system, ensure you have a connection from the Support Element to the support system. If you do not have a connection, you will receive a message. The Remote Service Facility (RSF) must be enabled. To enable the Remote Service Facility, follow these steps:

1. On the Support Element, select the server.
2. In the tasks pad, expand the **Remote Customization** task list and select **Remote Service**.
3. Check **Enable remote service request**.
4. Select how the service call is reported.
5. Click **OK**.


The information in this chapter assumes that you know how to navigate the HMC and the Support Element user interface. For information about the user interface, refer to the console help system.

If you are retrieving permanent upgrade records, refer to [“Permanent upgrades” on page 59](#). If you are retrieving temporary upgrade records, refer to [“Temporary upgrades” on page 63](#).

Permanent upgrades


When retrieving and applying a permanent upgrade record, keep the following information in mind:

- If the installation of permanent LICCC upgrades ordered from your sales representative is in progress or was recently completed, before subsequently installing a permanent LICCC upgrade ordered from CIU on Resource Link, carefully consider each upgrade's configuration and the effect they may have on each other upon installation. Refer to [“Considerations for ordering and installing consecutive permanent LICCC upgrades” on page 4](#) for detailed information.
- If your upgrade record is located on the support system, you can either retrieve and apply (activate) the upgrade record using one task or using two separate tasks. When using two tasks, the first task retrieves and stages the upgrade record on the Support Element. Then, whenever you are ready, the second task activates the upgrade record.
- You can view any installed or staged permanent upgrade record using the **Display processor upgrade data (installed and staged)** task on the **Perform Model Conversion** window. A **Display Processor Upgrade Data** window similar to the following opens:



To retrieve a permanent upgrade record, follow these steps:

1. Log onto the HMC in system programmer mode.
2. Using the expand icon (+) in the navigation toolbar, expand the **Systems Management** nodes in the navigation pane and select the server. For information on the HMC user interface, refer to the console help system.
3. From the tasks pad, click **Configuration** and **Perform Model Conversion**. The **Perform Model Conversion** window opens:



4. Use one of the following methods to retrieve and apply (install) a permanent upgrade record:

- Retrieve and immediately apply the permanent upgrade record
- Retrieve the permanent upgrade record and apply it at a later time.

Note: In all methods, the upgrade is performed concurrently, if possible; otherwise it becomes activated after the next IML.

If there are activated temporary upgrade records, you can either manually run the precheck function or let it run automatically. The precheck function runs automatically when you choose to retrieve and apply the permanent upgrade record at the same time.

• **To retrieve your upgrade data from the support system and apply (install) it immediately:**

- a. From the **Perform Model Conversion** window, click **Permanent upgrades**, **Retrieve and apply**, and **Processor/memory upgrade data from support system**.
- b. On the **Customer Initiated Upgrade Order Activation Number** window, enter the order activation number and click **OK**.

The permanent upgrade record is retrieved. If there are activated temporary upgrade records, the precheck function automatically runs to determine if there are any conflicts.

If a conflict is detected, the permanent upgrade is not applied and a message window opens describing the conflict. After resolving the conflict, continue to step [“4.d” on page 62](#) to apply the permanent upgrade.

If a conflict is not detected, the permanent upgrade is applied.

If you increase permanent capacity while On/Off CoD resources are active, any active On/Off resources of the same type are used to satisfy the permanent upgrade.


• **To retrieve your upgrade data from the support system and install it at a later time:**

- a. From the **Perform Model Conversion** window, click **Permanent upgrades** and **Retrieve processor/memory upgrade data but do not apply**.
- b. On the **Customer Initiated Upgrade Order Activation Number** window, enter the order activation number and click **OK**.


The upgrade record is retrieved and stored on the Support Element hard drive to be installed at a later time.

If you decide you do not want to apply the upgrade record, contact IBM support who will dispatch someone to remove the record.

- c. When you are ready to apply the upgrade record you previously retrieved **AND** no temporary upgrade records are activated, the **Perform precheck on staged upgrade** tasks displays in the **Perform Model Conversion** window, but it is greyed out. This means that a permanent upgrade record is staged, but no temporary upgrade records are activated. Therefore, the precheck function is not necessary.



- i) Click **Permanent upgrades** and **Apply processor/memory upgrade data (previously retrieved)**. The permanent upgrade records are now installed.
- d. When you are ready to apply the upgrade record you previously retrieved **AND** temporary upgrade records are activated or if you need to verify that a previous conflict is corrected, the **Perform precheck on staged upgrade** task displays in the **Perform Model Conversion** window. This allows you to check for any conflicts before applying the permanent upgrade record.



- i) Click **Perform precheck on staged upgrade** to determine if there are any conflicts. If a conflict is detected, a message window opens describing the conflict. If a conflict is not detected, a message window opens saying the precheck was successful.
- ii) If the conflict is detected, resolve the conflict and repeat the previous step.
- iii) If a conflict is not detected, click **Apply processor/memory upgrade data (previously retrieved)**. The permanent upgrade is installed.

If you increase permanent capacity while On/Off CoD resources are active, any active On/Off resources of the same type are used to satisfy the permanent upgrade.

- 5. Purchase billing is generated when the memory or processor upgrade is downloaded and the machine owner receives an email confirmation that it is downloaded. The **Machine profile** page in Resource Link will also reflect the changed status of this record.

If the server is a leased machine, the lease payment is recalculated.

Temporary upgrades


The retrieve, install, and activate tasks for temporary upgrade records are all separate.

Up to eight temporary upgrade records (On/Off CoD, CBU, CPE, System Recovery Boost Upgrade) can be installed and activated at any given time. However, you can only have one On/Off CoD record activated at any given time.

To retrieve and install a temporary upgrade record, follow these steps:

1. Log onto the HMC in system programmer mode.
2. Using the expand icon (+) in the navigation toolbar, expand the **Systems Management** nodes in the navigation pane and select the server. For information on the HMC user interface, refer to the console help system.

- Expand the **Configuration** task list and click **Perform Model Conversion** (located in the Configuration list). The **Perform Model Conversion** window, similar to the following, opens:



- Retrieve your temporary upgrade record from with the support system or from a media device.
 - To retrieve your upgrade record from the support system, from the **Perform Model Conversion** window, click **Temporary upgrades**, **Retrieve**, and **Processor upgrade data from support system**.
 - To retrieve your upgrade data from a USB flash memory drive, from the **Perform Model Conversion** window, click **Temporary upgrades**, **Retrieve**, and **Processor upgrade data from media**.

If you are retrieving a replenishment record and the original record is already installed, the replenishment record is read directly into the installed slot of the record matching the record ID and added to that record.

If you are retrieving an original record, the record is placed in a staging area so it can be installed at a later time.

- Once you are ready to install the upgrade record, from the **Perform Model Conversion** window, click **Temporary upgrades** and **Manage**. The **Temporary Upgrades** window opens. In this window, you can see how many records are installed on the server.

P000BB01: Perform Model Conversion

Temporary Upgrades - P000BB01

Installed Records Staged Records

The following table shows all the installed records on the system.
 - To view a record description, place the mouse over the record.
 - The processors in the table are represented as "Maximum/Pending/Active"

Record ID	Record Type	CLIs	CPs	SAPs	ICFs	IFLs	zIIPs	Status
CB9U2VC3	CBU(pre-paid)	*0/0	*0/0	2/0/0	1/0/0	4/0/0	3/0/0	Installed
CR9U2TXT	On/Off CoD(post-paid)	*0/0	*0/0	4/0/0	2/0/0	2/0/0	2/0/0	Installed
Active Temporary		0	0	0	0	0	0	
Permanent		-	4	6	2	2	2	
Total Used		0	4	6	2	2	2	

Description: +12 FCs model capacity, +1 ICF, +3 zIIP, +4 IFL, +2 SAP
 Status details: N/A
 * - For CPs and CLIs, the maximum value is determined by an offering specific algorithm that accounts for engines, capacity level changes, and resulting capacity. For all other processor types, the maximum value is unlimited.

System Summary

Model-Capacity Identifier: 604 MSUs: 471
 Model-Temporary-Capacity Identifier: 604 Available PUs: 20
 Model-Permanent-Capacity Identifier: 604

Details... Add processors... Remove processors... Delete Help

Cancel

See Appendix C, "Understanding the content of the Installed Records page in the Temporary Upgrades window," on page 117 for details on the fields displayed on the **Installed Records** page in the **Temporary Upgrades** window.

- To install a record you just retrieved, click the **Staged Records** tab. The **Staged Records** page opens:

P000BB01: Perform Model Conversion

Temporary Upgrades - P000BB01

Installed Records **Staged Records**

Number of installed records: 2 records installed of 8 available.
 Staged Records

Select	Record ID	Record Type	Description
<input checked="" type="radio"/>	CR9U5LZP	On/Off CoD(pre-paid)	Prepaid +100% model capacity, +0 ICF, +0 zIIP, +0 IFL, +0 SAP
<input type="radio"/>	CR9U5M2K	On/Off CoD(post-paid)	Administrative On/Off CoD test record for Support Element training

Details... Install Delete Help

Cancel

The table on the **Staged Records** page lists all the records that are ready to be moved to the installed area.

- When a record is in the staged area, any retrieved replenishment records (identified by the same Record ID) are also loaded into the staged area. When the record in the staged area is selected to be loaded into the installed area, all the associated replenishment records (records having the same Record ID) are processed from the staged area and added to the installed record ID. These replenishment records are processed in the order based on their timestamp. Only one install slot is used.

Before the records are installed, you will be prompted with the following confirmation message: Are you sure you want to install this record and all its replenishment records?

- When a record is already in the installed area, any replenishment records (identified by the same record ID as the record in the installed area) retrieved are read directly into the installed slot of the record matching the record ID and added to that record.

Note: When you install a replenishment record, the record description on the Support Element is not updated. The record description on the Support Element shows the original record's description, including the original expiration date. The new expiration date **is** reflected in the **Record Details** window (in the Record Expiration Date field in the Time Limits area).

- Select the record you want to install and click **Install**. The **Installed Records** page opens showing the newly installed record.

The screenshot shows a window titled "P000BB01: Perform Model Conversion" with a sub-tab "Temporary Upgrades - P000BB01". It has two tabs: "Installed Records" (selected) and "Staged Records".

The main content area contains the following text:

The following table shows all the installed records on the system.
 - To view a record description, place the mouse over the record.
 - The processors in the table are represented as "Maximum/Pending/Active"

Record ID	Record Type	CLIs	CPs	SAPs	ICFs	IFLs	zIIPs	Status
CB9U2VC3	CBU(pre-paid)	*/0/0	*/0/0	2/0/0	1/0/0	4/0/0	3/0/0	Installed
CR9U2TXT	On/Off CoD(post-paid)	*/0/0	*/0/0	4/0/0	2/0/0	2/0/0	2/0/0	Installed
CR9U5LZP	On/Off CoD(pre-paid)	*/0/0	*/0/0	0/0/0	0/0/0	0/0/0	0/0/0	Installed
Active Temporary		0	0	0	0	0	0	
Permanent		-	4	6	2	2	2	
Total Used		0	4	6	2	2	2	

Description: Prepaid +100% model capacity, +0 ICF, +0 zIIP, +0 IFL, +0 SAP
 Status details: N/A
 * - For CPs and CLIs, the maximum value is determined by an offering specific algorithm that accounts for engines, capacity level changes, and resulting capacity. For all other processor types, the maximum value is unlimited.

System Summary

Model-Capacity Identifier:	604	MSUs:	471
Model-Temporary-Capacity Identifier:	604	Available PUs:	20
Model-Permanent-Capacity Identifier:	604		

Buttons: Details..., Add processors..., Remove processors..., Delete, Help, Cancel

Chapter 6. Activating temporary upgrade records

This chapter discusses information you need to about activating a temporary upgrade record. It includes activation rules and describes the different methods for activating a temporary upgrade record.

Activation rules

- Entitlement is based on permanent capacity.
- Current model position can limit activation capability.
- You can change activation level for active offerings. You cannot activate a CBU record in test mode if it is already active in real mode or if the number of real activations available is zero. If a record is active in test mode, you cannot activate a CBU real activation either.
- You can have multiple temporary upgrade records (up to 8) activated at the same time. However, you can have only one On/Off CoD record activated at any given time.
- When you activate an On/Off CoD upgrade, an indicator is set in the Vital Product Data. This indicator is part of the Call Home transmission, which is sent on a scheduled basis. A time stamp is placed into Call Home data when the upgrade is deactivated.

Methods of activation

You can activate a temporary upgrade record using any of the following methods:

- Manually activating an upgrade record using the Support Element.
- Setting up scheduled operations to activate upgrade records
- Using APIs
- z/OS® Capacity Provisioning.

Manually activating using the Support Element

To manually activate an installed upgrade record using the Support Element, follow these steps:

1. From the **Perform Model Conversion** window, click **Temporary upgrades** and **Manage**. The **Temporary Upgrades** window opens.

P000BB01: Perform Model Conversion

Temporary Upgrades - P000BB01

Installed Records Staged Records

The following table shows all the installed records on the system.
 - To view a record description, place the mouse over the record.
 - The processors in the table are represented as "Maximum/Pending/Active"

Record ID	Record Type	CLIs	CPs	SAPs	ICFs	IFLs	zIIPs	Status
CB9U2VC3	CBU(pre-paid)	*0/0	*0/0	2/0/0	1/0/0	4/0/0	3/0/0	Installed
CR9U2TXT	On/Off CoD(post-paid)	*0/0	*0/0	4/0/0	2/0/0	2/0/0	2/0/0	Installed
CR9U5LZP	On/Off CoD(pre-paid)	*0/0	*0/0	0/0/0	0/0/0	0/0/0	0/0/0	Installed
Active Temporary		0	0	0	0	0	0	
Permanent		-	4	6	2	2	2	
Total Used		0	4	6	2	2	2	

Description: +12 FCs model capacity, +1 ICF, +3 zIIP, +4 IFL, +2 SAP
 Status details: N/A

* - For CPs and CLIs, the maximum value is determined by an offering specific algorithm that accounts for engines, capacity level changes, and resulting capacity. For all other processor types, the maximum value is unlimited.

System Summary

Model-Capacity Identifier: 604 MSUs: 471
 Model-Temporary-Capacity Identifier: 604 Available PUs: 20
 Model-Permanent-Capacity Identifier: 604

Details... Add processors... Remove processors... Delete Help

Cancel

See Appendix C, "Understanding the content of the Installed Records page in the Temporary Upgrades window," on page 117 for details on the fields displayed on the **Installed Records** page in the **Temporary Upgrades** window.

- If you want to see more details about a record, such as the remaining test/real activations, the expiration dates, and whether the upgrade is controlled by tokens, select the record and click **Details...** The **Record Details** window opens.

For On/Off CoD records:

P000BB01: Perform Model Conversion

Record Details - P000BB01

Record ID: CR9U2TXT Status: Installed User: Panel
 Record Type: On/Off CoD(post-paid) CIU order #: LT9U2TXT
 Status details: N/A
 Activation Time: N/A
 Description: +100% model capacity, +2 ICF, +2 zIIP, +2 IFL, +4 SAP
 Original Description: +100% model capacity, +2 ICF, +2 zIIP, +2 IFL, +4 SAP

Resources

Model-Capacity Identifier (Maximum/Active): 705/604 Maximum MSU Percentage: 100
 Resource Counts (Maximum/Pending/Active)

CLIs	CPs	SAPs	ICFs	IFLs	zIIPs
*/0/0	*/0/0	4/0/0	2/0/0	2/0/0	2/0/0

Capacity Pools (Remaining/Consumption Rate)

Processor Tokens

CPs	SAPs	ICFs	IFLs	zIIPs
N/A	N/A	N/A	N/A	N/A

MSU Tokens: N/A
 Real Activations: N/A
 Test Activations: 0

Time Limits

Record Expiration Date: 8/23/15 11:59:59 PM GMT
 Real Activation Days Remaining: N/A
 Test Activation Days Remaining: N/A

Note: Fields containing the value "N/A" are not applicable for this record.

The data in the **Capacity Pools (Remaining)** section is determined by the type of On/Off CoD upgrade record:

- If the On/Off CoD upgrade is not controlled by tokens, the values in the **Processor Tokens** table and the value of **MSU Tokens** is set to N/A.
- If the On/Off CoD upgrade is controlled by tokens, in the **Processor Token** table, the value of CPs is set to N/A, and the value of each specialty engine is set to the number of tokens purchased. (A token represents the activation of one engine of that type for one day.)

MSU Tokens represents the number of tokens of processing capacity available based on the upgrade configurations and the number of days selected when you placed your order. **MSU Tokens** applies to CP engines. For CP engines, a token represents an amount of processing capacity resulting in one MSU of software cost for one day (an MSU day).

In the **Time Limits** section for post-paid On/Off CoD records, **Record Expiration Date** displays the date the record expires. For prepaid On/Off CoD upgrade records, **Record Expiration Date** is set to N/A. For all On/Off CoD upgrade records, **Real Activation Days Remaining** and **Test Activation Days Remaining** is set to N/A.

Note: To change the record description, edit or replace the existing description in the **Description** field, and then click **Update Description**. On the confirmation panel, click **OK**.

For CBU upgrades:

P000BB01: Perform Model Conversion

Record Details - P000BB01

Record ID:CB9U2VC3 Status:Installed User:Panel
Record Type:CBU(pre-paid) CIU order #:LT9U2VC3
Status details:N/A
Activation Time:N/A
Description:
Original Description:+12 FCs model capacity, +1 ICF, +3 zIIP, +4 IFL, +2 SAP

Resources

Model-Capacity Identifier (Maximum/Active):712/604 Maximum MSU Percentage:N/A
Resource Counts (Maximum/Pending/Active)

CLIs	CPs	SAPs	ICFs	IFLs	zIIPs
*0/0	*0/0	2/0/0	1/0/0	4/0/0	3/0/0

Capacity Pools (Remaining/Consumption Rate)

Processor Tokens

CPs	SAPs	ICFs	IFLs	zIIPs
N/A	N/A	N/A	N/A	N/A

MSU Tokens:N/A
Real Activations:1
Test Activations:10

Time Limits

Record Expiration Date:2/24/17 11:59:59 PM GMT
Real Activation Days Remaining:90
Test Activation Days Remaining:10

Note: Fields containing the value "N/A" are not applicable for this record.

If the value of the **Status** field displays "(Default)" or "(Attention!, Default)," this record is set as the default CBU record. The default CBU record is used to support the legacy API interface by enabling the **Force activation** option on the **Change Activation Levels** window. (See Step 3 for information on setting the **Force activation** option.) Enabling and setting the **Force activation** option allow the APIs to activate or deactivate all the resources in the default CBU record. If there is no default CBU record specified, the oldest CBU record is used. To set a CBU record as the default CBU record, select the **Set as Default CBU** button located at the bottom of the **Record Details** window.

In the **Capacity Pools (Remaining)** section for a CBU record, **Processor Tokens** and **MSU Tokens** are set to N/A. **Real Activations** and **Test Activations** display the number of real or test activations remaining for this upgrade record.

In the **Time Limits** section for a CBU record, **Record Expiration Date** displays the date the record expires. **Real Activation Days Remaining** and **Test Activation Days Remaining** display the number of days allowed for a real or test activation, if the record is not active. Otherwise, **Real Activation Days Remaining** and **Test Activation Days Remaining** display the number of days remaining for the activation.

Note: To change the record description, edit or replace the existing description in the **Description** field, and then click **Update Description**. On the confirmation panel, click **OK**.

- To activate processors in a record, select the record and click **Add processors...** (You can perform this task from either the **Temporary Upgrades** window or the **Record Details** window.) Depending on the type of record you select, the **Change Activation Levels** window opens:

For On/Off CoD records:

P000BB01: Perform Model Conversion

Change Activation Levels - P000BB01 i

Record ID:CR9U2TXT Record Type:On/Off CoD(post-paid) Status:Installed
 Description:+100% model capacity, +2 ICF, +2 zIIP, +2 IFL, +4 SAP
 Status details:N/A

Model-Capacity Identifier:604 CPs:0 active, 0 pending CLIs:0 active, 0 pending MSU Value:471

--- Select Action ---

Select ^	Target Model-Capacity ID ^	CLIs ^	CPs ^	Target MSU Value ^	MSU Cost ^
<input checked="" type="radio"/>	604	0	0	471	0
<input type="radio"/>	605	0	1	577	106
<input type="radio"/>	606	0	2	678	207
<input type="radio"/>	607	0	3	777	306
<input type="radio"/>	608	0	4	874	403

Processors

Select additional temporary processor counts for each processor type. The current values will be displayed as active(pending).

SAPs: * Current:0(0)

ICFs: * Current:0(0)

IFLs: * Current:0(0)

zIIPs: * Current:0(0)

When you have finished changing the activation levels, press the "OK" button to save your changes.

For CBU records:

P000BB01: Perform Model Conversion

Change Activation Levels - P000BB01 i

Record ID:CB9U2VC3 Record Type:CBU(pre-paid) Status:Installed
 Description:+12 FCs model capacity, +1 ICF, +3 zIIP, +4 IFL, +2 SAP
 Status details:N/A

Model-Capacity Identifier:604 CPs:0 active, 0 pending CLIs:0 active, 0 pending MSU Value:471

--- Select Action ---

Select ^	Target Model-Capacity ID ^	CLIs ^	CPs ^	Target MSU Value ^	MSU Cost ^
<input checked="" type="radio"/>	604	0	0	471	0
<input type="radio"/>	605	0	1	577	106
<input type="radio"/>	606	0	2	678	207
<input type="radio"/>	607	0	3	777	306
<input type="radio"/>	608	0	4	874	403

Processors

Select additional temporary processor counts for each processor type. The current values will be displayed as active(pending).

SAPs: * Current:0(0)

ICFs: * Current:0(0)

IFLs: * Current:0(0)

zIIPs: * Current:0(0)

Activation Options

Test Activation
 Real Activation

Force activation

When you have finished changing the activation levels, press the "OK" button to save your changes.


The table shows all the possible target model capacity identifiers that can be activated with this record. The values in this table are based on the configuration selections you set when you ordered the record on Resource Link, the current permanent configuration, and the available PUs in the system.

The Processors section identifies the count for each processor type that you can select.

The Activation Options section is visible for records that allow test activations. If a record is already activated for test, it must be deactivated prior to real activation.

Force activation is only available for CBU records and can only be set on the default CBU record. (Refer back to Step 1 for information on setting the default CBU record.) It is supported for legacy CBU activations because legacy activations did not allow the user to specify levels. If the Force activation is checked, the record is activated to its maximum regardless of what resources are available. That is, the CP table refreshes with a single entry with the maximum values for the record and the other processor types are automatically restricted to their maximum LICCC values. The machine will activate as many resources as it can based on what is available and the remaining resources become pending PUs. Pending PUs become active as soon as resource become available. (This information can be seen on the **Records Details** window.)

4. Make your changes and click **OK**. A window opens showing the new activation levels you selected.



5. If you want to continue with the changes you made, click **Yes**.

The changes you made are now active and are reflected in the **Temporary Upgrades** window.

P000BB01: Perform Model Conversion

Temporary Upgrades - P000BB01

Installed Records

The following table shows all the installed records on the system.
 - To view a record description, place the mouse over the record.
 - The processors in the table are represented as "Maximum/Pending/Active"

Record ID	Record Type	CLIs	CPs	SAPs	ICFs	IFLs	zIIPs	Status
CB9U2VC3	CBU(pre-paid)	*/0/0	*/0/0	2/0/0	1/0/0	4/0/0	3/0/0	Installed
CR9U2TXT	On/Off CoD(post-paid)	*/0/0	*/0/3	4/0/0	2/0/0	2/0/1	2/0/0	Active-Real
CR9U2UBT	On/Off CoD(pre-paid)	*/0/0	*/0/0	4/0/0	2/0/0	2/0/0	2/0/0	Installed
Active Temporary		0	3	0	0	1	0	
Permanent		-	4	6	2	2	2	
Total Used		0	7	6	2	3	2	

Description: +100% model capacity, +2 ICF, +2 zIIP, +2 IFL, +4 SAP
 Status details: N/A
 * - For CPs and CLIs, the maximum value is determined by an offering specific algorithm that accounts for engines, capacity level changes, and resulting capacity. For all other processor types, the maximum value is unlimited.

System Summary

Model-Capacity Identifier:	607	MSUs:	777
Model-Temporary-Capacity Identifier:	607	Available PUs:	16
Model-Permanent-Capacity Identifier:	604		

Setting up scheduled operation to activate an upgrade record

Using the Customize Scheduled Operations task on the Support Element, you can set up a scheduled operation to activate and deactivate an On/Off CoD record. However, when you use this task, all resources in the On/Off record are activated or deactivated. You cannot partially activate or deactivate capacity or specialty engines.

To set up a scheduled operation, follow these steps:

1. On the Support Element, select the appropriate server.
2. From the Tasks pad, click **Operational Customization** and **Customize Schedule Operations**.
3. From the **Customize Scheduled Operations** window, click **Options** and **New**.
4. From the **Add a Scheduled Operation** window, select **Activate or deactivate processor resources in an OoCoD record** and click **OK**.
5. From the **Set up a Scheduled Operation** window, fill in the appropriate information on the **Date and Time** page, **Repeat** page, and **Options** page.
 - On the **Date and Time** page, enter the date and time you want to activate or deactivate the record. You can also select a time window value. If an existing conditions prevents the activate or deactivation of the record, an attempt to activate or deactivate will be made within this time window value.
 - On the **Repeat** page, you can set up criteria to have the activation or deactivation repeated.

- On the **Options** page:
 - a. Select the function you want performed – activate or deactivate.
 - b. In the **Installed OOCoD Records** table, select the specific record you want to activate or deactivate.
 - c. Click **Save**.

Using SNMP and HMC Web Services APIs to activate an upgrade record

Before using SNMP and HMC Web Services APIs to process temporary capacity records, you must first ensure that the HMC and Support Element are enabled to process SNMP and HMC Web Services APIs requests. Then you must enable the function that allows capacity changes through API requests.

For SNMP APIs:

- On the Support Element, open the **Customize API Settings** task, select the **Enable SNMP APIs** option, select the **Allow capacity change API requests** option, and click **OK**.

For HMC Web Services APIs:

- On the HMC, open the **Customize API Settings** task. Select the tab for the Web Services API, and enable the API. Authorize the appropriate HMC user to use it.
- On the Support Element, open the **Customize API Settings** task, select the **Allow capacity change API requests** option, and click **OK**.

The user performing the **Customize API Settings** task must be assigned the access administrator role. The user performing the **Customize Console Services** task must be assigned the access administrator or system programmer role. Hardware Management Console (HMC) and Support Element (SE) (version 2.12.1 or later) information can be found on the console help system.

Using SNMP APIs

You can use the `HWMCA_ADD_CAPACITY_COMMAND` and `HWMCA_REMOVE_CAPACITY_COMMAND` APIs to allow applications to add and remove temporary capacity for defined CPC objects. You can use the `HWMCA_ACTIVATE_CBU_COMMAND` and `HWMCA_ACTIVATE_OOCOD_COMMAND` APIs to allow applications to activate a CBU or On/Off CoD record for a defined CPC object.

When activating a CBU record, the API activates all the resource in the **default** CBU record. If there is no default CBU record specified, the oldest CBU record is used. To set a CBU record as the default CBU record, select the **Set as Default CBU** button located at the bottom of the **Record Details** window.

Refer to *SNMP Application Programming Interfaces* for details on these Command APIs.

Using HMC Web Services APIs

With the HMC Web Services APIs, you can use the **Add Temporary Capacity** and **Remove Temporary Capacity** requests to add and remove temporary capacity for a CPC. These operations are targeted at the CPC object to be affected. You can also use API operations such as **List CPCs** to locate the URIs of the CPC desired, and then invoke the **Add Temporary Capacity** or **Remove Temporary Capacity** operation using that CPC's URI.

Refer to *Hardware Management Console Web Services API* for details on the CPC object and the **Add Temporary Capacity** or **Remove Temporary Capacity** operations on it.

Using z/OS Capacity Provisioning

z/OS Capacity Provisioning gives the customer a flexible and automated process to control the configuration and activation of On/Off CoD records.

z/OS MVS™ Capacity provisioning allows you to set up rules defining the circumstances under which additional capacity should be provisioned in order to fulfill a specific business need. The rules are based on criteria, such as: a specific application, the maximum additional capacity that should be activated,

time and workload conditions. This support provides a fast response to capacity changes and ensures sufficient processing power will be available with the least possible delay even if workloads fluctuate. Refer to the *z/OS MVS Capacity Provisioning User's Guide* for more information.

Chapter 7. Deactivating temporary capacity

Deactivating is the process of removing temporary processors or decreasing temporary model capacity. Deactivation can be performed manually or automatically upon expiration.

When you are finished using all or part of a capacity upgrade, you can take action to remove processors or decrease model capacity using the Support Element. You can only remove activated resources for the specific offering. You cannot remove dedicated engines or the last of the engine type.

If you deactivate resources back to the base configuration, the activation is complete. (That is, if you deactivate the last temporary processor, your record is deactivated.) For a CBU and On/Off CoD record, to add resources again, you must start a new activation. For a On/Off CoD test or CPE record, once the record is deactivated, it is no longer available for use. You can delete the record.

If you do not manually deactivate the added capacity, the activated resources are automatically deactivated at expiration time (including any grace period). You will receive daily warning messages (hardware messages) starting five days in advance of the expiration. Once a temporary record enters the grace period, the only customer option is to deactivate all resources from this record. You cannot change the activation level by increasing or decreasing partial resources. If you attempt to partially increase or decrease resources, you will receive an error indicating the temporary record has expired.

After deactivation, a record remains as an installed record. If you want a record deleted, you must manually select the record on the **Installed Records** page and click **Delete**.

Considerations before deactivating

Before deactivating a record, consider the following:

- If the processors were made available into the shared pool without configuring any processor online to any logical partition, no preparatory actions are required. Deactivating the active record is sufficient, all the logical partitions defined with shared processors will fall back to exactly the same situation as before the record was activated.
- If the processors were made available into the shared pool and reserved processors were configured online in logical partitions (or a new logical partition with shared processors was activated), they should be configured offline (or logical partition deactivated) before record deactivation. Otherwise the logical-to-physical ratio would become different than before the activation of the record, which may lead to performance issues. Even if there are less physical processors available in the shared pool than logical shared processors assigned to any logical partition, the record can be deactivated.
- If processors were made available and new dedicated processors were brought online, they should be configured offline before record deactivation because record deactivation will remove processors only from the shared pool. If the processor(s) are not configured offline and there are active partitions using shared processors:
 - Deactivation will fail if it would bring the number of processors in the shared pool to zero
 - Deactivation will proceed if at least one processor remains in the shared pool. Note that in this case the ratio of shared logical processors to physical processor will be changed.

Processors are automatically deactivated if either of the following conditions occur:


- A temporary record expires
- Activation days are exceeded.

How to deactivate


To manually deactivate all or part of a temporary upgrade, follow these steps:

1. Log onto the HMC in system programmer mode.

- Using the expand icon (+) in the navigation toolbar, expand the **Systems Management** nodes in the navigation pane and select the server. For information on the HMC user interface, refer to the console help system.
- From the tasks pad, click **Configuration** and **Perform Model Conversion**. The **Perform Model Conversion** window opens:



- From the **Perform Model Conversion** window, click **Temporary Upgrades** and **Manage**. The **Temporary Upgrades** window opens.



See Appendix C, “Understanding the content of the Installed Records page in the Temporary Upgrades window,” on page 117 for details on the fields displayed on the **Installed Records** page in the **Temporary Upgrades** window.

5. Select the active record you want to deactivate and click **Remove processors....** The **Change Activation Levels** window opens.

Note: When you are deactivating capacity, only the values to which you can "downgrade" are available.

Change Activation Levels - P000BB01

Record ID:CR9U2TXT Record Type:On/Off CoD(post-paid) Status:Active-Real
 Description:+100% model capacity, +2 ICF, +2 zIIP, +2 IFL, +4 SAP
 Status details:N/A

Model-Capacity Identifier:607 CPs:3 active, 0 pending CLIs:0 active, 0 pending MSU Value:777

Select	Target Model-Capacity ID	CLIs	CPs	Target MSU Value	MSU Cost
<input type="radio"/>	604	0	-3	471	0
<input type="radio"/>	605	0	-2	577	106
<input checked="" type="radio"/>	606	0	-1	678	207
<input type="radio"/>	607	0	0	777	306
<input type="radio"/>	704	1	-3	740	269


Processors

Select additional temporary processor counts for each processor type. The current values will be displayed as active(pending).

SAPs: * Current:0(0)
 ICFs: * Current:0(0)
 IFLs: * Current:1(0)
 zIIPs: * Current:0(0)

When you have finished changing the activation levels, press the "OK" button to save your changes.

6. Either make your changes (the previous window shows a deactivation of one CP) or click **Undo**. The **Undo** function deactivates all the resources from the record back to the base configuration. Then click **OK**. The **Temporary Upgrades** window opens showing the changes.



- View the data and if you want to continue with the changes you made, click **Yes**.
The changes you made are now active and are reflected in the **Temporary Upgrades** window.

P000BB01: Perform Model Conversion

Temporary Upgrades - P000BB01

Installed Records

The following table shows all the installed records on the system.
 - To view a record description, place the mouse over the record.
 - The processors in the table are represented as "Maximum/Pending/Active"

Record ID	Record Type	CLIs	CPs	SAPs	ICFs	IFLs	zIIPs	Status
CB9U2VC3	CBU(pre-paid)	*/0/0	*/0/0	2/0/0	1/0/0	4/0/0	3/0/0	Installed
CR9U2TXT	On/Off CoD(post-paid)	*/0/0	*/0/2	4/0/0	2/0/0	2/0/1	2/0/0	Active-Real
CR9U2UBT	On/Off CoD(pre-paid)	*/0/0	*/0/0	4/0/0	2/0/0	2/0/0	2/0/0	Installed
Active Temporary		0	2	0	0	1	0	
Permanent		-	4	6	2	2	2	
Total Used		0	6	6	2	3	2	

Description: +100% model capacity, +2 ICF, +2 zIIP, +2 IFL, +4 SAP
 Status details: N/A
 * - For CPs and CLIs, the maximum value is determined by an offering specific algorithm that accounts for engines, capacity level changes, and resulting capacity. For all other processor types, the maximum value is unlimited.

System Summary

Model-Capacity Identifier:	606	MSUs:	678
Model-Temporary-Capacity Identifier:	606	Available PUs:	17
Model-Permanent-Capacity Identifier:	604		


Note: If you remove all the temporary processors and decrease the capacity to the permanent capacity available on this record, the record remains installed for you to modify at a later and the status changes to "Installed."

Chapter 8. Deleting temporary Capacity on Demand records

You can delete staged and installed temporary Capacity on Demand records (On/Off CoD, CBU, CPE, System Recovery Boost Upgrade) when you no longer want or need them. For example, if you have On/Off CoD records that support activating more ICFs, but now you want to prevent activating additional ICFs, then you might want to delete any staged or installed records that support activating more ICFs. Or if you must discontinue the use of CoD features and remove them from your machine, you typically must delete all staged and installed temporary CoD records. (See [Chapter 11, “Discontinuing and removing Capacity on Demand features,”](#) on page 93 for details.)


To delete staged and installed records, follow these steps:

1. Log onto the HMC in system programmer mode.
2. Using the expand icon (+) in the navigation toolbar, expand the **Systems Management** nodes in the navigation pane and select the server. For information on the HMC user interface, refer to the console help system.
3. From the tasks pad, click **Configuration** and **Perform Model Conversion**. The **Perform Model Conversion** window opens:



4. From the **Perform Model Conversion** window, click **Temporary upgrades** and **Manage**. The **Temporary Upgrades** window opens.
5. Click the **Staged Records** tab. The **Staged Records** page opens.

The table on the **Staged Records** page lists all the records that are ready to be deleted or installed. If available, replenishment records (identified by the same Record ID as the original record) are also shown in this table.




6. From the **Staged Records** page, select the records you need to delete and click **Delete**.

Note: If you delete a record that has replenishment records, the replenishment records are also deleted.

7. Click the **Installed Records** tab. The **Installed Records** page opens.

The table on the **Installed Records** page lists all the records that are currently installed or active.



8. From the **Installed Records** page, select the record you need to delete and click **Delete**.

Note: If a record that you need to delete is currently active, you must deactivate the record before deleting it. (Refer to [Chapter 7, “Deactivating temporary capacity,” on page 77](#) for details on deactivating a record.)

All appropriate staged and installed records are now deleted.

9. Transmit the vital product data (VPD) to the support system using the following steps:
 - a. Click **Cancel** on the **Temporary Upgrades** window and the **Perform Model Conversion** window to return to the tasks pad.
 - b. From the tasks pad, click **Configuration** and **Transmit Vital Product Data**.
 - c. From the **Transmit Vital Product Data to IBM** window, select **support system** and click **OK**.

Chapter 9. Billing

Permanent upgrades

For permanent upgrade records, you are charged one fee per record based on the price agreement negotiated for the machine or the record order. Billing begins when you download (retrieve) the permanent upgrade record to the Support Element.

Temporary upgrades

For temporary upgrades, the billing information is defined in the LICCC record. You are responsible for any software charges resulting from the activated capacity. The charges will depend on the license agreement for the particular software product.

For CBU, CPE, and System Recovery Boost Upgrade records, you are charged one fee per record based on the price agreement negotiated for the machine or the record order. You are billed when you download (retrieve) the record to the Support Element. Records are priced for hardware. There are no additional software charges or maintenance charges.

For post-paid On/Off CoD records with no spending limit, when you activate the record, tracking for billing begins. You pay for what you activate during the activation time. You are charged on a 24-hour basis. For each month (starting with the month you activated the record), a report is generated; and in the following month, you are billed for hardware, software, and maintenance charges.

For prepaid On/Off CoD records, when you download the record, hardware billing is initiated. You will be billed for the total capacity enabled on the record based on the number of token days you requested. Every 24 hours tokens (corresponding to the upgrade configuration activated) are decremented from the token pool as they are used. You will be billed for any software and maintenance charges associated with the activated capacity in the month following the activation.

For post-paid On/Off CoD records with spending limits, when you activate the record, tracking for billing begins. Every 24 hours, tokens (corresponding to the upgrade configuration activated) are decremented from the token pool as they are used. For each month (starting with the month you activated the record), a report is generated; and in the following month, you are billed for the number of tokens used and for any software and maintenance charges associated with the activated capacity. (NOTE: Software and maintenance charges incurred are not part of the spending limit the customer identified in the On/Off CoD record.)

Billing is also based on activation level relative to permanent capacity. If you activate temporary capacity below the current purchased capacity (referred to as the "high water mark" (HWM)), there are no hardware charges. However, there may be software and maintenance charges.

Billing is managed via the support system and Resource Link.

Chapter 10. Monitoring

The chapter explains some of the functions available for you to use to monitor your Capacity on Demand activity.

STSI instruction

The model-capacity identifier, model-permanent capacity identifier, and model-temporary capacity identifier information provided by the STSI instruction allows programs to recognize On/Off CoD and CBU activity. The capacity identifiers correspond to software models.

Model Capacity Identifier equals the base machine capacity + billable capacity (On/Off CoD) + replacement capacity (CBU and CPE)

Model Permanent Capacity Identifier equals the base machine capacity

Model Temporary Capacity Identifier equals the base machine capacity + billable capacity (On/Off CoD)

You can use the STSI instruction to obtain the model-capacity rating, model-permanent capacity rating, and model-temporary capacity rating. These capacity factors are the MSU ratings for the corresponding capacity identifiers. Using these values, you can determine how changing your capacity may impact your licensing agreements.

SNMP APIs

The following APIs allow registered application to be notified about temporary capacity changes:

- `HWMCA_EVENT_CAPACITY_CHANGE` notifies the application that the processing capacity for a defined CPC object has changed.
- `HWMCA_EVENT_CAPACITY_RECORD_CHANGE` notifies the application that a change has occurred to a temporary capacity record.

Refer to *SNMP Application Programming Interfaces* for details.

History of activity on the system

Using the Support Element, you can view the history of actions taken on records for your system within the last 90 days. To view this history information, follow these steps:

1. From the Support Element, using the expand icon (+) in the navigation toolbar, expand the **Systems Management** nodes in the navigation pane and select the server. For information on the Support Element user interface, refer to the console help system.
2. From the tasks pad, click **Configuration** and **Perform Model Conversion**. The **Perform Model Conversion** window opens.
3. From the **Perform Model Conversion** window, click **Temporary upgrades** and **History**. The **Upgrade History** window opens.

P000BB01: Perform Model Conversion

Upgrade History - P000BB01

History

--- Select Action ---

Select ^	Date and Time ^	Record ID ^	Action ^
<input checked="" type="radio"/>	2/27/15 4:56:53 PM GMT	CR9U2TXT	Activate(608)
<input type="radio"/>	2/27/15 4:38:38 PM GMT	CR9U5LZP	Install
<input type="radio"/>	2/27/15 4:03:51 PM GMT	CR9U2UBT	Delete
<input type="radio"/>	2/26/15 11:58:47 PM GMT	CR9U2TXT	Deactivate(604)
<input type="radio"/>	2/26/15 11:54:53 PM GMT	CR9U2TXT	Deactivate(606)
<input type="radio"/>	2/26/15 11:24:07 PM GMT	CR9U2TXT	Activate(607)
<input type="radio"/>	2/26/15 10:54:05 PM GMT	CR9U2UBT	Install
<input type="radio"/>	2/26/15 10:44:08 PM GMT	CR9U2TXT	Install
<input type="radio"/>	2/26/15 10:31:06 PM GMT	CB9U2VC3	Install
<input type="radio"/>	2/25/15 1:15:39 PM GMT		Permanent
<input type="radio"/>	2/24/15 7:45:27 PM GMT		Permanent

Details... Cancel Help

The actions are identified as:

Activate/Deactivate

Displays when the activation levels were changed for the record.

Install

Displays when the record was moved from the staged area to the installed area.

Replenish

Displays when the record was replenished.

Delete

Displays when the selected record was permanently removed from the system.

Permanent

Displays when a change was made to the permanent LICCC on the system.

Expired

Displays when the record reached its expiration criteria. (Expiration criteria can be: a specific calendar date, a specific number of days, or a specific number of tokens.)


The entries in the table are initially sorted by the date and time of the changes made to the records. You can, however, sort the table by any column by clicking the arrow located to the right of the column header.

- To view details about a specific action, select the record on the **Upgrade History** window and click **Details....** The **Temporary Upgrade History** window opens. Depending on the action of the record selected, the contents of the **Temporary Upgrade History** window may include:


- The record ID of the selected record, the action performed on the selected record, the date the action was performed, the order number associated with the selected record, the ID of the last user who acted on this record, and the source, Net ID, and NAU

- The maximum/active model capacity identifier
- Unassigned IFLs
- A table containing the active CPs, and specialty engines installed **for the record**. For example, suppose you had a permanent configuration of 7 CPs and a CBU record had 2 active CPs previously. Then you add 3 more CBU CPs in a second activation. The table would show 5 active CPs (not 3 or not 12).

For example, when the action of the record is "Activate" or "Deactivate," a **Temporary Upgrade History** window similar to the following opens:



When the action of the record is "Delete," "Install," or "Replenish," a **Temporary Upgrade History** window similar to the following opens:



When the action of the record is "Permanent," a **Temporary Upgrade History** window similar to the following opens:

P000BB01: Perform Model Conversion

Temporary Upgrade History - P000BB01

- Action: Permanent
- Date: 2/24/15 7:45:27 PM GMT
- Order number:
- Source:
- Net ID:
- NAU:

Model-Capacity Identifier: 604
Maximum Model-Capacity Identifier: 604
Unassigned IFLs: 0

Activated Levels

CPs	SAPs	ICFs	IFLs	zIIPs
4	6	2	2	2

ACT37472

OK

Chapter 11. Discontinuing and removing Capacity on Demand features

Certain events require that you discontinue your use of one or more of the Capacity on Demand (CoD) features on a machine and remove those features from the machine. These events include:

- You are upgrading your machine to a newer machine type
- You are selling your machine to another party
- You are returning your machine to IBM or another leasing company
- You no longer wish to participate in the CoD offering
- IBM has withdrawn the machine's CoD features from marketing (not applicable to CBU or CPE features).

These events may require you to deactivate CoD records or delete staged or installed CoD records. For details on deactivating CoD records, see Chapter 7, “Deactivating temporary capacity,” on page 77. For details on deleting staged or installed CoD records, see [Chapter 8, “Deleting temporary Capacity on Demand records,”](#) on page 83.

Upgrading your machine

If you are upgrading your machine to a newer machine type server, then the steps you need to perform prior to the upgrade will differ depending on how the upgrade is being done.

For upgrades where the machine's serial number remains the same, your IBM service representative will migrate your CoD records to the upgrade machine as part of the upgrade installation. However, prior to the upgrade, you must complete the following steps:

1. Deactivate any active CoD records
2. Remove the CoD features
3. Transmit or upload vital product data (VPD) to IBM.

This step gives IBM an accurate representation of your machine's current CoD record state prior to the upgrade. It is especially important for On/Off CoD users to ensure that IBM Resource Link has an accurate record of all On/Off CoD activity that has occurred on the machine prior to the upgrade being performed. IBM computes charges for On/Off CoD usage based on information returned with the VPD, and incomplete VPD could result in incorrect charges.

If your IBM Z upgrade is a "hybrid" or another type of upgrade where your new or upgraded machine has a different serial number than the original machine, you must complete the following steps for all CoD records:

1. Deactivate any active CoD records
2. Delete any installed CoD records
3. Delete any staged CoD records
4. Remove the CoD features
5. Transmit or upload vital product data (VPD) to IBM.

New CBU records will be shipped with your upgraded machine. For CPE and prepaid On/Off CoD records, contact your IBM or Business Partner sales representative and notify them that you will need new records created and delivered for your upgraded machine. These records cannot be created prior to shipment of the upgraded machine because the records must be based on the final VPD transmitted to IBM after the upgrade is performed. You will need to create and install new post-paid On/Off CoD records for your machine after it is upgraded.

IBM will create a new CIU machine profile on Resource Link for the upgraded machine. You no longer need the CIU machine profile for the former machine. Disable the machine profile to remove it from your list of active machine profiles. See [“Disabling a machine profile” on page 95](#).

Selling your machine to another company

If you are selling your machine to a third party, you must remove all CoD records on the machine, including CBU and CPE records, prior to uninstalling the machine and transferring it to the new owner.

- Deactivate any active CoD records
- Delete any installed CoD records
- Delete any staged CoD records
- Remove the CoD features
- Transmit or upload vital product data (VPD) to IBM.

You no longer need the machine's CIU machine profile on Resource Link. Disable the machine profile to remove it from your list of active machine profiles. See [“Disabling a machine profile” on page 95](#).

Returning your leased machine to IBM

If you are returning a leased machine to IBM or another lessor, the temporary CoD records on the machine must be removed prior to returning it. You must complete the following steps:

- Deactivate any active CoD records
- Delete any installed CoD records
- Delete any staged CoD records
- Remove the CoD features
- Transmit or upload vital product data (VPD) to IBM.

You no longer need the machine's CIU machine profile on Resource Link. Disable the machine profile to remove it from your list of active machine profiles. See [“Disabling a machine profile” on page 95](#).

IBM withdrawing the machine from marketing

When IBM withdraws a machine from marketing, the right to use post-paid On/Off CoD records typically is withdrawn. Your right to use prepaid CoD records, such as CBU, CPE, or prepaid On/Off CoD typically remains until terminated per the terms of the offering. You should check the announcement and offering terms for details. Unless instructed otherwise by IBM, upon the withdrawal from marketing of your machine, you must complete following steps:

- Deactivate any active post-paid On/Off CoD records
- Delete any installed post-paid On/Off CoD records
- Delete any staged post-paid On/Off CoD records
- Transmit or upload vital product data (VPD) to IBM.

IBM will disable CIU machine profiles on Resource Link for a withdrawn machine type, typically on the date when ordering new CoD records is no longer allowed.

Removing the Capacity on Demand features

To remove the Capacity on Demand features, follow these steps:

- Log onto the HMC in system programmer mode.
- Using the expand icon (+) in the navigation toolbar, expand the nodes in the navigation pane and select the server

- From the tasks pad, click **Recovery** and **Single Object Operations** to open a Support Element session for the selected server
- Make sure the correct server name is listed and selected, and click **Yes**
- From the Support Element, expand the nodes in the navigation pane and select the server name
- From the tasks pad, click **Configuration** and **Prepare System for Discontinuance**
- Click **Yes** to confirm the discontinuance on the **Prepare System for Discontinuance** window.

Disabling a machine profile

Disable a CIU machine profile when you no longer need it. You no longer need a CIU machine profile when, for example, you discontinue use of and remove the machine's CoD features for any of the events described in this chapter.

Disabling a machine profile will:

- remove it from the CIU **Active machine profiles** page on Resource Link
- Remove its ordering options
- Cancel any upgrades or CoD records on order.

Disabling a machine profile does not cancel, deactivate, or delete CoD records currently installed or staged on the machine. You still need to deactivate the machine's active CoD records and delete its installed and staged CoD records.

Disabling a machine profile does not delete it. A disabled machine profile remains listed on the CIU **All machine profiles** page on Resource Link so you can review its order history, billing history, or other information if necessary.

To disable a machine profile:

- Open the machine profile on Resource Link.
- Click the **Disable machine profile...** link in the **To update profile** link list. Clicking the link will display a confirmation page.
- Follow the instructions on the confirmation page to confirm disabling the machine profile.

Appendix A. Status and Messages

This chapter provides useful information for troubleshooting problems you may encounter when you plan for, order, and activate a permanent upgrade, a On/Off CoD record, a CBU record, or a CPE record.

“[Order status definitions](#)” on page 97 provides explanations of the order status of the upgrade from ordering to activating to completing. This status is shown on the **Machine profile** page in Resource Link.

The “[Messages](#)” on page 98 provides product messages with descriptions, in alphanumeric sequence, that are displayed on the Support Element.

Order status definitions

Activated

The order has been activated.

Cancel denied

A cancellation request received after the order was downloaded is denied and the billing process continues. Contact your sales representative with any questions.

Canceled

The cancellation request is complete and the order was canceled. New orders can now be created for the machine.

Cancel requested

You requested to cancel the order. Notification is sent to you verifying the cancellation. New orders can be created after the cancel request is completed for the order.

Complete

The order has been retrieved, installed and billing is complete.

Deactivated

The order has been deactivated.

Downloaded

The upgrade has been downloaded (retrieved) to the machine. For a permanent upgrade, billing is also notified.

Download ready

The order is ready for you to download (retrieve) and install using the Hardware Management console. Downloading requires the order key that was generated for the order.

Installed

The order was detected as installed on the machine, Notification is sent to you. New orders can now be created for the machine.

Needs customer approval

Pricing set prices for an order that was created without a prenegotiated agreement. The authorized Resource Link customer user ID is notified that the purchase price needs to be approved or the order is canceled.

Needs lease quote

A lease agreement is being created for your approval.

Needs price agreement

An order was created without a prenegotiated agreement in place. Your order cannot be retrieved or activated until there is a price agreement in place. Pricing will negotiate an agreement with you and the sales representative.

Needs secondary approval

An upgrade order placed for this machine requires a secondary approval or cancellation from an authorized Resource Link secondary approval user ID. Notification is sent to the authorized approver when a secondary approval is required.

New Order

The approved order is being processed in the IBM Service Support System.

Partially installed

Part of the upgrade order was installed. It must be fully installed before new orders can be created for the machine.

Processing credit

Order entry is processing the order.

Staging order

This order is now being processed in the IBM Service Support System. Authorized users will be notified by email when the order is ready to be retrieved.

Messages

This topic describes the messages displayed on the Support Element by the Capacity on Demand offerings during retrieve, installation, activation, and deactivation. The messages and descriptions are in alphanumeric sequence by message identifier.

Message format

The message format is:

```
ACTnnns text
```

nnn

Is the message serial number.

s

Is the type code:

E

Error. The user must perform a specific action.

I

Information. No operator action is required.

Q

Question. Requires a response or action.

W

Warning. A process is pending. Determine and perform an action.

text

Is the message text.

Message list

ACT37111E **Warmstart error**

Explanation

A problem was detected while updating the configuration.

User response

It is strongly recommended that you reboot the Support Element now to complete the configuration update. Failure to reboot the Support Element will preserve configuration data mismatches and unexpected system performance problems.

ACT37112E **I390 sync error**

Explanation

A problem was detected while trying to update the configuration concurrently.

User response

Please retry the operation. If a subsequent retry fails, then the operation must be completed disruptively. Contact your next level of support.

ACT37113I **VPD information**

Explanation

Update of the hardware configuration and VPD was successful.

User response

None.

ACT37114E **VPD error**

Explanation

A problem was detected while updating the configuration and VPD. The hardware configuration and VPD may not have been updated.

User response

Ensure that the configuration and VPD have been updated and try the operation again.

ACT37115E **VPD error**

Explanation

Update of the hardware configuration and VPD cannot be done on this machine type.

User response

Try the operation on a valid machine type.

ACT37116Q **VPD**

Explanation

Update the hardware configuration and vital product data to reflect the current LICCC data.

User response

Click **OK** to update the hardware configuration and VPD.

ACT37130Q **Test initial**

Explanation

A test will be performed to determine if various system FRUs meet minimum serviceability requirements.

User response

Click **OK** to start the test and display messages indicating the results.

ACT37131I **Test OK**

Explanation

The MSQ processor test indicates acceptable hardware.

User response

None.

ACT37132E **Spare PUs**

Explanation

There are insufficient spare PUs available. The MSQ test fails.

User response

None.

ACT37133E **Test failure**

Explanation

A problem was detected during the MSQ processor test. The test could not be completed.

User response

None.

ACT37142I **Add successful**

Explanation

The Flexible Memory Option feature was added successfully.

User response

None.

ACT37143E **Add error**

Explanation

An error occurred while installing the Flexible Memory Option feature.

User response

Try the operation again. If the error continues, contact your next level of support.

ACT37144I **Remove successful**

Explanation

Remove of the Flexible Memory Option feature was successful.

User response

None.

ACT37145E Remove error

Explanation

Remove of the Flexible Memory Option feature was unsuccessful.

User response

Try the operation again. If the error continues, contact your next level of support.

ACT37146W IML warning

Explanation

The selected operation cannot be processed at this time because a required IML was never completed after a previous configuration update.

User response

Please IML your system and retry the operation.

ACT37150W CBU busy

Explanation

The requested operation cannot be done at this time because a mirror operation is in progress.

User response

Please try again in approximately 10 minutes.

ACT37151E CBU error

Explanation

An error was encountered requiring the SE to be rebooted.

User response

Reboot the Support Element.

ACT37152I Completion successful

Explanation

Requested function completed successfully.

User response

None.

ACT37153W User cancelled

Explanation

Request was cancelled.

User response

None.

ACT37155W Undo CBU LPAR

Explanation

Undo temporary upgrade was selected from the **Perform Model Conversion** window. Ensure that at least *{0}* logically dedicated General Purpose (GP) CPs, *{1}* ICF CPs, *{2}* zAAPs, *{3}* IFLs and *{4}* zIIPs are configured offline.

You need at least one nondedicated GP CP, ICF CP, zAAP, IFL, or zIIP for any logical partitions using shared GP CPs, ICF CPs, zAAPs, IFLs or zIIPs.

User response

Click **OK** to continue. Click **Cancel** if you do not want to perform the Undo now.

ACT37160E Internal error

Explanation

Error detected performing the requested function.

User response

Try the operation again. If the problem continues, contact your next level of support.

**ACT37161W Disable CP Assist for
Cryptographic Functions**

Explanation

The **IBM CP Assist for Cryptographic Functions** (CPACF) feature will be removed from the system. Operating systems and applications utilizing these functions may become unpredictable and fail.

Some functions of Integrated Cryptographic Service Facility (ICSF) may fail. See the *ICSF Application Programmer's Guide* for more information.

Some Linux kernel and application cryptographic functions may become unusable. Linux images should be shut down gracefully before removal of CPACF functions.

User response

Click **OK** to continue to process the new LICCC data. Click **Cancel** if you do not want to process the new LICCC at this time.

ACT37167W **Memory successful**

Explanation

The system was successfully updated with the new MCM and memory LICCC data. The system was able to complete the MCM upgrade concurrently. However, the upgrade will not take effect until the next IML is performed.

User response

Perform a system IML to initiate the MCM upgrade.

ACT37169W **IOCDS active**

Explanation

The request cannot be performed while the D0 IOCDS is active.

User response

Re-IML with another IOCDS and retry the operation.

ACT37170W **Disruptive OK**

Explanation

The system was successfully updated with the new LICCC data. However, validation of the new LICCC data will not occur until the next Power on Reset (POR). Incorrect LICCC data will severely affect system performance.

User response

It is strongly recommended that you perform a Power On Reset via a disruptive CPC deactivation and activation to verify the new LICCC data.

ACT37171E **Function failed**

Explanation

The operation cannot be performed in a timely manner.

User response

Try the operation again. If the problem continues, contact your next level of support.

ACT37172W **IML required**

Explanation

The system was successfully updated with the new LICCC data. However, validation of the new LICCC data will not occur until the next IML. Incorrect LICCC data will severely affect the system performance. Failure to do a POR after an Undo of a temporary upgrade will prevent successful upgrades in the future.

User response

It is strongly recommended that you perform a Power On Reset to verify the new LICCC data.

ACT37173E **LICCC data corrupted**

Explanation

The request was not performed because the LICCC data is corrupted.

User response

Contact IBM to have your system updated.

ACT37174E **Machine state**

Explanation

The request cannot be performed in the power-off state.

User response

Power on and retry the operation.

ACT37175E **No spare**

Explanation

The request cannot be performed at this time because there is no available hardware to support the LICCC upgrade.

User response

Try the operation again at a later time.

ACT37176E **Not enabled**

Explanation

The request cannot be performed until the feature is enabled.

User response

Contact IBM to have your system updated.

ACT37177W **Upgrade warning**

Explanation

Although the upgrade was successful, it will be lost after the next IML due to a Support Element problem. The next IML will restore the system back to its original configuration.

User response

Perform an IML to restore the system back to its original configuration.

ACT37178W **Partial error**

Explanation

Only a partial upgrade was performed. There is insufficient hardware available for the requested LICCC upgrade.

User response

None.

ACT37179E **Partial success**

Explanation

Request was partially successful. Detected errors were logged.

User response

Refer to the error log.

ACT37180E **System resources are insufficient**

Explanation

System resources are insufficient to perform this operation.

User response

Ensure that all the resources requested to be removed are not in use. See hardware messages for details. Contact your system programmer for assistance.

ACT37181E **System resources are insufficient**

Explanation

Ensure that no more than {0} logically dedicated General Purpose (GP) CPs, {1} ICF CPs, {2} zAAPs, {3} IFLs, and {4} zIIPs are configured online. You need at least one nondedicated GP CP, ICF CP, zAAP, IFL, or zIIP for any logical partitions using shared GP CPs, ICF CPs, zAAPs, IFLs, or zIIPs respectively.

User response

Contact your system programmer.

ACT37182E **Data corrupted**

Explanation

The request was not performed because the retrieved data from the support system is corrupted.

User response

Contact IBM for assistance.

ACT37183E **Retrieve error**

Explanation

An error was detected trying to retrieve data from the support system.

User response

Contact IBM for assistance.

ACT37184E **No data**

Explanation

No data was retrieved from the support system.

User response

Contact IBM for assistance.

ACT37186W **Retry**

Explanation

Request to apply the CIU On/Off CoD was canceled by the user and, therefore, deleted from the system.

User response

Contact IBM for assistance.

ACT37188E **System degraded**

Explanation

The request cannot be done at this time because the system is currently degraded.

User response

Correct the problem and retry the operation.

ACT37190W **TVM mode active**

Explanation

The request cannot be performed while TVM mode is active.

User response

Try the request at a later time.

ACT37191E Request not authorized

Explanation

The request was not performed because the feature data would decrease system performance if activated.

User response

Contact IBM to have your system updated.

ACT37192E Request not authorized

Explanation

The request was not performed because the LICCC data is corrupted.

User response

Contact IBM to have your system updated.

ACT37193E Not authorized

Explanation

The request was not performed because the feature data would downgrade the MCM configuration if activated.

User response

Contact IBM to have your system updated.

ACT37194E Not authorized

Explanation

Request failed due to missing or invalid LICCC data.

User response

Contact IBM to have your system updated.

ACT37195E Not authorized

Explanation

The request was not performed because the LICCC data is not authorized for this system.

User response

Contact IBM to have your system updated.

ACT37197E Not authorized

Explanation

The request was not performed because the LICCC data was previously used.

User response

Contact IBM to have your system updated.

ACT37198E No telephone server

Explanation

The system was unable to connect to the support system because there was no available phone server.

User response

Retry the request when a phone server becomes available.

ACT37199E No RSF connection

Explanation

The system was unable to connect to the support system because there was no RSF connection.

User response

Restore your RSF connection, and retry the request.

ACT37200W Pending data

Explanation

New Customer Initiated Upgrade data cannot be retrieved because previously retrieved unapplied data has been detected.

User response

Apply or remove existing upgrade data before retrieving additional upgrade data.

ACT37201I No data available

Explanation

Customer Initiated Upgrade data is not present on the system.

User response

Contact your next level of support.

ACT37202W **No telephone server**

Explanation

Customer Initiated Upgrade data cannot be retrieved because your system is not registered as a phone server.

User response

Register your server as a phone server, and retry the request.

ACT37203W **No data**

Explanation

There is no retrieved Customer Initiated Upgrade data to be applied. Only unapplied upgrades can be removed.

User response

None.

ACT37204W **Retrieve warning**

Explanation

Defective PUs have been detected while retrieving Customer Initiated Upgrade data. It is strongly recommended that you replace the MCM prior to retrieving the CIU data.

User response

Click **OK** if you want to continue with CIU. Click **Cancel** if you do not want to retrieve the CIU data.

ACT37204I **Order not valid**

Explanation

An incorrect customer order number was entered.

User response

Enter the correct order number or contact IBM for assistance.

ACT37206W **Activate CBU**

Explanation

This CBU activation is not a test CBU.

User response

Click **OK** to continue with the request. Click **Cancel** if you do not want to continue.

ACT37207E **Reboot**

Explanation

A problem was detected while updating the configuration. It is strongly recommended that you perform a Power On Reset after rebooting the Support Element to complete the configuration update. Failure to perform both operations will preserve configuration data mismatches and unexpected system performance problems.

User response

Reboot the Support Element and perform a Power On Reset to complete the configuration update.

ACT37208W **Add hardware**

Explanation

Before beginning the Book operation, required hardware and software must be available.

User response

Verify that all the required hardware and software is available. The following FRUs are needed to complete this operation:

{0}

ACT37209W **Service pending**

Explanation

This system has outstanding service pending. You may wish to postpone this operation until the service has been completed.

User response

Click **OK** to continue or **Cancel** to exit this operation.

ACT37210W **Fenced**

Explanation

The system has fenced books.

User response

Please correct this before trying the requested function.

ACT37211E **Feature data corrupted**

Explanation

The request was not performed because the feature data is corrupted.

User response

Contact IBM to have your system updated.

ACT37212E **Feature data not valid**

Explanation

Request failed due to missing or invalid feature data.

User response

Contact IBM to have your system updated.

ACT37213E **Flexible memory option error**

Explanation

The Flexible Memory Option feature cannot be installed due to insufficient memory.

User response

Contact IBM to have your system updated.

ACT37214I **Memory downgrade**

Explanation

The requested operation cannot be completed at this time. The request to downgrade the system is a disruptive action.

User response

If you want to continue, deactivate the system, power on the CPC, and retry the operation.

ACT37215I **Remove media**

Explanation

The media must be removed from the device.

User response

Remove the media from the device.

ACT37222W **Disruptive partial upgrade**

Explanation

Only a partial upgrade was performed. There is insufficient hardware available for the requested

LICCC upgrade. Validation of the new LICCC data will not occur until the next IML.

User response

None.

ACT37223E **Time out**

Explanation

Unable to establish connection to the support system.

User response

None.

ACT37224I **Insert media**

Explanation

Please ensure that the media has been inserted in the device.

User response

Click **OK** to continue or **Cancel** to exit.

ACT37225E **Not prepared**

Explanation

The request cannot be done at this time. The system is not ready for any Enhanced Book Availability operations at this time.

User response

Perform the *Prepare for Enhanced Book Availability* operation to determine the corrective actions.

ACT37226E **Target error**

Explanation

The request cannot be done at this time. The system is not ready for the Enhanced Book Availability operation on the targeted book.

User response

Perform the *Prepare for Enhanced Book Availability* operation to determine the corrective actions.

ACT37227E **Next level retry**

Explanation

Error detected performing the requested function.

User response

Contact IBM for assistance.

ACT37228E **Next level no retry**

Explanation

Error detected performing the requested function. This function should not be retried.

User response

Contact IBM for assistance.

ACT37229I **Reseat book**

Explanation

A problem was encountered while applying power to the target book. It is possible the book was not seated properly when installed. You can reseat the book at this time and retry the power sequence.

User response

Click **OK** after reseating the book. Click **Cancel** to exit without retrying.

ACT37230I **CBU activation profiles**

Explanation

Activation profiles may be changed due to the configuration update.

User response

None.

ACT37231W **Memory degraded**

Explanation

The system detected degraded memory.

It is strongly recommended that you cancel this request and service this system prior to upgrading system memory.

User response

Click **OK** to continue the memory upgrade request and process the new LICCC data. Validation of the new LICCC data will not occur until the next IML. Click **Cancel** if you do not want to upgrade memory at this time.

ACT37232W **Incorrect memory**

Explanation

The requested memory upgrade cannot be done concurrently because the system is not in the correct Power on Reset state.

User response

Click **OK** to continue the memory upgrade request and process the new LICCC data. Validation of the new LICCC data will not occur until the next IML. Click **Cancel** if you do not want to upgrade memory at this time.

ACT37233W **Add Hardware MRU missing**

Explanation

Add Book Hardware processing cannot continue until the second MRU is installed on the system.

User response

Install the required MRU and retry the action.

ACT37234W **Add Hardware Power error**

Explanation

System power is required for processing any book updates. If system power is on and the request was to Add Book Hardware, then the power system must be upgraded in order to support the additional book.

User response

Power on the system and retry this action.

ACT37235W **Add Hardware DCA error**

Explanation

A DCA plugging error was detected. Add Book Hardware processing cannot continue until the DCA cabling is corrected.

User response

Correct the DCA plugging and retry this action.

ACT37236I **Fanout card rebalancing**

Explanation

You have successfully completed an Add Book Hardware procedure. Determine whether you would like to continue with the fanout card rebalancing.

User response

Click **Yes** to continue with the fanout card rebalancing. Otherwise, click **No**.

ACT37237E **Replug cables**

Explanation

During the FRU activation, STI cables have been detected to be misplugged.

User response

Check the labels on your STI cables and replug them in the same positions they were prior to starting this Enhanced Book Availability (memory add) operation. Click **OK** to continue after replugging the STI cables in the correct locations as per the labels.

ACT37238E **Unsupported hardware**

Explanation

The system was successfully updated with the new LICCC data. However, the request to reset the capacity marker data was not performed because the data file does not match this system or because the capacity marker values in the data file are incorrect. Your system needs to be updated.

User response

Contact IBM to have your system updated.

ACT37242E **On/Off CoD activated**

Explanation

The On/Off CoD order cannot be removed because it has already been activated on the system.

User response

None.

ACT37243E **Timeout**

Explanation

The request could not be performed because the system was unable to connect to the support system in a timely manner.

User response

None.

ACT37245W **Machine state**

Explanation

The system is not in the required state to perform the requested operation. System is not powered on complete.

User response

Power on your system and retry the operation.

ACT37246W **Service required warning**

Explanation

The system is not in the required state to perform the requested operation. Service required is pending.

User response

Repair the service required action and retry the operation.

ACT37247W **Memory degraded**

Explanation

The system is not in the required state to perform the requested operation. Memory is degraded.

User response

Repair the memory and retry the operation.

ACT37248W **Processors pending warning**

Explanation

The system is not in the required state to perform the requested operation. The system has processors pending activation from a previous temporary processor activation request.

User response

Deactivate enough temporary processors to satisfy the pending state or wait until resources become available and retry the operation.

ACT37249W **Missing file**

Explanation

The system cannot perform the requested operation because the required input data was not found.

User response

None.

ACT37258W **Invalid CP-KCID warning**

Explanation

The system cannot perform the requested operation because the input data has an invalid CP-KCID combination.

User response

Contact IBM for new upgrade data.

ACT37259W Invalid maximum processors

Explanation

The system cannot perform the requested operation because the input data has a maximum processor value.

User response

Contact IBM for new upgrade data.

ACT37260W Invalid maximum processors

Explanation

The system cannot perform the requested operation because the input data has a maximum processor value that is not consistent with the current book configuration.

User response

Contact IBM for new upgrade data.

ACT37261W Invalid SAP processors

Explanation

The system cannot perform the requested operation because the input data has an invalid SAP processor value that is not consistent with the current book configuration.

User response

Contact IBM for new upgrade data.

ACT37262W Not Power On Reset

Explanation

The system is not in the required state to perform the requested operation. System is not in Power On Reset complete state.

User response

Power On Reset your system and retry the operation.

ACT37263W Invalid KCID

Explanation

The system cannot perform the requested operation because the input data has an invalid capacity marker value.

User response

Contact IBM for new upgrade data.

ACT37264W Invalid maximum purchased CPUs

Explanation

The system cannot perform the requested operation because the input data has an invalid maximum purchased CPUs value.

User response

Contact IBM for new upgrade data.

ACT37265W Invalid maximum purchased KCID

Explanation

The system cannot perform the requested operation because the input data has an invalid maximum purchased capacity marker value.

User response

Contact IBM for new upgrade data.

ACT37266W Invalid CP and SAP combinations

Explanation

The system cannot perform the requested operation because the input data has an invalid maximum processor and SAP processors combination.

User response

Contact IBM for new upgrade data.

ACT37267W No memory size

Explanation

The system cannot perform the requested operation because the input data has no memory size defined.

User response

Contact IBM for new upgrade data.

ACT37268E Exceeding physical memory

Explanation

The system cannot perform the requested operation because the processor LICCC upgrade data exceeds the physical capacity of processor hardware.

User response

Contact IBM for assistance.

ACT37269E No media selection

Explanation

A media type was not selected.

User response

Select a media type and click **OK**.

ACT37270W Successful upgrade

Explanation

The permanent upgrade activation was successful. However, some or all resources from an active temporary billable record (On/Off CoD) were converted to permanent to fulfill the request.

User response

To view the latest temporary processor configuration, from the **Perform Model Conversion** window, select the **Manage** option. If zero resources are active for this temporary billable record, deactivate the record by using the Undo button.

ACT37271E Authorization error

Explanation

The requested activation could not be performed because the record is not authorized for the configuration changes requested or the specified target configuration does not exist.

User response

Retry again with less resources.

ACT37272E On/Off CoD error

Explanation

The requested activation could not be performed because only one billable capacity record can be active in the system at a time. The active billable record must be deactivated (Undo) before activating a new record.

User response

Use the **Manage** option on the **Perform Model Conversion** window to manage the records.

ACT37273E Invalid request

Explanation

The request to install a temporary process record could not be performed at this time because the maximum allowed records are already installed.

User response

Use the **Manage** option on the **Perform Model Conversion** window to manage the records.

ACT37274E Invalid state

Explanation

The request to remove a temporary processor record could not be performed at this time because it is currently active.

User response

Deactivate the record and try again.

ACT37275E Authorization error

Explanation

The temporary processor record cannot be activated with the parameters you selected due to one or more of the following expiration reasons:

- No real or test activations are left for this record
- Insufficient processor/MSU tokens are left in the token pools
- Record expiration date has been reached
- The number of activation days is exceeded.

User response

Use different activation parameters or contact IBM to discuss your options about this record.

ACT37276W Confirmation warning

Explanation

Are you sure you want to update the LICCC data?

	Original	New
CPs	{0}	{1}

	Original	New
SAPs	{2}	{3}
ICFs	{4}	{5}
IFLs	{6}	{7}
zAAPs	{8}	{9}
zIIPs	{10}	{11}
Model-Capacity Identifier	{12}	{13}
Memory (GB)	{14}	{15}
Crypto Assists Feature	{16}	{17}

The memory size will be decreased by the amount of the HSA. For the actual memory usage sizes, refer to the **Storage Information** window.

User response

View the information in the table and click **Yes** to make the changes you selected. Otherwise, click **No**.

ACT37277W **Order not valid**

Explanation

The requested upgrade cannot be performed because the order number is required to be eight characters.

User response

Click **OK** to enter the order number again, or click **Cancel** if you do not want to perform this request at this time.

ACT37280E **Operation not performed**

Explanation

The permanent LICCC operation could not be performed at this time because there is a conflict with the currently active temporary CP resources.

User response

Deactivate some temporary resources and retry this permanent LICCC operation.

ACT37292W **Status ready**

Explanation

Upon the selection of a book, the *Perform Enhanced Book Availability* request will evacuate resources and will power off the selected book.

User response

Click **OK** to continue. If you do not want to perform the request at this time, click **Cancel**.

ACT37293I **Status ready**

Explanation

The *Prepare for Enhanced Book Availability* has been performed on Book {0}. The book is ready for the *Prepare for Enhanced Book Availability* step.

User response

None.

ACT37294W **Confirmation warning**

Explanation

The following processor allocation will be made if **OK** is selected. Click **Cancel** if you wish to not make changes or abort the allocation.

- Number of CPUs = {0}
- Number of ICFs = {1}
- Number of IFLs = {2}
- Number of zAAPs = {3}
- Number of zIIPs = {4}
- PU's not assigned = {5}

User response

Click **OK** to continue or **Cancel** to exit.

ACT37295E **Reassign not numeric data**

Explanation

The data for {0} at *Non-Dedicated Count* is not of a numeric format.

User response

Enter the data again.

ACT37296E **Reassign column error**

Explanation

The total value of {0} for *Non-Dedicated Count* PUs will exceed the allowable value of {1}.

User response

Readjust the entered values in the *Non-Dedicated Count* column for the various PUs.

ACT37297E **Reassign row error**

Explanation

The {0} entry value of {1} would make the total for this entry greater than the allowed LICCC value of {2} for this type of PU.

User response

Correct the entered value in the nondedicated PUs row for {0}.

ACT37298E **Book selection no changes**

Explanation

You must select a target book for the chosen action.

User response

Select a target book.

ACT37299E **Add Book Hardware error**

Explanation

An error occurred that prevents the book from being added.

{0}

User response

Click **OK** to start removing the hardware. Use the windows to remove all the hardware in the reverse order of installation.

ACT37300E **Perform Model Conversion error**

Explanation

While doing a **Perform Model Conversion** Hardware Management Console (HMC) Single Object Operations on a media device, the following error occurred:

{0} (rc={1})

User response

Click **Yes** to retry the operation. Click **No** if you wish to exit.

ACT37460I **No temporary records**

Explanation

There are no temporary upgrade records on the system.

User response

None.

ACT37461Q **Delete confirmation**

Explanation

- Are you sure you want to permanently remove this record from the system?
 - Record ID: {0}
 - Description: {1}

User response

Click **Yes** to delete. Click **No** to exit.

ACT37462E **Invalid state**

Explanation

This record cannot be removed because it is currently active. If you want to remove this record, you must deactivate it first.

User response

To deactivate the record, you must remove all the temporary processors and decrease the capacity to the permanent capacity available on this record.

ACT37463Q **Description confirmation**

Explanation

Are you sure you want to change the record description from {0} to {1}?

User response

Click **Yes** to change the description. Click **No** if you want to leave the description as it is.

ACT37464Q **Temporary change confirmation**

Explanation

- Are you sure you want to change the activation levels for this record?
 - Record ID: {0}
 - Description: {1}
 - Activation type: {2}

	Original	New
Model-Capacity Identifier	{3}	{10}
CPs	{4}	{11}
SAPs	{5}	{12}
ICFs	{6}	{13}
IFLs	{7}	{14}
zAAPs	{8}	{15}
zIIPs	{9}	{16}

User response

View the information in the table and click **Yes** to make the changes you selected. Otherwise, click **No**.

ACT37465Q Install temporary records

Explanation

This is a replenishment record and cannot be installed by itself. When installing a replenishment record, the associated new record and all its replenishment records are installed and one install slot is used. The replenishment records are applied to the new record in the order they were placed in the staged area according to their timestamps.

Would you like to install the associated new record and all its replenishment records?

User response

Click **Yes** if you want all replenishment records and the associated record installed. Otherwise, click **No**.

ACT37466Q Install temporary records

Explanation

- If a record in the staged area has any replenishment records (identified by the same record ID), then when this record is installed, all the replenishment records with the same record ID will also be installed and only one install slot will be used. The replenishment records are applied to the new record in the order they were placed in the staged area according to their timestamps.

Are you sure you want to install this record and all its replenishment records?

- Record ID: {0}
- Description: {1}

User response

Click **Yes**, if you want all the records installed. Otherwise, click **No**.

ACT37467Q Removing staged temporary records

Explanation

- Are you sure you want to permanently remove this record and all its replenishments from the system?
 - Record ID: {0}
 - Description: {1}

User response

Click **Yes** to remove this record and all its replenishment records. Otherwise, click **No**.

ACT37468Q Confirmation

Explanation

Are you sure you want to cancel without saving your changes?

User response

Click **Yes** if you do not want to save your changes. Otherwise, click **No**.

ACT37469I Message wrapper

Explanation

{0}
{1}

User response

None.

ACT37470I History display

Explanation

There is no upgrade history on the system.

User response

None.

ACT37471I History display

Explanation

Record ID: {0}
Action: {1}

Date: {2}
Order number: {3}
Source: {4}
Net ID: {5}
NAU: {6}
{7}
Model-Capacity Identifier for this record: {8}

Activated Levels

	SA	ICF	IFL	zA	zII
CPs	Ps	s	s	APs	Ps
{9}	{10}	{11}	{12}	{13}	{14}

User response

None.

ACT37472I **History display**

Explanation

Action: {0}
Date: {1}
Order number: {2}
Source: {3}
Net ID: {4}
NAU: {5}
{6}
Model-Capacity Identifier: {7}
Maximum Model-Capacity Identifier: {8}
Unassigned IFLs: {9}

Activated Levels

	SA	ICF	IFL	zA	zII
CPs	Ps	s	s	APs	Ps
{10}	{11}	{12}	{13}	{14}	{15}

User response

None.

ACT37473I **History display**

Explanation

Record ID: {0}
Action: {1}
Date: {2}
Order number: {3}
Source: {4}
Net ID: {5}

NAU: {6}
{7}

User response

None.

ACT37474I **History display**

Explanation

- Record ID: {0}
- Action: {1}
- Date: {2}
- Order number: {3}

User response

None.

ACT37500W **Timeout**

Explanation

The requested operation cannot be done at this time because a CDU operation is in progress.

User response

Please try again in approximately 10 minutes.

ACT37501E **SE error**

Explanation

An error was encountered requiring the SE to be rebooted.

User response

Reboot the Support Element.

ACT37502W **Change Management**

Explanation

The requested operation cannot be done at this time because change management is permanently disabled.

User response

None.

ACT37503E **Internal error**

Explanation

An error was encountered acquiring change management status.

User response

Try the operation again. If the problem continues, contact your next level of support.

ACT37519W

Explanation

The requested permanent MES cannot be performed because one or more temporary records are currently active. One or more of the following conditions might display. Resolve all of the conditions and retry the operation.

- This system has $\{nn\}$ pending PUs from a previous CBU activation with force activation option, and has no available PU. Uncheck the **Force activation** checkbox for record ID $\{ID\}$ and modify this record's activation levels to remove the pending PUs condition. Alternatively, you can also remove the pending resources condition by deactivating resources from other temporary records.
- The target configuration with the new permanent MES configuration and the current active temporary upgrades is outside of valid configuration. Your current model capacity identifier is $\{nn\}$ and you tried to increase the model capacity levels by $\{nn\}$ steps and/or $\{nn\}$ CPs. Deactivate temporary capacity (by removing temporary CPs, decreasing temporary model capacity, or performing Undo to deactivate all the resources) from some or all temporary records in order to make the permanent upgrade target configuration valid.
- Not enough available PUs exist in the system. Deactivate at least $\{nn\}$ PUs from temporary records.
- One or more active temporary upgrades increased the model capacity level and the target configuration results in the model capacity identifiers 713 through

764. Deactivate all temporary model capacity levels from the following temporary record IDs: $\{ID1\}$, $\{ID2\}$, ...

- One or more CBU records do not have enough CBU feature codes left to satisfy the new permanent configuration. Remove all temporary model capacity levels,

or $\{n1\}$ temporary processors from record ID $\{ID1\}$

or $\{n2\}$ temporary processors from record ID $\{ID2\}$

or $\{n3\}$ temporary processors from record ID $\{ID3\}$

⋮

Otherwise, contact IBM to discuss your replenishment options for these records.

Note: You can have up to eight records.

- The new permanent configuration plus the number of active temporary SAPs exceeds the allowed maximum. Deactivate at least $\{nn\}$ SAPs from temporary records.

User response

Resolve each applicable condition and retry the operation.

ACT37520I

Explanation

The requested permanent MES can be performed.

User response


None.

Appendix B. Exporting your profile data

When a CBU is activated, more processors are activated in the system. When making any change to your activation profiles, it is recommended to export your profiles for safe keeping. You can save profile data to a USB flash memory drive or hard drive.

To export your profile data, follow these steps:

1. Log onto the HMC in system programmer mode.
2. Expand the nodes in the navigation pane and select the appropriate server.
3. Expand the task list and select **Single Object Operations** (located in the Recovery task list) to open a Support Element session for the selected server.
4. Make sure the correct server name is listed and selected, and click **Yes**.
5. From the Support Element, expand the nodes in the navigation pane and select the server name.
6. Expand the task list and select **Export/Import Profile Data** (located in the Operational Customization list). The **Export/Import Profiles** window opens:



7. Select where you want your profiles exported:
 - To hard drive
 - To USB flash memory drive.
8. Click **OK**.

Appendix C. Understanding the content of the Installed Records page in the Temporary Upgrades window

P000BB01: Perform Model Conversion

Temporary Upgrades - P000BB01

Installed Records | Staged Records

The following table shows all the installed records on the system.
 - To view a record description, place the mouse over the record.
 - The processors in the table are represented as "Maximum/Pending/Active"

Record ID	Record Type	CLIs	CPs	SAPs	ICFs	IFLs	zIIPs	Status
CB9U2VC3	CBU(pre-paid)	*/0/0	*/0/0	2/0/0	1/0/0	4/0/0	3/0/0	Installed
CR9U2TXT	On/Off CoD(post-paid)	*/0/0	*/0/0	4/0/0	2/0/0	2/0/0	2/0/0	Installed
Active Temporary		0	0	0	0	0	0	
Permanent		-	4	6	2	2	2	
Total Used		0	4	6	2	2	2	

Description: +12 FCs model capacity, +1 ICF, +3 zIIP, +4 IFL, +2 SAP
 Status details: N/A
 * - For CPs and CLIs, the maximum value is determined by an offering specific algorithm that accounts for engines, capacity level changes, and resulting capacity. For all other processor types, the maximum value is unlimited.

System Summary

Model-Capacity Identifier: 604 MSUs: 471
 Model-Temporary-Capacity Identifier: 604 Available PUs: 20
 Model-Permanent-Capacity Identifier: 604

Details... | Add processors... | Remove processors... | Delete | Help

Cancel

For each record listed on the **Installed Records** page, three values (Maximum/Pending/Active) display for the model capacity information (CLIs and CPs) and the specialty engines (SAPs, ICFs, IFL, and zIIPs).

- Maximum = the maximum value of temp resources that can be activated for a given type
- Pending = the number of resources of that type there are pending activation (applies to active CBU records only)
- Active = the current number of active resources of that type on this record.

For the specialty engines, the numbers always represent the number of engines of that type that fit into the category. For example, an IFL with the values 4/1/1 mean that the record can activate a maximum of 4 IFLs, has 1 IFL in pending activation state, and has 1 IFL active.

Model capacity has two columns, CLIs and CPs, because of subcapacity engines. Model capacity is identified by a capacity level and a number of CP engines: 4xx, 5xx, 6xx, and 7xx.

For example, a 408 is a system running at capacity level 4, with 8 engines active. Because it is possible to set limits based on either the capacity level or the number of CP engines, two columns are displayed (CLIs and CPs). The CLI column shows how many capacity level increases the record allows, and the CP column shows the number of additional CP engines that may be activated by the record. Whether there is a value in the CLI and CP columns depends on whether the record limits activations by CLI or CP increments. The CPE offering limits activations based on CP or CLI counts. In the example, a CLI value of 3/0/0 means that the CPE record may increase the model capacity up to 3 capacity levels. The example machine is a 408, so the CLI column allows the increase of the capacity from a 408 to a 508 (+1 CLI), 608 (+2 CLI), or 708 (+3 CLI). The CP value of 1/0/0 means that only one additional CP engine may be activated. The combination of the two columns allows the customer to activate model capacity levels between a 408 and a 709.

On/Off CoD records always show an * for the CLI and CP Maximum value because the record limits activations by percentage of capacity increased, not CLI or engine increments. CBU records also show as an * for the CLI and CP maximum value because the CBU record contains the number of CP features that can be applied, and a CP feature can be used to increase the number of engines or to increase an engine any number of capacity levels. It is not a specific limit of engines or capacity levels. The Pending and Active values for these two offerings are not * because, once activated, the activations can be represented in terms of a number of capacity levels or CP engines. For example, if the On/Off CoD record was activated to raise the current 408 capacity to a 609, the record would show a CLI value of */0/2 and a CP value of */0/1 because the capacity level was increased 2 levels (4 to 6) and 1 additional CP engine was added.

Appendix D. Notices

This information was developed for products and services offered in the US.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not grant you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing
IBM Corporation
North Castle Drive, MD-NC119
Armonk, NY 10504-1785
US

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM websites are provided for convenience only and do not in any manner serve as an endorsement of those websites. The materials at those websites are not part of the materials for this IBM product and use of those websites is at your own risk.

IBM may use or distribute any of the information you provide in any way it believes appropriate without incurring any obligation to you.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

Statements regarding IBM's future direction or intent are subject to change or withdrawal without notice, and represent goals and objectives only.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to actual people or business enterprise is entirely coincidental.

Trademarks

IBM, the IBM logo, and [ibm.com](http://www.ibm.com)[®] are trademarks or registered trademarks of International Business Machines Corporation, in the United States and/or other countries. Other product and service names might be trademarks of IBM or other companies. A current list of IBM trademarks is available on <http://www.ibm.com/trademark>.

The registered trademark Linux® is used pursuant to a sublicense from the Linux Foundation, the exclusive licensee of Linus Torvalds, owner of the mark on a worldwide basis.

Microsoft, Windows, and the Windows logo are trademarks of Microsoft Corporation in the United States, other countries, or both.

Other product and service names might be trademarks of IBM or other companies.

Class A Notices

The following Class A statements apply to this IBM product. The statement for other IBM products intended for use with this product will appear in their accompanying manuals.

Federal Communications Commission (FCC) Statement

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Industry Canada Compliance Statement

This Class A digital apparatus complies with Canadian ICES-003.

United Kingdom Notice

This product may cause interference if used in residential areas. Such use must be avoided unless the user takes special measures to reduce electromagnetic emissions to prevent interference to the reception of radio and television broadcasts.

Avis de conformité à la réglementation d'Industrie Canada

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

European Community Compliance Statement

This product is in conformity with the protection requirements of EU Council Directive 2014/30/EU on the approximation of the laws of the Member States relating to electromagnetic compatibility. IBM cannot accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product, including the fitting of non-IBM option cards.

This product has been tested and found to comply with the limits for Class A Information Technology Equipment according to European Standard EN 55032. The limits for Class A equipment were derived for commercial and industrial environments to provide reasonable protection against interference with licensed communication equipment.

European Community contact:
IBM Deutschland GmbH

Technical Regulations, Department M372
IBM-Allee 1, 71139 Ehningen, Germany
Tele: +49 (0) 800 225 5423 or +49 (0) 180 331 3233
email: halloibm@de.ibm.com

Warning: This is a Class A product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

VCCI Statement - Japan

この装置は、クラス A 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。 VCCI-A

The following is a summary of the Japanese VCCI statement above:

This is a Class A product based on the standard of the VCCI Council. If this equipment is used in a domestic environment, radio interference may occur, in which case the user may be required to take corrective actions.

Japan Electronics and Information Technology Industries Association (JEITA) Notice

(一社) 電子情報技術産業協会 高調波電流抑制対策実施
要領に基づく定格入力電力値 : IBM Documentationの各製品の仕様ページ参照

This statement applies to products less than or equal to 20 A per phase.

高調波電流規格 JIS C 61000-3-2 適合品

These statements apply to products greater than 20 A, single-phase.

高調波電流規格 JIS C 61000-3-2 準用品

本装置は、「高圧又は特別高圧で受電する需要家の高調波抑制対策ガイドライン」対象機器（高調波発生機器）です。

回路分類 : 6 (単相、PFC回路付)

換算係数 : 0

These statements apply to products greater than 20 A per phase, three-phase.

高調波電流規格 JIS C 61000-3-2 準用品

本装置は、「高圧又は特別高圧で受電する需要家の高調波抑制対策ガイドライン」対象機器（高調波発生機器）です。

回路分類 : 5 (3相、PFC回路付)

換算係数 : 0

Electromagnetic Interference (EMI) Statement - People's Republic of China

警 告

此为 A 级产品，在生活环境中，
该产品可能会造成无线电干扰。
在这种情况下，可能需要用户对
其干扰采取切实可行的措施。

Declaration: This is a Class A product. In a domestic environment, this product may cause radio interference, in which case the user may need to perform practical action.

Taiwan Notice

CNS 13438:

警告使用者：

此為甲類資訊技術設備，
於居住環境中使用時，
可能會造成射頻擾動，在此種情況下，
使用者會被要求採取某些適當的對策。

CNS 15936:

警告：為避免電磁干擾，本產品不應安裝或使用於住宅環境。

IBM Taiwan Contact Information:

台灣IBM 產品服務聯絡方式：
台灣國際商業機器股份有限公司
台北市松仁路7號3樓
電話：0800-016-888

Electromagnetic Interference (EMI) Statement - Korea

이 기기는 업무용(A급)으로 전자파적합등록을 한 기기이오니
판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의
지역에서 사용하는 것을 목적으로 합니다.

Germany Compliance Statement

Deutschsprachiger EU Hinweis: Hinweis für Geräte der Klasse A EU-Richtlinie zur Elektromagnetischen Verträglichkeit

Dieses Produkt entspricht den Schutzanforderungen der EU-Richtlinie 2014/30/EU zur Angleichung der Rechtsvorschriften über die elektromagnetische Verträglichkeit in den EU-Mitgliedsstaaten und hält die Grenzwerte der EN 55032 Klasse A ein.

Um dieses sicherzustellen, sind die Geräte wie in den Handbüchern beschrieben zu installieren und zu betreiben. Des Weiteren dürfen auch nur von der IBM empfohlene Kabel angeschlossen werden. IBM übernimmt keine Verantwortung für die Einhaltung der Schutzanforderungen, wenn das Produkt ohne Zustimmung von IBM verändert bzw. wenn Erweiterungskomponenten von Fremdherstellern ohne Empfehlung von IBM gesteckt/eingebaut werden.

EN 55032 Klasse A Geräte müssen mit folgendem Warnhinweis versehen werden:

"Warnung: Dieses ist eine Einrichtung der Klasse A. Diese Einrichtung kann im Wohnbereich Funk-Störungen verursachen; in diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen zu ergreifen und dafür aufzukommen."

Deutschland: Einhaltung des Gesetzes über die elektromagnetische Verträglichkeit von Geräten

Dieses Produkt entspricht dem "Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG)". Dies ist die Umsetzung der EU-Richtlinie 2014/30/EU in der Bundesrepublik Deutschland.

Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG) (bzw. der EMC EG Richtlinie 2014/30/EU) für Geräte der Klasse A

Dieses Gerät ist berechtigt, in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen.

Verantwortlich für die Einhaltung der EMV Vorschriften ist der Hersteller:

International Business Machines Corp.
New Orchard Road
Armonk, New York 10504
Tel: 914-499-1900

Der verantwortliche Ansprechpartner des Herstellers in der EU ist:

IBM Deutschland GmbH
Technical Regulations, Abteilung M372
IBM-Allee 1, 71139 Ehningen, Germany
Tel: +49 (0) 800 225 5423 or +49 (0) 180 331 3233
email: halloibm@de.ibm.com

Generelle Informationen:

Das Gerät erfüllt die Schutzanforderungen nach EN 55024 und EN 55032 Klasse A.

Electromagnetic Interference (EMI) Statement - Russia

ВНИМАНИЕ! Настоящее изделие относится к классу А.

В жилых помещениях оно может создавать радиопомехи, для снижения которых необходимы дополнительные меры

Index

A

accessibility
 contact IBM [x](#)
 features [x](#)
activating temporary records
 scheduled operations [74](#)
 SNMP APIs [75](#)
applying upgrades [59](#)
assistive technologies [x](#)

B

benefits [1](#)
billing [87](#)

C

canceling an upgrade record [57](#)
capacity limits [29](#)
CBU
 applying [63](#)
 canceling [57](#)
 CP feature codes [33](#)
 installing [63](#)
 ordering
 considerations [33](#)
 planning [14](#)
 replenishing [54](#)
 retrieving [63](#)
 software considerations [16](#)
CIU Express [31](#)
CP feature codes [33](#)
CPE
 applying [63](#)
 canceling [57](#)
 installing [63](#)
 ordering
 considerations [34](#)
 planning [16](#)
 retrieving [63](#)
 software considerations [16](#)
current purchased capacity [31](#)

D

deactivating temporary records
 scheduled operations [74](#)
 SNMP APIs [75](#)
deactivating temporary upgrades [77](#)
discontinuing use of CoD features [93](#)
downloading upgrades [59](#)

E

enablement [21](#)

enablement feature codes [21](#)
exporting profile data [115](#)

I

installing upgrades [59](#)

K

keyboard
 navigation [x](#)

M

messages [97](#), [98](#)
monitoring activity
 SNMP APIs [89](#)
 STSI instructions [89](#)
 Support Element task [89](#)

N

navigation
 keyboard [x](#)

O

On/Off CoD
 applying [63](#)
 canceling [57](#)
 installing [63](#)
 ordering
 considerations [31](#)
 planning [11](#)
 replenishing [54](#)
 retrieving [63](#)
 software considerations [13](#)
On/Off CoD test record
 canceling [57](#)
 ordering
 considerations [33](#)
order status definitions [97](#)
ordering
 CP feature codes [33](#)
 permanent upgrades [29](#)
 replenishment record [54](#)
 temporary records [31](#)

P

permanent upgrades
 applying [59](#)
 canceling [57](#)
 capacity limits [29](#)
 CIU Express [31](#)
 installing [59](#)

- permanent upgrades (*continued*)
 - ordering
 - considerations [29](#)
 - steps [35](#)
 - planning [3](#)
 - retrieving [59](#)
 - software considerations [10](#)
 - specialty engine limits [29](#)
- planning
 - CBU [14](#)
 - CPE [16](#)
 - On/Off CoD [11](#)
 - permanent upgrades [3](#)
 - System Recovery Boost Upgrade [17](#)
- prepaid On/Off CoD
 - replenishing [54](#)

R

- related publications [x](#)
- removing CoD features [93](#)
- removing temporary CoD features [83](#)
- replenishment record
 - ordering [54](#)
- retrieving upgrades [59](#)

S

- scheduled operations
 - activating/deactivating temporary records [74](#)
- shortcut keys [x](#)
- SNMP APIs
 - activating/deactivating temporary records [75](#)
 - monitoring activity [89](#)
- software considerations
 - CBU [16](#)
 - CPE [16](#)
 - On/Off CoD [13](#)
 - permanent upgrades [10](#)
- specialty engine limits [29](#)
- STSI instructions
 - monitoring activity [89](#)
- subcapacity CP activation [17](#)
- System Recovery Boost Upgrade
 - applying [63](#)
 - installing [63](#)
 - ordering
 - considerations [35](#)
 - planning [17](#)
 - retrieving [63](#)

T

- temporary upgrades
 - applying [63](#)
 - deactivating [77](#)
 - installing [63](#)
 - ordering
 - considerations [31](#)
 - steps [35](#)
 - retrieving [63](#)

U

- unassigned model capacity and IFL considerations [12](#)
- upgrade process [2](#)
- upgrade record
 - replenishing [54](#)

Z

- z/OS Capacity Provisioning [75](#)



SC28-7025-00

